

SINUMERIK 828D SINUMERIK Integrate Run MyScreens

Programming Manual

Valid for

CNC software version 4.95

10/2020
6FC5398-4EP40-0BA0

Introduction	1
Fundamental safety instructions	2
Functional scope	3
Getting Started	4
Fundamentals	5
Dialogs	6
Variables	7
Programming commands	8
Graphic and logic elements	9
"Custom" operating area	10
Dialog selection	11
Examples for cycle masks	12
Configuration in the side screen	13
Configuration in the Display Manager	14
Reference lists	A
Tips and tricks	B
Animated elements	C

Legal information

Warning notice system

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring only to property damage have no safety alert symbol. These notices shown below are graded according to the degree of danger.

DANGER

indicates that death or severe personal injury will result if proper precautions are not taken.
--

WARNING
--

indicates that death or severe personal injury may result if proper precautions are not taken.

CAUTION
--

indicates that minor personal injury can result if proper precautions are not taken.
--

NOTICE

indicates that property damage can result if proper precautions are not taken.
--

If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

Qualified Personnel

The product/system described in this documentation may be operated only by **personnel qualified** for the specific task in accordance with the relevant documentation, in particular its warning notices and safety instructions. Qualified personnel are those who, based on their training and experience, are capable of identifying risks and avoiding potential hazards when working with these products/systems.

Proper use of Siemens products

Note the following:

WARNING
--

Siemens products may only be used for the applications described in the catalog and in the relevant technical documentation. If products and components from other manufacturers are used, these must be recommended or approved by Siemens. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be complied with. The information in the relevant documentation must be observed.
--

Trademarks

All names identified by ® are registered trademarks of Siemens AG. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

Disclaimer of Liability

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

Table of contents

1	Introduction	9
1.1	About SINUMERIK	9
1.2	About this documentation	9
1.3	Documentation on the internet	10
1.3.1	Documentation overview SINUMERIK 828D	10
1.3.2	Documentation overview SINUMERIK operator components	10
1.4	Feedback on the technical documentation	11
1.5	mySupport documentation	11
1.6	Service and Support.....	12
1.7	Important product information	13
2	Fundamental safety instructions.....	15
2.1	General safety instructions.....	15
2.2	Warranty and liability for application examples	15
2.3	Security information	15
3	Functional scope.....	17
3.1	Range of functions of "Run MyScreens".....	17
4	Getting Started	21
4.1	Introduction.....	21
4.2	Project example	21
4.2.1	Task description	21
4.2.2	Creating the configuration file (example).....	25
4.2.3	Saving the configuration file in the OEM directory (example)	28
4.2.4	Creating the online help (example)	29
4.2.5	Integrating the online help and saving the files to the OEM directory (example)	32
4.2.6	Copying "easyscreen.ini" into the OEM directory (example).....	33
4.2.7	Registering the COM file in "easyscreen.ini" (example)	33
4.2.8	Testing the project (example)	33
5	Fundamentals.....	35
5.1	Structure of configuration file	35
5.2	Structure of the menu tree	36
5.3	Definition and functions for start softkeys.....	38
5.3.1	Defining the start softkey	38
5.3.2	Functions for start softkeys	39
5.4	Troubleshooting (log book)	41
5.5	Notes on "easyscreen.ini"	42

5.6	Notes for personnel changing over to "Run MyScreens"	44
5.7	Extended configuration syntax	45
5.8	SmartOperation and MultiTouch operation	47
6	Dialogs	49
6.1	Structure and elements of a dialog	49
6.1.1	Defining a dialog	49
6.1.2	Defining dialog properties	51
6.1.3	Defining dialog elements	58
6.1.4	Defining dialogs with multiple columns	60
6.1.5	Password dialogs	61
6.1.6	Using display images/graphics	63
6.2	Defining softkey menus	63
6.2.1	Changing softkey properties during runtime	66
6.2.2	Language-dependent text	69
6.3	Configuring the online help	72
6.3.1	Overview	72
6.3.2	Generating HTML files	73
6.3.3	Generating the help book	76
6.3.4	Integrating the online help in SINUMERIK Operate	78
6.3.5	Saving help files	80
6.3.6	Help files in PDF format	80
7	Variables	83
7.1	Defining variables	83
7.2	Application examples	84
7.3	Example 1: Assigning the variable type, texts, help display, colors, tooltips	85
7.4	Example 2: Assigning the Variable Type, Limits, Attributes, Short Text Position properties	86
7.5	Example 3: Assigning the Variable Type, Default, System or User Variable, Input/Output Field Position properties	87
7.6	Example 4: Toggle field and list field	87
7.7	Example 5: Image display	88
7.8	Example 6: Progress bar	88
7.9	Example 7: Password input mode (asterisk)	91
7.10	Variable parameters	91
7.11	Details on the variable type	97
7.12	Details on the toggle field	100
7.13	Details on the default setting	101
7.14	Details on the position of the short text, position of the input/output field	102
7.15	Use of strings	103
7.16	CURPOS variable	105
7.17	CURVER variable	105

7.18	ENTRY variable.....	106
7.19	ERR variable.....	107
7.20	FILE_ERR variable.....	107
7.21	FOC variable.....	109
7.22	Variable S_ALEVEL.....	110
7.23	S_CHAN variable.....	110
7.24	Variable S_CONTROL.....	111
7.25	Variable S_LANG.....	111
7.26	Variable S_NCCODEREADONLY.....	112
7.27	Variables S_RESX and S_RESY.....	112
8	Programming commands.....	115
8.1	Operators.....	115
8.1.1	Mathematical operators.....	115
8.1.2	Bit operators.....	118
8.2	Methods.....	119
8.2.1	ACCESSLEVEL.....	120
8.2.2	CHANGE.....	120
8.2.3	CHANNEL.....	122
8.2.4	CONTROL.....	122
8.2.5	FOCUS.....	123
8.2.6	LANGUAGE.....	123
8.2.7	LOAD.....	124
8.2.8	UNLOAD.....	125
8.2.9	OUTPUT.....	125
8.2.10	PRESS.....	126
8.2.11	PRESS(ENTER).....	127
8.2.12	PRESS(TOGGLE).....	127
8.2.13	RESOLUTION.....	128
8.2.14	RESUME.....	129
8.2.15	SUSPEND.....	129
8.2.16	Example: Version management with OUTPUT methods.....	130
8.3	Functions.....	131
8.3.1	Reading and writing drive parameters: RDOP, WDOP, MRDOP.....	132
8.3.2	Subprogram call (CALL).....	134
8.3.3	Define block (/B).....	135
8.3.4	Check Variable (CVAR).....	136
8.3.5	Copy Program file function (CP).....	137
8.3.6	Delete Program file function (DP).....	138
8.3.7	Exist Program file function (EP).....	139
8.3.8	Move Program file function (MP).....	140
8.3.9	Select Program file function (SP).....	141
8.3.10	File accesses: RDFILE, WRFILE, RDLINEFILE, WRLINEFILE.....	141
8.3.11	Dialog line (DLGL).....	144
8.3.12	DEBUG.....	145
8.3.13	Exit dialog (EXIT).....	145

8.3.14	Dynamic manipulation of the lists of toggle fields or list box fields.....	147
8.3.15	Evaluate (EVAL)	149
8.3.16	Exit Loading Softkey (EXITLS)	151
8.3.17	Function (FCT)	151
8.3.18	Generate code (GC)	153
8.3.19	Password functions	156
8.3.20	Load Array (LA)	157
8.3.21	Load Block (LB)	158
8.3.22	Load Mask (LM)	159
8.3.23	Load Softkey (LS)	160
8.3.24	Load Grid (LG).....	161
8.3.25	Multiple selection SWITCH.....	162
8.3.26	Multiple Read NC PLC (MRNP).....	163
8.3.27	P_LOGICAL_FILEPATH	165
8.3.28	P_REAL_FILEPATH.....	166
8.3.29	PI services.....	166
8.3.30	Reading (RNP) and writing (WNP) system or user variables.....	167
8.3.31	RESIZE_VAR_IO and RESIZE_VAR_TXT.....	168
8.3.32	Register (REG).....	169
8.3.33	RETURN	171
8.3.34	Recompile.....	171
8.3.35	Recompile without user comment.....	173
8.3.36	Search Forward, Search Backward (SF, SB)	176
8.3.37	SL_HMI_INSTALL_DIR	177
8.3.38	SL_TEMP_DIR.....	177
8.3.39	STRING functions	177
8.3.40	WHILE/UNTIL loops.....	183
8.3.41	Cyclic execution of scripts: START_TIMER, STOP_TIMER.....	186
9	Graphic and logic elements	189
9.1	Line, dividing line, rectangle, circle and ellipse	189
9.1.1	Defining graphic elements.....	189
9.1.2	Graphic functions	192
9.2	Defining an array	194
9.2.1	Accessing the value of an array element.....	195
9.2.2	Example Access to an array element.....	197
9.2.3	Scanning the status of an array element.....	198
9.3	Table description (grid)	199
9.3.1	Defining a table (grid)	200
9.3.2	Defining columns.....	201
9.3.3	Focus control in the table (cell)	203
9.4	Custom widgets	203
9.4.1	Defining custom widgets.....	203
9.4.2	Structure of the custom widget library.....	204
9.4.3	Structure of the custom widget interface.....	205
9.4.4	Interaction between custom widget and dialog box - Automatic data exchange	206
9.4.5	Interaction between custom widget and dialog box - Manual data exchange.....	207
9.4.5.1	Reading and writing properties	208
9.4.5.2	Executing a method of the custom widget.....	209
9.4.5.3	Response to a custom widget signal	212

9.5	SIEsGraphCustomWidget.....	214
9.5.1	SIEsGraphCustomWidget.....	214
9.5.2	Notes regarding performance.....	216
9.5.3	Reading and writing properties	216
9.5.4	Properties	217
9.5.5	Functions.....	228
9.5.6	Signals.....	242
9.6	SIEsTouchButton	243
9.6.1	SIEsTouchButton	243
9.6.2	Reading and writing properties	245
9.6.3	Properties	245
9.6.4	Functions.....	262
9.6.5	Signals.....	263
9.6.6	Positioning and aligning picture and text.....	266
9.6.7	Language-dependent texts.....	268
10	"Custom" operating area	271
10.1	How to activate the "Custom" operating area	271
10.2	How to configure the "Custom" softkey.....	271
10.3	How to configure the "Custom" operating area.....	272
10.4	Programming example for the "Custom" area.....	274
11	Dialog selection	279
11.1	Dialog selection using PLC softkeys	279
11.1.1	Calling Run MyScreens-cycle screens in the program editor.....	280
11.2	Dialog selection using PLC hard keys.....	282
11.3	Dialog selection via NC.....	284
12	Examples for cycle masks	285
12.1	Examples for cycle masks	285
13	Configuration in the side screen	287
13.1	Display of a Run MyScreens configuration in a side screen page	288
13.2	Display of several Run MyScreens configurations in a side screen page.....	290
13.3	Adding Run MyScreens configurations to a side screen page	292
13.4	Adding Run MyScreens configurations to a side screen element	293
13.5	Notes on carrying out Run MyScreens configurations in the side screen	295
14	Configuration in the Display Manager.....	297
14.1	Displaying Run MyScreens configurations in the Display Manager	297
14.2	Integration in SISideScreenDialog.....	297
14.3	Integration into SIWidgetsApp.....	298
14.4	Notes on carrying out Run MyScreens configurations in the Display Manager	299

A	Reference lists	301
A.1	Lists of start softkeys.....	301
A.1.1	List of start softkeys for turning.....	301
A.1.2	List of start softkeys for milling.....	302
A.2	List of predefined softkeys.....	304
A.3	List of access levels	304
A.4	List of colors	305
A.5	List of language codes used in file names	306
A.6	List of accessible system variables	306
A.7	Behavior when opening the dialog (attribute CB).....	307
B	Tips and tricks	309
B.1	General tips	309
B.2	Tips for debugging	310
B.3	Tips for the CHANGE method	310
B.4	Tips for DO LOOP loops	311
C	Animated elements	313
C.1	Introduction.....	313
C.2	Modeling	314
C.2.1	Requirements	314
C.2.2	Rules for modeling	314
C.2.3	Importing graphics (models)	317
C.2.4	Modeling templates	318
C.3	XML commands.....	319
C.3.1	Overview	319
C.3.2	Structure of the scene description file	320
C.3.3	Mirroring and rotations	323
C.3.4	View type	323
C.4	Conversion to hmi file	324
C.5	Display in Create MyHMI /3GL.....	324
C.5.1	X3D Viewer.....	324
C.5.2	Class SIX3dViewerWidget	324
C.5.3	Public methods	325
C.5.4	Public slots.....	325
C.5.5	Libraries	326
C.5.6	Implementation example	326
C.5.7	Machine data.....	326
C.5.8	Notes about use.....	327
C.6	Display in Run MyScreens.....	327
	Index	329

Introduction

1.1 About SINUMERIK

From simple, standardized CNC machines to premium modular machine designs – the SINUMERIK CNCs offer the right solution for all machine concepts. Whether for individual parts or mass production, simple or complex workpieces – SINUMERIK is the highly dynamic automation solution, integrated for all areas of production. From prototype construction and tool design to mold making, all the way to large-scale series production.

Visit our website for more information SINUMERIK (<https://www.siemens.com/sinumerik>).

1.2 About this documentation

Target group

This document addresses programmers and configuring engineers.

Benefits

Using the Programming Manual, the target group can develop, write, test, and debug programs and software user interfaces.

Standard scope

This documentation only describes the functionality of the standard version. This may differ from the scope of the functionality of the system that is actually supplied. Please refer to the ordering documentation only for the functionality of the supplied drive system.

It may be possible to execute other functions in the system which are not described in this documentation. This does not, however, represent an obligation to supply such functions with a new control or when servicing.

For reasons of clarity, this documentation cannot include all of the detailed information on all product types. Further, this documentation cannot take into consideration every conceivable type of installation, operation and service/maintenance.

The machine manufacturer must document any additions or modifications they make to the product themselves.

Websites of third-party companies

This document may contain hyperlinks to third-party websites. Siemens is not responsible for and shall not be liable for these websites and their content. Siemens has no control over the information which appears on these websites and is not responsible for the content and information provided there. The user bears the risk for their use.

1.3 Documentation on the internet

1.3.1 Documentation overview SINUMERIK 828D

Comprehensive documentation about the functions provided in SINUMERIK 828D Version 4.8 SP4 and higher is provided in the 828D documentation overview (<https://support.industry.siemens.com/cs/ww/en/view/109766724>).



You can display documents or download them in PDF and HTML5 format.

The documentation is divided into the following categories:

- User: Operating
- User: Programming
- Manufacturer/Service: Configuring
- Manufacturer/Service: Commissioning
- Manufacturer/Service: Functions
- Manufacturer/Service: Safety Integrated
- SINUMERIK Integrate/MindApp
- Info & Training

1.3.2 Documentation overview SINUMERIK operator components

Comprehensive documentation about the SINUMERIK operator components is provided in the Documentation overview SINUMERIK operator components (<https://support.industry.siemens.com/cs/document/109783841/technische-dokumentation-zu-sinumerik-bedienkomponenten?dti=0&lc=en-WW>).

You can display documents or download them in PDF and HTML5 format.

The documentation is divided into the following categories:

- Operator Panels
- Machine control panels

- Machine Pushbutton Panel
- Handheld Unit/Mini handheld devices
- Further operator components

An overview of the most important documents, entries and links to SINUMERIK is provided at SINUMERIK Overview - Topic Page (<https://support.industry.siemens.com/cs/document/109766201/sinumerik-an-overview-of-the-most-important-documents-and-links?dti=0&lc=en-WW>).


1.4 Feedback on the technical documentation

If you have any questions, suggestions or corrections regarding the technical documentation which is published in the Siemens Industry Online Support, use the link "Send feedback" link which appears at the end of the entry.

1.5 mySupport documentation

With the "mySupport documentation" web-based system you can compile your own individual documentation based on Siemens content, and adapt it for your own machine documentation.

To start the application, click on the "My Documentation" tile on the mySupport homepage (<https://support.industry.siemens.com/cs/ww/en/my>):



The configured manual can be exported in RTF, PDF or XML format.

Note

Siemens content that supports the mySupport documentation application can be identified by the presence of the "Configure" link.

1.6 Service and Support

Product support

You can find more information about products on the internet:

Product support (<https://support.industry.siemens.com/cs/ww/en/>)

The following is provided at this address:

- Up-to-date product information (product announcements)
- FAQs (frequently asked questions)
- Manuals
- Downloads
- Newsletters with the latest information about your products
- Global forum for information and best practice sharing between users and specialists
- Local contact persons via our Contacts at Siemens database (→ "Contact")
- Information about field services, repairs, spare parts, and much more (→ "Field Service")

Technical support

Country-specific telephone numbers for technical support are provided on the internet at address (<https://support.industry.siemens.com/cs/ww/en/sc/4868>) in the "Contact" area.


If you have any technical questions, please use the online form in the "Support Request" area.

Training

You can find information on SITRAIN at the following address (<https://www.siemens.com/sitrain>).

SITRAIN offers training courses for automation and drives products, systems and solutions from Siemens.

Siemens support on the go



With the award-winning "Siemens Industry Online Support" app, you can access more than 300,000 documents for Siemens Industry products – any time and from anywhere. The app can support you in areas including:

- Resolving problems when implementing a project
- Troubleshooting when faults develop
- Expanding a system or planning a new system

Furthermore, you have access to the Technical Forum and other articles from our experts:

- FAQs
- Application examples
- Manuals
- Certificates
- Product announcements and much more

The "Siemens Industry Online Support" app is available for Apple iOS and Android.

Data matrix code on the nameplate

The data matrix code on the nameplate contains the specific device data. This code can be read with a smartphone and technical information about the device displayed via the "Industry Online Support" mobile app.

1.7 Important product information

Using OpenSSL

This product can contain the following software:

- Software developed by the OpenSSL project for use in the OpenSSL toolkit
- Cryptographic software created by Eric Young.
- Software developed by Eric Young

You can find more information on the internet:

- OpenSSL (<https://www.openssl.org>)
- Cryptsoft (<https://www.cryptsoft.com>)

Compliance with the General Data Protection Regulation

Siemens observes standard data protection principles, in particular the data minimization rules (privacy by design).

For this product, this means:

The product does not process or store any personal data, only technical function data (e.g. time stamps). If the user links this data with other data (e.g. shift plans) or if he/she stores person-related data on the same data medium (e.g. hard disk), thus personalizing this data, he/she must ensure compliance with the applicable data protection stipulations.

Fundamental safety instructions

2.1 General safety instructions

 WARNING
Danger to life if the safety instructions and residual risks are not observed If the safety instructions and residual risks in the associated hardware documentation are not observed, accidents involving severe injuries or death can occur. • Observe the safety instructions given in the hardware documentation. • Consider the residual risks for the risk evaluation.

 WARNING
Malfunctions of the machine as a result of incorrect or changed parameter settings As a result of incorrect or changed parameterization, machines can malfunction, which in turn can lead to injuries or death. • Protect the parameterization against unauthorized access. • Handle possible malfunctions by taking suitable measures, e.g. emergency stop or emergency off.

2.2 Warranty and liability for application examples

Application examples are not binding and do not claim to be complete regarding configuration, equipment or any eventuality which may arise. Application examples do not represent specific customer solutions, but are only intended to provide support for typical tasks.

As the user you yourself are responsible for ensuring that the products described are operated correctly. Application examples do not relieve you of your responsibility for safe handling when using, installing, operating and maintaining the equipment.

2.3 Security information

Siemens provides products and solutions with industrial security functions that support the secure operation of plants, systems, machines and networks.

In order to protect plants, systems, machines and networks against cyber threats, it is necessary to implement – and continuously maintain – a holistic, state-of-the-art industrial security concept. Siemens' products and solutions constitute one element of such a concept.

Customers are responsible for preventing unauthorized access to their plants, systems, machines and networks. Such systems, machines and components should only be connected to

2.3 Security information

an enterprise network or the internet if and to the extent such a connection is necessary and only when appropriate security measures (e.g. firewalls and/or network segmentation) are in place.

For additional information on industrial security measures that may be implemented, please visit

<https://www.siemens.com/industrialsecurity> (<https://www.siemens.com/industrialsecurity>).

Siemens' products and solutions undergo continuous development to make them more secure. Siemens strongly recommends that product updates are applied as soon as they are available and that the latest product versions are used. Use of product versions that are no longer supported, and failure to apply the latest updates may increase customer's exposure to cyber threats.

To stay informed about product updates, subscribe to the Siemens Industrial Security RSS Feed under

<https://www.siemens.com/industrialsecurity> (<https://new.siemens.com/global/en/products/services/cert.html#Subscriptions>).

Further information is provided on the Internet:

Industrial Security Configuration Manual (<https://support.industry.siemens.com/cs/ww/en/view/108862708>)



WARNING

Unsafe operating states resulting from software manipulation

Software manipulations, e.g. viruses, Trojans, or worms, can cause unsafe operating states in your system that may lead to death, serious injury, and property damage.

- Keep the software up to date.
- Incorporate the automation and drive components into a holistic, state-of-the-art industrial security concept for the installation or machine.
- Make sure that you include all installed products into the holistic industrial security concept.
- Protect files stored on exchangeable storage media from malicious software by with suitable protection measures, e.g. virus scanners.
- On completion of commissioning, check all security-related settings.

Functional scope

3.1 Range of functions of "Run MyScreens"

Overview

"Run MyScreens" can be used to create user interfaces that display functional expansions designed by the machine manufacturer or user, or to implement your own layout.

Cycle calls can also be generated with user interfaces that you have created. Dialogs can be created directly on the control system.

"Run MyScreens" is implemented with an Interpreter and configuration files that describe the user interfaces.

"Run MyScreens" is configured using ASCII files: These configuration files contain the description of the user interface. The syntax that must be applied in creating these files is described in the following chapters.

Basic configuration

The "Run MyScreens" function enables machine manufacturers to configure their own dialogs. Even with the basic configuration, it is possible to configure five dialogs in the operator menu tree or for customer-specific cycle dialogs.



Software option

To expand the number of dialogs, you require one of the following software options:

- SINUMERIK 828D/840D sl, SINUMERIK Integrate Run MyScreens (6FC5800-0AP64-0YB0)
- SINUMERIK 840D sl, SINUMERIK Integrate Run MyHMI / 3GL (6FC5800-0AP60-0YB0)
- SINUMERIK 840D sl, SINUMERIK Integrate Run MyHMI / WinCC (6FC5800-0AP61-0YB0)

Supplementary conditions

The following conditions must be met:

- It is only possible to switch between dialogs within a single operating area.
- User variables may not have the same names as system or PLC variables (also see List Manual System Variables /PGAsI/).
- The dialogs activated by the PLC form a separate operating area (similar to measuring cycle screens).

Tools

- UTF8-capable editor (e.g. the integrated editor of the user interface or Notepad)
- A graphics program is needed to create graphics/display images.

File names and coding

Note

When using HMI Operate in the NCU, note that all file names are written in lower case letters (com, png, txt) on the CF card. This is required because of Linux.

File names are not case-sensitive on the PCU. However, it is recommended that you also use lower case letters here, in case of a possible subsequent transfer to Linux.

Note

When saving configuration and language files, ensure that the coding is set to UTF-8 for the editor you are using.

Storage paths

Note the following convention when storing the configuration files, help files, etc.

[System siemens-directory]		
	Linux:	/card/siemens/sinumerik/hmi
	Windows 7:	C:\ProgramData\Siemens\MotionControl\siemens
[System oem-directory]		
	Linux:	/card/oem/sinumerik/hmi
	Windows 7:	C:\ProgramData\Siemens\MotionControl\oem
[System user-directory]		
	Linux:	/card/user/sinumerik/hmi
	Windows 7:	C:\ProgramData\Siemens\MotionControl\user
[System addon-directory]		
	Linux:	/card/addon/sinumerik/hmi
	Windows 7:	C:\ProgramData\Siemens\MotionControl\addon
Storage locations		
	"Run MyScreens" configuration:	[System oem-directory]/proj
	Configuration file:	[System oem-directory]/cfg
	Language files:	[System oem-directory]/lng

	Image files:	[System oem-directory]\\lco\\ico[resolution] Example: [System oem-directory]\\lco\\ico640
	Online help:	[System oem-directory]\\hlp/[language] Example: [System oem-directory]\\hlp/eng

Use

You can implement the following functions:

- Display dialogs containing the following elements:
 - Softkeys
 - Variables
 - Texts and Help texts
 - Graphics and Help displays
- Call dialogs by:
 - Pressing the (start) softkeys
 - Selection from the PLC/NC
- Restructure dialogs dynamically:
 - Edit and delete softkeys
 - Define and design variable fields
 - Insert, exchange, and delete display texts (language-dependent or language-neutral)
 - Insert, exchange, and delete graphics
- Initiate operations in response to the following actions:
 - Displaying dialogs
 - Inputting values (variables)
 - Selecting a softkey
 - Exiting dialogs
 - Value change of a system or user variable
- Data exchange between dialogs
- Variables:
 - Read (NC, PLC and user variables)
 - Write (NC, PLC and user variables)
 - Combine with mathematical, comparison or logic operators

3.1 Range of functions of "Run MyScreens"

- Execute functions:
 - Subprograms
 - File functions
 - PI services
- Apply protection levels according to user groups

Getting Started

4.1 Introduction

Using the following example, you get to know the steps necessary to insert your own dialogs into the SINUMERIK Operate user interface using Run MyScreens. You also learn how to create your own dialogs, insert context-sensitive help screens and help calls, define softkeys and how you can navigate between the dialogs.

4.2 Project example

4.2.1 Task description

In the project example you create the dialogs described in the following, including a context-sensitive help.

Dialog 1

R parameters that can be written to (0 and 1) and geometry axis names are displayed in the first dialog (input fields). The corresponding help screens are linked in for the two R parameters. A context-sensitive help is linked in for the geometry axes. Further, the dialog includes examples for separating lines (horizontal and vertical), toggle fields, input/output fields with integrated unit selection and progress bars (with and without color change).




Figure 4-1 R parameters with help displays




Figure 4-2 Geometry axes with context sensitive help




Figure 4-3 Toggle fields: List and box




Figure 4-4 I/O field with integrated unit selection

Dialog 2

MCS and WCS values are displayed in the second dialog. The dialog also contains examples of progress bars with and without color change.




Figure 4-5 Progress bars with (right) and without (left) color change

Navigation

The first dialog is called using the "START" softkey in the diagnostics operating area. The horizontal SK7 softkey is used.




Figure 4-6 Start softkey „START“ in the machine operating area, AUTO mode

You can call the second dialog from the first dialog with the "Next Mask" softkey. You can return to the root screen of the operating area by pressing the "EXIT" softkey (see the screen above).

Using the "EXIT" softkey, you can also return to the root screen of the operating area from the second dialog (see the screen above). You can return to the first dialog via the "Back to Mask" softkey.

Procedure

The necessary steps are described in the following chapters:

1. Creating the configuration file (COM file) (Page 25)
2. Saving the configuration file in the OEM directory (Page 28)
3. Creating the online help (Page 29)
4. Integrating the online help and saving the files to the OEM directory (Page 32)
5. Copying "easyscreen.ini" into the OEM directory (Page 33)
6. Registering the COM file in "easyscreen.ini" (Page 33)
7. Testing the project (Page 33)

4.2.2 Creating the configuration file (example)

Content of the configuration file

Using a UTF8-capable editor, create the configuration file "diag.com" for the two dialogs.

```
; Start identifier of start softkey
//S(START)
; Start softkey only text
HS7=("START")
; Start softkey with language-dependent text and png
;HS7=([$80792,"\\sk_ok.png"])

; Press method
PRESS(HS7)
; LM or LS function
LM("MASK1")
; LM, specifying a com file
LM("MASK1","TEST.COM")
END_PRESS
; End identifier of start softkey
//END

; Definition of dialog 1 with header and screen
//M(MASK1/"Display R parameter and Channel MD"/"mz961_01.png")
; Definition of the variables
DEF VAR1 = (R2///,"R parameter 0"///"$R[0]"/200,50,150/400,50,100,)
; With help screen
DEF VAR2 = (R2///,"R parameter 1"///"mz961_02.png"/"$R[1]"/200,70,150/400,70,100)
; With online help
DEF ACHS_NAM1 = (S///"Press i for Help","Geometry axis[0]"/200,100,150/400,100,100//sinumer-
ik_md_1.html","20060[0]")
; With online help
DEF ACHS_NAM2 = (S///"Press i for Help","Geometry axis[1]"/200,120,150/400,120,100//sinumer-
ik_md_1.html","20060[1]")
DEF ACHS_NAM3 = (S///,"Geometry axis[2]"/200,140,150/400,140,100)
; Definition of toggle fields and unit toggle
DEF VAR_TGL = (S/* "Hello", "Run", "MyScreens"/"Run"/,"Toggle box"/10,230,100/120,230,100/, ,6)

DEF VAR_TGB = (S/* "Hello", "Run", "MyScreens"/"Run"/,"List box"/
dt4///250,230,100/370,230,100,60/, ,"#0602ee")
; BC, FC, BC_ST, FC_ST, BC_GT, FC_GT, BC_UT, FC_UT, SC1, SC2
DEF VarEdit = (R///,"Unit Toggle",,,"Feedrate"///"$R[11]"/5,300,100/120,300,100//VarTgl"),
VarTgl = (S/*0="mm",1="inch"/0//WR2///220,300,40)
```

```
; Softkey definition in the dialog
HS1=("")
HS2=("")
HS3=("")
HS4=("")
HS5=("")
HS6=("")
HS7=("")
HS8=("")
VS1=("")
VS2=("")
VS3=("")
VS4=("")
VS5=("")
VS6=("")
VS7=("Next Mask")
VS8=("EXIT")

; Definition LOAD block
LOAD
    ; Read value with RNP
    ACHS_NAM1 = RNP("$MC_AXCONF_GEOAX_NAME_TAB[0]")
    ACHS_NAM2 = RNP("$MC_AXCONF_GEOAX_NAME_TAB[1]")
    ACHS_NAM3 = RNP("$MC_AXCONF_GEOAX_NAME_TAB[2]")
    ; Output of a dialog line
    DLGL("Value R2: = " << RNP("$R[2]"))
    ; Write WNP to a value
    WNP("$R[3]",VAR0)

    ; Vertical dividing line
    V_SEPARATOR(360,1,6,1)
    ; Horizontal dividing line
    H_SEPARATOR(220,1,7,1)
END_LOAD

; Press method
PRESS(VS7)
    ; Load an additional dialog
    LM("MASK2")
; End identifier press method
END_PRESS

; Press method
PRESS(VS8)
```

```

; Exit the dialog
EXIT
; End identifier press method
END_PRESS
; End identifier dialog 1
//END

; Definition of dialog 2 with header and screen
//M(MASK2/"Position WCS MCS"/"mz961_01.png")

; Definition of the variables
DEF TEXT1 = (I///,"WCS"/WR0,fs2///230,30,120/, ,1)
DEF VAR1 = (R3///,"1. Axis $AA_IW[AX1]"/WR1/"$AA_IW[AX1]"/230,70,150/400,70,100)
DEF VAR2 = (R3///,"2. Axis $AA_IW[AX2]"/WR1/"$AA_IW[AX2]"/230,90,150/400,90,100)

DEF TEXT2 = (I///,"MCS"/WR0,fs2///230,120,120/, ,1)
DEF VAR3 = (R2///,"1. Axis $AA_IM[AX1]"/WR1/"$AA_IM[AX1]"/230,160,150/400,160,100)
DEF VAR4 = (R2///,"2. Axis $AA_IM[AX2]"/WR1/"$AA_IM[AX2]"/230,180,150/400,180,100)
DEF VAR5 = (R3///,"$P_UIFR G54 AX1"///"$P_UIFR[1,AX1,TR]"/230,200,150/400,200,100)

; Definition of the progress bar
DEF PROGGY0 = (R/0,150//,"Progress bar Operate style"/DT2,DO0/"$R[10]"/5,240,190/5,260,150/6,10)
DEF PROGGY4 = (R/0,150,50,100/120//,"Progress bar with color change"/DT1,DO0/"$R[10]"/
260,240,190/260,260,150/3,4,, ,9,7)

; Definition of the variables
DEF PROGVAL = (R/0,150//,"Value to change Progress bar 0 - 150"///"$R[10]"/5,300,230/260,300,100)

; Softkey definition in the dialog
HS1=("")
HS2=("")
HS3=("")
HS4=("")
HS5=("")
HS6=("")
HS7=("")
HS8=("")
VS1=("")
VS2=("")
VS3=("")
VS4=("")
VS5=("")
VS6=("")
VS7=("Back to Mask")
VS8=("EXIT")

```

```
; Load method
LOAD
    H_SEPARATOR(230,1,7,1)
END_LOAD

; Change method
CHANGE(VAR5)
    ; Function PI_START
    PI_START("/NC,201,_N_SETUFR")
; End identifier change method
END_CHANGE

; Press method
PRESS(RECALL)
    ; Return to the calling mask
    LM("MASK1")
; End identifier press method
END_PRESS

; Press method
PRESS(VS7)
    ; Return to the calling mask
    LM("MASK1")
; End identifier press method
END_PRESS

; Press method
PRESS(VS8)
    ; Exit the dialog to the standard application
    EXIT
; End identifier press method
END_PRESS
; Dialog end identifier
//END
```

4.2.3 Saving the configuration file in the OEM directory (example)

Storage path

Save the configuration file "diag.com" under the following path:

[System oem-directory]/proj

4.2.4 Creating the online help (example)

Create the HTML file "sinumerik_md_1.html". The example under "Content of the online help" shows the context-sensitive help call via **name="20060[0]"** and **name="20060[1]"**.

Notes

You can find notes on creating HTML files in Chapter Generating HTML files (Page 73).

Notes regarding the integration of online help are provided in Section Integrating the online help and saving the files to the OEM directory (example) (Page 32).

Content of the online help

The example has no comments.

```
<html><head><meta http-equiv="Content-Type" content="text/html; charset="UTF-8"/><title></
title></head>
<body>
  <table border="1" cellspacing="0" cellpadding="2" width="100%">
    <tr>
      <td><a name="20060[0]"><b>20060[0]</b></a></td>
      <td colspan="3">AXCONF_GEOAX_NAME_TAB</td>
      <center>
        
      </center>
      <td>-</td>
      <td>-</td>
    </tr>
    <tr>
      <td>-</td>
      <td colspan="3">Geometry axis name in channel</td>
      <td>DWORD</td>
      <td>POWER ON</td>
    </tr>
    <tr>
      <td colspan="6">This MD is used to enter the names of the geometry axes
separately for each channel.<br />
    <tr>
      <td>-</td>
      <td colspan="5">&nbsp;</td>
    </tr>
    <tr>
      <td width="16*">System</td><td width="16*">Dimension</td><td width="16*">Default
value</td>
      <td width="16*">Minimum value</td><td width="16*">Maximum value</td>
      <td width="16*">Protection</td>
    </tr>
    <tr>
      <td>-</td>
      <td>-</td>
      <td>60</td>
      <td>0</td>
      <td>180</td>
      <td>7/3</td>
    </tr>
  </table>
<p></p>
  <table border="1" cellspacing="0" cellpadding="2" width="100%">
    <tr>
      <td><a name="20060[1]"><b>20060[1]</b></a></td>
      <td colspan="3">AXCONF_GEOAX_NAME_TAB</td>
      <td>-</td>
      <td>-</td>
    </tr>
    <tr>
      <td>-</td>
      <td colspan="3">Geometry axis name in channel</td><td>BYTE</td>
      <td>POWER ON</td>
    </tr>
    <tr>
```

```

        <td colspan="6">This MD is used to enter the names of the geometry axes
separately for each channel.<br />
        <tr>
            <td>--</td>
            <td colspan="5">&nbsp;</td>
        </tr>
        <tr>
            <td width="16*">System</td>
            <td width="16*">Dimension</td>
            <td width="16*">Default value</td>
            <td width="16*">Minimum value</td>
            <td width="16*">Maximum value</td>
            <td width="16*">Protection</td>
        </tr>
        <tr>
            <td>--</td>
            <td>--</td>
            <td>0</td>
            <td>0</td>
            <td>2</td>
            <td>7/3</td>
        </tr>
    </table>
    <p></p>
</body>
</html>

```

4.2.5 Integrating the online help and saving the files to the OEM directory (example)

Integrating the online help

The syntax to integrate the online help is analogous to SINUMERIK Operate.

```
DEF RFP=(R//1,"RFP","RFP////////sinumerik_md_1.html","9006")
```

Note

As a result of LINUX, the HTML file must be written in lower case letters!

Storage path

Save the HTML file "sinumerik_md_1.html" for the English help under the following path:

[System oem-directory]/hlp/eng

You must create a folder for additional languages as required (e.g. chs, deu, esp, fra, ita, etc.).

A list of language codes is provided in the Appendix "Reference lists".

Further information

Detailed information about creating OEM-specific online help files is provided in Chapter Configuring the online help (Page 72).

4.2.6 Copying "easyscreen.ini" into the OEM directory (example)

Storage path

Copy the file "easyscreen.ini" from the directory
[System siemens-directory]/cfg
to the directory
[System oem-directory]/cfg.

4.2.7 Registering the COM file in "easyscreen.ini" (example)

Adaptation of the "easyscreen.ini"

Make the following change in the "easyscreen.ini" in the OEM directory. You have thus registered the "diag.com" configuration file.

```
;#####  
;# AREA Diagnosis      #  
;#####  
;<=====>  
;< OEM Softkey on first horizontal Main Menu      >  
;< SOFTKEY position="7"      >  
;<=====>  
StartFile28 = area := AreaDiagnosis, dialog:= SldgDialog, menu := DgGlobalHu, startfile := diag.com
```

4.2.8 Testing the project (example)

Testing the dialog call

Switch to the diagnostics operating area. Click the "START" horizontal softkey.

If "Run MyScreens" detects errors when interpreting the configuration files, these errors will be written to the "easyscreen_log.txt" text file. Further information can be found in Chapter Troubleshooting (log book) (Page 41).

Testing context sensitive help screens and online help

Test the context sensitive help screens and the online help. If errors occur, then check the paths where files have been saved.

Fundamentals

5.1 Structure of configuration file

Introduction

The description of new user interfaces is stored in configuration files. These files are automatically interpreted and the result displayed on the screen. Configuration files are not stored in the software supplied and must be set up by the user.

A UTF-8-capable editor (e.g. the integrated editor of the user interface or Notepad) is used to create the configuration files and language files. The description can also be explained using comments. A ";" is inserted as comment character before every explanation.

Note

When saving configuration and language files, ensure that the coding is set to UTF-8 for the editor you are using.

However, keywords - also in an UTF-8-coded COM file - may only comprise characters that are contained in the ASCII character set. Otherwise the interpretation and therefore the display of the screens/dialogs cannot be guaranteed.

Configuration

Each HMI operating area has permanent start softkeys which can be used to access newly generated dialogs.

In the event of a "Load a screen" (LM) or a "Load softkey menu" (LS) call in a configuration file, a new file name containing the object called can be specified. This makes it possible to structure the configuration, e.g. all functions in one operating level in a separate configuration file.

Structure of the configuration file

A configuration file consists of the following elements:

1. Description of the start softkeys
2. Definition of the dialogs
3. Definition of the variables
4. Description of the methods
5. Definition of the softkey menus

Note**Sequence**

The specified sequence in the configuration file must be maintained.

Example:

```
//S (START)                ; Definition of the start softkey (optional)
....
//END
//M (.....)              ; Definition of the dialog
DEF .....                  ; Definition of the variables
LOAD                       ; Description of the blocks
...
END_LOAD
UNLOAD
...
END_UNLOAD
...
//END
//S (...)                  ; Definition of a softkey menu
//END
```

Storing the configuration files

The configuration files are stored in the directory [System user-directory]/proj and accordingly also in the directories [System addon-directory] and [System oem-directory].

Converting texts from other HMI applications

Procedure to convert a text file with code page coding to text-coding UTF-8:

1. Open the text file on a PG/PC in a text editor.
2. When saving, set the UTF-8 coding.

The read-in mechanism via code page code is still supported.

5.2 Structure of the menu tree

Menu tree principle

Several interlinked dialogs create a menu tree. A link exists if you can switch from one dialog to another. You can use the newly defined horizontal/vertical softkeys in this dialog to call the preceding or any other dialog.

A menu tree can be created behind each start softkey:




Figure 5-1 Menu tree

Start softkeys

One or more softkeys (start softkeys), which are used to initiate your own operating sequences, are defined in the configuration files specified in "easyscreen.ini".

The loading of a dedicated dialog is associated with a softkey definition or another softkey menu. These are then used to perform the subsequent actions.

Pressing the start softkey loads the assigned dialog. This will also activate the softkeys associated with the dialog. Variables will be output to the standard positions unless specific positions have been configured.

Reverting to the standard application

You can exit the newly created dialog and return to the standard operating area.

You can use the <RECALL> key to close new user interfaces if you have not configured this key for any other task.

Note

Calling dialogs in the PLC user program

Dialogs can be selected from the PLC as well as via softkeys: An interface signal is available in DB19.DBB10 for signal exchange between the PLC → HMI.

5.3 Definition and functions for start softkeys

5.3.1 Defining the start softkey

Dialog-independent softkey

Start softkeys are dialog-independent softkeys which are not called from a dialog, but which have been configured **before** the first new dialog. In order to access the start dialog or a start softkey menu, the start softkey must be defined.

Programming

The definition block for a start softkey is structured as follows:

```
//S(Start)           ; Start identifier of start softkey
HS1=(...)            ; Define the start softkey: horizontal SK 1
PRESS(HS1)           ; Method
    LM...            ; LM or LS function
END_PRESS            ; End of method
//END                ; End identifier of start softkey
```

Permissible positions for start softkeys

The following positions for "Run MyScreens" start softkeys are permissible in the operating areas:

Operating area	Position
Machine	HSK6
Parameter	HSK7
Program	HSK6 and HSK15 Measuring cycles: HSK13 and HSK14
Program Manager	HSK2-8 and HSK12-16, if not assigned to drives.
Diagnostics	HSK7
Commission	HSK7

Start softkeys are configured in special files. The names of these files are stated in the "easyscreen.ini" file. They usually have a name which is specific to an operating area (e.g. "startup.com" operating area for the startup area). The machine operating area represents an exception. There are several mode-specific files in the machine operating area ("ma_jog.com", "ma_auto.com").

The softkey menu with the start softkeys is called "Start". Existing configurations for start softkeys can still be used. The function where start softkeys are merged with the softkeys for the respective HMI application (operating area) in the start softkey menu is not supported.

This means that until the first dialog call is made - in other words, the time at which full functionality becomes available (e.g. execution of PRESS blocks) - menus or softkey menus can only be replaced by others in their entirety.

Template for configuration of the start softkey

A detailed description of all permissible positions for start softkeys and their configuration is located in the "easyscreen.ini" file in the following directory:

[System siemens-directory]/cfg

This file is used as a template for your own configuration of the start softkey.

See also

Lists of the start softkeys

5.3.2 Functions for start softkeys

Functions for dialog-independent softkeys

Only certain functions can be initiated with start softkeys.

The following functions are permitted:

- The **LM function** can be used to load another dialog: **LM**("Identifier","File")
- The **LS function** can be used to display another softkey menu: **LS**("Identifier"[, "File"][, Merge])
- You can use the **"EXIT" function** to exit newly configured user interfaces and return to the standard application.
- You can use the **"EXITLS" function** to exit the current user interface and load a defined softkey menu.

PRESS method

The softkey is defined within the definition block and the "LM" or "LS" function is assigned in the PRESS method.

If the start softkey definition is designated as a comment (semicolon (;) at beginning of line) or the configuration file removed, the start softkey will not function.

```
//S(Start)                ; Start identifier
HS6=("1st screen")         ; Label horizontal SK 6 with "1st screen"
PRESS(HS6)                 ; PRESS method for horizontal SK 6
    LM("Screen1")          ; Load screen1 function, where Screen 1 must be
                           ; defined within the same file.
```

5.3 Definition and functions for start softkeys

```

END_PRESS                ; End of PRESS method
HS7= ("2nd screen")      ; Label horizontal SK 7 with "2nd screen"
PRESS (HS7)              ; PRESS method for horizontal SK 7
    LM("Screen2")        ; Load Screen2 function, where Screen2 must be de-
                        ; fined within the same file.
END_PRESS                ; End of PRESS method
//END                    ; End identifier of entry block

```

Example

```

HS1 = ("new softkey menu")
HS2 = ("no function")
PRESS (HS1)
    LS("Menu1")          ; Load new softkey menu
END_PRESS
PRESS (HS2)              ; Empty PRESS method
END_PRESS

```

Various configurations of the start softkeys

Various configurations of the start softkeys are merged. In this case, initially the name of the file to be interpreted is read-out of "easyscreen.ini". A search is made for *.com files in the following directories:

- [System user-directory]/proj
- [System oem-directory]/proj
- [System addon-directory]/proj
- [System siemens-directory]/proj

The configurations included for the start softkeys are now merged to form a configuration, i.e. the individual softkeys are compared. If there are two or more configurations for a softkey, the higher order configuration is always used in the merge version.

Softkey menus or dialogs that are possibly included are ignored. If a softkey has a command without file information, e.g. LM ("test"), as the required softkey menu or dialog is contained in the same file, then the corresponding file name is supplemented in the internal merge version so that in this case, no changes are required. The merge configuration obtained is then subsequently displayed.

5.4 Troubleshooting (log book)

Overview

If "Run MyScreens" detects errors when interpreting the configuration files, these errors will be written to the "easyscreen_log.txt" text file. Only errors of the currently selected dialog are entered. Error entries from previously selected dialogs are deleted.

The file contains the following information:

- The action during which an error occurred.
- The line and column number of the first faulty character.
- The entire faulty line of the configuration file.
- The entries made by the DEBUG function.

Note

Each entry has a prefix with the current time stamp in square brackets. This can be helpful, for example, when analyzing time-critical configurations.

Saving "easyscreen-log.txt"

The "easyscreen_log.txt" file is saved in the following directory:

[System user-directory]/log

Syntax

The system does not start to interpret the syntax until the start softkey has been defined and a dialog with start and end identifiers as well as a definition line has been configured.

```
//S(Start)
HS6= ("1st screen")
PRESS(HS6)
    LM("Maskel")
END_PRESS
//END

//M(Maskel)
DEF Var1=(R)
DEF VAR2 = (R)
LOAD
VAR1 = VAR2 + 1           ; Error message in logbook, as VAR2 has no value
...
//END
```

```
; correct way would be, for
example:
//M(Maske1)
  DEF Var1=(R)
  DEF VAR2 = (R)

  LOAD
    VAR2 = 7
    VAR1 = VAR2 + 1 ;
  ...
```

5.5 Notes on "easyscreen.ini"

As of SINUMERIK Operate V4.7, "easyscreen.ini" has been extended by the entries described in this chapter. The "easyscreen.ini" can be found in the [System siemens-directory]/cfg.

Help screen start position

Entry in "easyscreen.ini":

```
[GENERAL]
HlpPicFixPos=true
```

Note:

The start position of help displays is positioned at the configured pixel position independent of the resolution (default=true).

Elongation behavior, default line height and line spacing

Entry in easyscreen.ini:

```
[GENERAL]
SymmetricalAspectRatio=false
DefaultLineHeight=18
DefaultLineSpacing=3
```

Notes:

- The "SymmetricalAspectRatio" entry determines whether the same aspect ratio is used in the X and Y direction when adapting a configuration to a specific screen resolution.
 - "false" (default): Fields and graphics are shortened in widescreen resolution in the Y direction (asymmetrical elongation in relation to 640x480). For example, a square configured in 640x480 is shortened vertically for a widescreen panel and becomes a rectangle.
 - "true": The same aspect ratio is used in the X and Y direction and fields and graphics retain their originally configured proportions in relation to 640x480. For example, a square configured in 640x480 remains a square in a widescreen panel.
- The entries "DefaultLineHeight" and "DefaultLineSpacing" can be used to specify the default line height (default: 18 pixels) and the default line spacing (default: 3 pixels) in relation to 640x480. They only take effect when no Y position or height is specified in the configuration for the position of the short text or the input/output field.

Cycles in the basic display Machine

- Entry to machine operating mode JOG via HS6 with the possibility to generate a cycle call into the Machine main screen with section [JOBSHOPINTEGRATION]:


```
[JOBSHOPINTEGRATION]
Integration = true
or via the starting block in the configuration
LM("Screen1",,1)
PRESS(VS8)
    GC("MOVE_RIDE") ; cycle call is being generated
    EXIT
END_PRESS
```
- Retention of the operate menus with section [Integration]:

If the dialog only includes vertical softkeys, the horizontal standard softkey bar incl. the start softkey is retained when the dialog is displayed. If the dialog contains horizontal and vertical softkeys, the horizontal bar from the dialog replaces the horizontal bar with the start softkey.

```
[Integration]
OperateMenusEnabled = true
```

Resolution-dependent screen position: Form panels**Entry in "easyscreen.ini":**

```
[640x480]
MyPanel = x:=0, y:=220, width:=340, height:=174
[800x480]
MyPanel = x:=0, y:=220, width:=420, height:=174
...
```

Notes:

The screen position can be defined as follows:

- The screen position can be specified in "Pixels in relation to 640x480".
Example:
`//M(MyMask/"MyCaption"/"\myhelp.png"/0,219,335,174)`
- The screen position can be coupled to the resolution-dependent position of a form panel from an Operate standard screen layout, e.g. "FormPanel4" ("auxiliary functions") from the screen layout "slmastandardscreenlayout.SIMaStandardScreenLayout" of the "Machine" area
`//M(MyMask/"MyCaption"/"\myhelp.png"/"slmastandardscreenlayout.SIMaStandardScreenLayout.FormPanel4")`

It is therefore easy to superimpose standard forms from Operate or position Easyscreen screens precisely at their position.

Example:

`//M(Mask/"Mask"/"slstandardscreenlayout.SIStandardScreenLayout.LowerForm")`
Any other screen layout can also be used.

- The screen position can be coupled to a self-defined, resolution-dependent definition of form panels in the "easyscreen.ini" file.
Example:
`//M(MyMask/"MyCaption"/"\myhelp.png"/"MyPanel")`

5.6 Notes for personnel changing over to "Run MyScreens"

Note

When using HMI Operate in the NCU, note that all file names are saved in lower case letters on the CF card (com, png, txt).

Note

Make sure that the coding is set to UTF-8 in the editor that you are using when saving the configuration and language files.

Image files

Always save image files in the PNG format "*.png".

The data must be saved, e.g. for OEM modifications, under
[System oem-directory]/ico/[resolution].

Further information can be found in Chapter Using display images/graphics (Page 63).

Adapting the configuration file

Check your configuration files regarding the following points:

- Compare the start softkeys with the currently permissible softkeys and adapt them, if required.
- Rename the integrated image files corresponding to the "Image files" point above.

The data is stored, e.g. for OEM modifications, in the following directory:

[System oem-directory]/proj

[System user-directory]/proj A

[System addon-directory]/proj

Adapting the help files

All help files must be saved in UTF-8. Check your existing files, and resave them accordingly with a suitable editor.

The HTML files are saved in the following directory, e.g. for English:

[System oem-directory]/hlp/eng

[System user-directory]/hlp/eng

[System addon-directory]/hlp/eng

You must create the directories for additional languages corresponding to the language codes.

Checking the "Run MyScreens" license

Check whether the number of dialogs that you have entered exceeds the basic scope of a maximum of five dialogs.

To expand the number of dialogs, you require one of the following software options:

- SINUMERIK 828D/840D sl, SINUMERIK Integrate Run MyScreens (6FC5800-0AP64-0YB0)
- SINUMERIK 840D sl, SINUMERIK Integrate Run MyScreens + Run MyHMI (6FC5800-0AP65-0YB0)
- SINUMERIK 840D sl, SINUMERIK Integrate Run MyHMI / 3GL (6FC5800-0AP60-0YB0)
- SINUMERIK 840D sl, SINUMERIK Integrate Run MyHMI / WinCC (6FC5800-0AP61-0YB0)

5.7 Extended configuration syntax

As of SINUMERIK Operate V4.7, a simplified syntax is available for the definition of screens, variables, softkeys and for table columns. Reading and servicing are improved with this alternative syntax. The properties and attributes can be specified in any order, empty entries are omitted. Instead of with round brackets "(" and ")" as in the previous syntax, the listing of the properties and attributes is now enclosed in curly brackets "{" and "}".

5.7 Extended configuration syntax

The properties and attributes are specified as follows:

```
{<Name> = <Value>, <Name> = <Value>, ...}
```

The previous syntax remains compatible.

Extended syntax for the definition of screens

```
//M {<Mask name> [,HD=<Title>] [,HLP=<Graphic>] [,X=<X position>] [,Y=<Y position>]
[,W=<Width>] [,H=<Height>] [,VAR=<> System or user variable] [,HLP_X=<X position help
screen>] [,HLP_Y=<Y position help screen>] [,CM=<Column alignment>] [,CB=<Response when
opening the dialog>] [,XG=<Interpret help screen as X3d graphic>] [,PANEL=<Name of the
linked FormPanel>] [,MC=<Mask background color>] [,HD_AL=<Alignment of the mask
header>] [,LANGFILELIST=<List of the mask-specific language files>]}
```

Example:

```
//M{VariantTest, HD="My Mask"}
```

Extended syntax for the definition of variables

```
DEF <Variable name> = {[TYP=<Type>] [,MIN=<Minimum value>] [,MAX=<Maximum value>]
[,TGL=<Toggle values>] [,VAL=<Preassignment>] [,LT=<Long text>] [,ST=<Short text>]
[,GT=<Graphic text>] [,UT=<Unit text>] [,TT=<ToolTip text>] [,TG=<Toggle option>]
[,WR=<Input mode>] [,AC=<Access level>] [,AL=<Text alignment>] [,FS=<Font size>]
[,LI=<Limit value handling>] [,UR=<Refresh rate>] [,CB=<Text align when opening the dialog>]
[,HLP=<Help screen>] [,VAR=<System or user variable>] >] [,TXT_X=<X position short text>]
[,TXT_Y=<Y position short text>] [,TXT_W=<Width short text>] [,TXT_H=<Height short text>]
[,X=<X position input/output field>] [,Y=<Y position input/output field>] [,W=<Width input
output field>] [,H=<Height input/output field>] [,UT_DX=<Distance between input field and
unit field>] [,UT_W=<Width unit field>] [,BC=<Background color input/output field>]
[,FC=<Foreground color input/output field>] [,BC_ST=<Background color short text>]
[,FC_ST=<Foreground color short text>] [,BC_GT=<Background color graphic text>]
[,FC_GT=<Foreground color graphic text>] [,BC_UT=<Background color unit text>]
[,FC_UT=<Foreground color unit text>] [,SC1=<Signal color 1 for progress bar>] [,SC2=<Signal
color 2 for progress bar>] [,SVAL1=<Threshold value 1 for progress bar>] [,SVAL2=<Threshold
value 2 for progress bar>] [,DT=<Display type>] [,DO=<Display alignment>] [,OHLP=<Online
help>] [,LINK_TGL=<Name of the linked toggle v>]}
```

Examples:

```
DEF MyVar5={TYP="R2", ST="MyVar5", VAL=123.4567, OHLP="myhelp.html", MIN=100.1,
MAX=200.9}
DEF MyVar2={TYP="I", TGL="*1,2,3", VAL=1}
DEF MyVar3={TYP="R2", TGL="*0=""Off"", 1=$80000", VAL=1}
DEF MyVar4={TYP="R2", TGL="*MyArray", VAL=1}
DEF MyVar1={TYP="R2", TGL="%grid99", X = 0, W=300, H=200}
DEF MyVar6={TYP="R2", TGL="+$80000", VAR="$R[10]", ST="Text offset"}
```

Extended syntax for the definition of softkeys

```
SK = {[ST=<Label>] [,AC=<Access level>] [,SE=<Status>]}
```

Examples:

```

HS1={ST=""MySk"", AC=6, SE=1}
HS3={ST="SOFTKEY_CANCEL"}
HS5={ST="[$81251, ""\sk_ok.png""]"}
HS8={ST="["Test"", ""\sk_ok.png""]"}

```

Extended syntax for the definition of table columns

```

{[TYP=<Type>] [,MIN=<Minimum value>] [,MAX=<Maximum value>] [,LT=<Long text>]
[,ST=<Short text>] [,WR=<Input mode>] [,AC=<Access level>] [,AL=<Text alignment>]
[,FS=<Font size>] [,LI=<Limit value handling>] [,UR=<Refresh rate>] [,HLP=<Help screen>]
[,VAR=<System or user variable>] >] [,W=<Column width>] [,OF1=<Offset1>]
[,OF2=<Offset2>] [,OF3=<Offset3>]}

```

Example:

```

DEF MyGridVar={TYP="R", TGL="%MyGrid1", X=10, W=550, H=100}
//G(MyGrid1/0/5)
    {TYP="I", ST="Index", WR=1, VAR="1", W=80, OF1=1}
    {TYP="S", LT="LongText2", ST="Text", WR=1, VAR="$80000", AL=2, W=330, OF1=1}
    {TYP="R3", LT="LongText1", ST="R9,R11,R13,R15", WR=2, VAR="$R[1]", W=110, OF1=2}
//END

```

5.8 SmartOperation and MultiTouch operation

You have the following setting options for specific adjustment to SmartOperation and for MultiTouch operation:

- Automatic adjustment of the field height and field width to the so-called minimum usable field size and the line spacing (mask attribute MA).
- Optimized and pixel-precise stretching of the fields for higher resolutions (mask attribute PA).
- Setting of the field height and line spacing proportional to the font (mask attribute FA).
- Allows free scrolling so that the input field is not covered by the virtual keyboard (mask attribute KM).

Further details can be found in Chapter Defining dialog properties (Page 51), Section "Programming".

Dialogs

6.1 Structure and elements of a dialog

6.1.1 Defining a dialog

Definition

A dialog is part of a user interface consisting of a display line, dialog elements and/or graphics, an output line for messages and 8 horizontal and 8 vertical softkeys.

Dialog elements are:


- Variables
 - Limits/toggle field
 - Default setting of variables
- Help display
- Texts
- Attributes
- System or user variable
- Position of short text
- Position of input/output field
- Colors

Dialog properties:

- Header
- Graphic
- Dimension
- System or user variable

6.1 Structure and elements of a dialog

- Graphic position
- Attributes



- ① Machine status display ("header")
- ② Dialog element
- ③ 8 vertical softkeys
- ④ 8 horizontal softkeys
- ⑤ Output of diagnostic messages
- ⑥ Graphic
- ⑦ Dialog
- ⑧ Header line of the dialog with header and long text

Figure 6-1 Structure of the dialog

Overview

The definition of a dialog (definition block) is basically structured as follows:

Definition block	Comment	Chapter reference
//M...	;Dialog start identifier	
DEF Var1=...	;Variables	Variables (Page 83)
...		
HS1=(...)	;Softkeys	Defining softkey menus (Page 63)
...		
PRESS (HS1)	;Method start identifier	
LM...	;Actions	Methods (Page 119)
END_PRESS	;Method end identifier	
//END	;Dialog end identifier	

Within the dialog definition block, various variables that appear as dialog elements in the dialog, as well as horizontal and vertical softkeys, are defined first. Different types of actions are then configured in methods.


Note

In operating area "Machine", for a dialog change, the following sequence should be observed:
Under the precondition that the dimensions of the following mask are smaller than the previous mask – or the position of the following mask is different than the previous mask, dialog change only functions if the following mask is exited before returning to the first mask, and only then is the first mask reloaded.

6.1.2 Defining dialog properties

Description

The properties of the dialog are defined in the start identifier line of the dialog.



- ① Machine status display ("header")
- ② Graphic
- ③ Dialog
- ④ Header line of the dialog with header and long text

Figure 6-2 Dialog properties

Programming

Syntax:	//M (Identifier/[Title]/[Graphic]/[Dimension]/[System or user variable]/[Position graphic]/[Attribute]/List of the mask-specific language files) See also Chapter Extended configuration syntax (Page 45).
Description:	Defines a dialog

6.1 Structure and elements of a dialog

Parameter:	Identifier		Name of the dialog
	Header		Dialog header as text or call for text (e.g. \$85011) from a language-specific text file.
	Graphic		Graphics file with path in double quotation marks.
	Dimension		Position and size of the dialog in pixels (distance from left-hand side, distance from top, width, height), in relation to the upper left-hand corner of the screen. The entries are separated by a comma.
	System or user variable		System or user variable to which the current cursor position is assigned. The NC or PLC can be provided with the cursor position via the system or user variable. The first variable has index 1. The order corresponds to the configuration order of the variables.
	Graphic position		Position of the graphic in pixels (distance from left-hand side, distance from top), in relation to the upper left-hand corner of the dialog. The entries are separated by a comma.
	Attributes		The specifications of the attributes are separated by a comma. Possible attributes are:
	CM		Column mode: Column alignment
		CM0	Default setting: The column distribution is carried out separately for each line.
		CM1	The column distribution of the line with the most columns applies to all lines.
	CB		CHANGE block: Response when dialog is opened: cb attributes specified for a variable in a variables definition take priority over the default setting in the dialog definition. See also AUTOHOTSPOT.
		CB0	Default setting: All CHANGE blocks associated with the dialog are processed when it is opened.
		CB1	CHANGE blocks are then only processed if the relevant value changes.
	XG		Integration of an X3D animation as help display (only in the machining step programming). Example: <code>//M(Meas/ \$85605/"myx3dhelpfile.hmi,,Z_Animation,,G17"///30,10/ XG1)</code>

	XG0	Default setting = 0
	XG1	The mask attribute XG must already be set to 1 in the mask definition, a change during runtime is not possible. Note: The specification in the mask property HLP must also be set accordingly.
AL		The alignment of the mask header can be influenced with the mask attribute AL. Example: Central setting of the "Set password" window header: <code>//M(MY_PWD_SET/"Set password"//"EasyPwdModalLayout"// AL2)</code>
	AL0	Left-justified, default
	AL1	Right-justified
	AL2	Centered

6.1 Structure and elements of a dialog

	KM		Freely scrolling in the mask (SIGfwScrollArea), if the virtual keyboard is to be displayed for MultiTouch, can be influenced as follows: - In the mask definition line with mask attribute "KM" (KeyboardMode) Example: <code>//M(MyMTMask/"MultiTouch Mask"//////KM1)</code> - As global setting for all Run MyScreens masks in the "easyscreen.ini" Example: [GENERAL] DefaultVirtualKeyboardMode=1 Note: If, when configuring the masks, the mask attribute KM is explicitly set, then this has a higher priority than the global setting in "easyscreen.ini". (See also Chapter SmartOperation and MultiTouch operation (Page 47))
		KM1	Free scrolling active (default)
		KM0	Free scrolling inactive
	PG		Alignment and appearance of the window title in conjunction with PNG images (only effective in the editor!) Example: <code>//M(MyPg1SampleMask/"My PG1 Sample Mask"//////PG1)</code>
		PG0	(Default)
		PG1	Alignment and appearance of the window title in conjunction with PNG images Path specification (on the far left), mask name (on the right) The display of the long text is no longer possible in this mode. Alternatively, you can work with tooltips.
	MA		Automatic adjustment of the field height for MultiTouch operation (Multi-Touch Adjustment) If required, the adjustment for a MultiTouch operator panel includes the necessary enlargement to the so-called minimum usable size (width, height) of the fields (exceptions: progress bar, animated GIF, CustomWidget) and the line spacing. The MultiTouch adjustment can be made - globally for all Run MyScreens mask in "easyscreen.ini", e.g. [GENERAL] DefaultMultiTouchAdjustmentLevel=1 - or mask-specifically in the mask definition line with the mask property "MA" in order to overwrite the global setting in "easyscreen.ini", e.g. <code>//M(MyMTMask/"MultiTouch Mask"//////MA1)</code> If the mask attribute MA is set explicitly in the mask configuration, then this has a higher priority than the global setting in "easyscreen.ini". (See also Chapter SmartOperation and MultiTouch operation (Page 47))
		MA0	There is no adjustment
		MA1	Only those fields are adjusted for which no spacing from the top and/or field height/width has been configured – i.e. the fields that use default positions and therefore for which Run MyScreens calculates the spacing from the top and/or field height/width. (Default)

	MA2	All fields are adjusted irrespective of the configured field sizes.
PA		Optimized and pixel-precise stretching of the fields for higher resolutions (Pixel Fine Adjustment) Previously all field positions were calculated in relation to 640x480 and then zoomed with the appropriate horizontal and vertical stretch factors. This process has the disadvantage that rounding errors can occur with "unfavorable stretch factors". For example, the field height or line spacing can "jump" by a pixel from line-to-line. The "Pixel Fine Adjustment" mode can be used to prevent this as the field positions are determined directly in the current resolution. //M(MyMask/"My Mask"////PA1) This setting can also be made globally for all Run MyScreens masks in "easyscreen.ini", e.g. [GENERAL] DefaultPixelFineAdjustment=1 If the mask attribute PA is set explicitly in the mask configuration, it has a higher priority than the global setting in "easyscreen.ini". If a mask is displayed with Font Adjustment = FA1, then the Pixel Fine Adjustment mode is also automatically active for this mask. (See also Chapter SmartOperation and MultiTouch operation (Page 47))
	PA0	Stretching as previously, i.e. the positions are calculated in relation to 640x480 and then stretched. (For compatibility reasons: Default)
	PA1	Optimized and pixel-precise stretching of the fields for higher resolutions
FA		Field height and line spacing proportional to the font (Font Adjustment) This setting can also be made globally for all Run MyScreens masks in "easyscreen.ini", e.g. [GENERAL] DefaultFontAdjustment=1 If the mask attribute FA is set explicitly in the mask configuration, then this has a higher priority than the global setting in "easyscreen.ini". The settings for the DefaultLineHeight and DefaultLineSpacing have no significance when Font Adjustment mode is active. (See also Chapter SmartOperation and MultiTouch operation (Page 47))
	FA0	Field height and line spacing are stretched as previously. (For compatibility reasons: Default)
	FA1	Field height and line spacing are set proportional to the font (automatically sets mask attribute PA=1)
	FA2	Same as FA1, but the X coordinate and the field width are also stretched proportionally to the font (Automatically sets mask attribute PA=1) (Only possible in conjunction with attribute XG=1!)
NT		Navigation Type
	NT0	NT0 = standard mode The navigation is analogous to the masks of the operating area in which Run MyScreens mask is integrated. This means in the cycle masks in the editor, navigation is line-oriented (see NT2), in all other "normal" masks, it is a geometrical (see NT1).

6.1 Structure and elements of a dialog

		NT1	Geometrical navigation (top, bottom, left, right), until the borders of the mask are reached (standard in a normal Run MyScreens environment, e.g. area "Custom")
		NT2	Line-oriented, i.e. within the line to the right until the end of the line is reached (standard, in the cycle masks of the editor)
	NR		Navigation direction when pressing the Enter key (Return Navigate Direction)
		NR0	NR0 = off (default), i.e. when pressing the Enter key, navigation is realized within the mask in a tabular sequence (standard in the normal Run MyScreens environment)
		NR1	When pressing the Enter key, navigation is the same as when pressing the up arrow key
		NR2	As for NR1, however, downward
		NR3	As for NR1, however, to the left
		NR4	As for NR1, however, to the right
	TA		Tooltip alignment
		TA0	Automatic (default)
		TA1	Left
		TA2	Right
		TA3	Top
		TA4	Bottom
		TA5	Top left
		TA6	Bottom left
		TA7	Top right
TA8	Bottom right		
MC			Mask background color (mask color) Example: Set mask background color blue (= 6) <code>//M(MyMask/"MyMask"/////6)</code> or <code>PRESS(HS1)</code> <code>MC=6</code> <code>END_PRESS</code>
List of the mask-specific language files			separated by a comma

Accessing the dialog properties

Read and write access to the following dialog properties is permitted within methods (e.g. PRESS block).

- HD = Header
- HLP = Help display
- VAR = System or user variable
- MC = Mask background color
- CM = Column alignment (read-only)

- CB = Behavior when opening (read-only)
- XG = Integration of X3d (read-only)
- AL = Mask header alignment (read-only)

Example




Figure 6-3 "Example 2: showing graphic"

```
//S(Start)
HS7=("Example", sel, ac7)

PRESS (HS7)
  LM("Mask2")
END_PRESS

//END
//M(Mask2/"Example 2 : showing graphic"/"example.png")
HS1=("new\nHeader")
HS2=("")
HS3=("")
HS4=("")
HS5=("")
HS6=("")
HS7=("")
```

6.1 Structure and elements of a dialog

```
HS8= ("")
VS1= ("")
VS2= ("")
VS3= ("")
VS4= ("")
VS5= ("")
VS6= ("")
VS7= ("")
VS8= ("")

PRESS (HS1)
    Hd= "new Header"
END_PRESS
...
//END
```

See also

Programming example for the "Custom" area (Page 274)


6.1.3 Defining dialog elements

Dialog element

The term "dialog element" refers to the visible part of a variable, i.e. short text, graphics text, input/output field, unit text and tooltip. Dialog elements fill lines in the main body of the dialog. One or more dialog elements can be defined for each line.

Variable properties

All variables are valid in the active dialog only. Properties are assigned to a variable when it is defined. The values of dialog properties can be accessed within methods (e.g. a PRESS method).



- ① Header line of the dialog with header and long text
- ② Dialog element
- ③ Short text
- ④ Input/output field
- ⑤ Graphic text
- ⑥ Unit text
- ⑦ Main body of the dialog

Figure 6-4 Elements of a dialog

Programming - Overview

The single parameters to be separated by commas are enclosed in round brackets:

DEF [identifier] =	Identifier = Name of variable
	Variable type
	/[Limit values or toggle field]
	/[Default]
	/[Texts (Long text, Short text Image, Graphic text, Unit text)]
	/[Attributes]
	/[Help display]
	/[System or user variable]
	/[Position of short text]
	/[Position of I/O field(Left, Top, Width, Height)]

	//[Colors]
	//[online help] (Page 72)

See also

Variable parameters (Page 91)

6.1.4 Defining dialogs with multiple columns**Overview**

Multiple variables can also be represented in a dialog on one line. In this case, the variables are all defined in the configuration file on a single definition line.

```
DEF VAR11 = (S///"Var11"), VAR12 = (I///"Var12")
```

To make individual variables in the configuration file more legible, the definition lines can be wrapped after every variables definition and following comma.

The key word "DEF" always indicates the beginning of a new line:

```
DEF Tnr1=(I//1/"", "T ", ""/wr1///, 10/20,, 50),
  TOP1=(I///, "Type="/WR2//"$TC_DP1[1,1]"/80,, 30/120,, 50),
  TOP2=(R3///, "L1="/WR2//"$TC_DP3[1,1]"/170,, 30/210,, 70),
  TOP3=(R3///, "L2="/WR2//"$TC_DP4[1,1]"/280,, 30/320,, 70),
  TOP4=(R3///, "L3="/WR2//"$TC_DP5[1,1]"/390,, 30/420,, 70)
DEF Tnr2=(I//2/"", "T ", ""/wr1///, 10/20,, 50),
  TOP21=(I///, "Typ="/WR2//"$TC_DP1[2,1]"/80,, 30/120,, 50),
  TOP22=(R3///, "L1="/WR2//"$TC_DP3[2,1]"/170,, 30/210,, 70),
  TOP23=(R3///, "L2="/WR2//"$TC_DP4[2,1]"/280,, 30/320,, 70),
  TOP24=(R3///, "L3="/WR2//"$TC_DP5[2,1]"/390,, 30/420,, 70)
```

Note

When configuring multi-column dialogs, please observe that a large number of columns might slow down the system!

6.1.5 Password dialogs

Using the standard password dialogs

You can integrate the following predefined password dialogs in the screen configuration:

- Set password




Figure 6-5 Set password dialog

- Change password




Figure 6-6 Change password dialog

- Delete password




Figure 6-7 Delete password dialog

Note

Password functionality is provided with these dialogs. The dialogs do not correspond to the dialogs of SINUMERIK Operate.

The dialogs can be called either via the Load softkey (LS) function or the Load mask (LM) function:

1. Call via the Load softkey (LS) function:
`LS ("Passwd", "slespasswd.com", 1)`
 Extension of the vertical softkeys:
 - Softkey 1: Set password
 - Softkey 2: Change password
 - Softkey 3: Delete password
2. Alternatively, the three masks can be directly jumped to by calling the (LM) function:
 - Set password: `LM ("PWD_SET", "slespasswd.com", 1)`
 - Change password: `LM ("PWD_CHG", "slespasswd.com", 1)`
 - Delete password: `LM ("PWD_CLEAR", "slespasswd.com", 1)`

6.1.6 Using display images/graphics

Use of graphics

A distinction is made between:

- Figures/graphics in the graphic area
- Help displays illustrating, for example, individual variables, which are superimposed in the graphic area.
- More help displays can be configured instead of short text or an input/output field, which you position where you like.

Storage locations

The image matching the resolution of the connected monitor is searched for in the associated resolution directories in the following sequence:

[System user-directory]/ico/ico<Resolution>

[System oem-directory]/ico/ico<Resolution>

[System addon-directory]/ico/ico<Resolution>

If the image is not displayed or not found, copy it into one of the following directories for a resolution of 640 x 480 pixels:

[System user-directory]/ico/ico640

[System oem-directory]/ico/ico640

[System addon-directory]/ico/ico640

Note

The images are positioned proportionally for the different panel resolutions

6.2 Defining softkey menus

Definition

The term softkey menu is used to refer to all the horizontal and vertical softkeys displayed on a mask. In addition to the existing softkey menus, it is possible to define other menus, which partially or completely overwrite the existing menus.

The names of the softkeys are predefined. Not all softkeys need to be assigned.

HSx x 1 - 8, Horizontal softkeys 1 to 8

VSy y 1 - 8, Vertical softkeys 1 to 8

The definition of a softkey menu (softkey menu definition block) is basically structured as follows:

Definition block	Comment	Section reference
//S . . .	;Start identifier of softkey menu	
HSx= . . .	;Define softkeys	
PRESS (HSx) LM . . . END_PRESS	;Method start identifier ;Actions ;Method end identifier	See Chapter Methods (Page 119)
//END	;End identifier of softkey menu	

Description

Properties are assigned to softkeys during definition of the softkey menu.

Programming

Syntax:	//S(Identifier)	;Start identifier of softkey menu
	... //END	;End identifier of softkey menu
	See also Section Extended configuration syntax (Page 45).	
Description:	Defines the softkey menu	
Parameters:	Identifier	Name of the softkey menu
	Text or image file name	
Syntax:	SK = (Text[, access level][, Status][, Alignment of the softkey image][, text alignment referred to the softkey image])	
Description:	Define softkey	
Parameters:	SK	Softkey, e.g. HS1 to HS8, VS1 to VS8

	Text	Enter text	
	Image file name	"\my_pic.png" or via separate text file \$85199, e.g. with the following text in the (language-specific) text file: 85100 0 0 "\my_pic.png". The image size which can be displayed on a softkey depends on the OP used:	
		OP 08:	640 x 480 mm → 25 x 25 pixels
		OP 010:	640 x 480 mm → 25 x 25 pixels
		OP 012:	800 x 600 mm → 30 x 30 pixels
		OP 015:	1024 x 768 mm → 40 x 40 pixels
		OP 019:	1280 x 1024 mm → 72 x 72 pixels
	Access level	ac0 to ac7 (ac7: default)	
	Status	se1: visible (default) se2: disabled (gray text) se3: displayed (last softkey used)	
	Alignment of the softkey image	PA (PictureAlignment)	
		Valid values: 0: Left 1: Right 2: Centered 3: Top (default) 4: Bottom	
	Text alignment in relation to the softkey image	TP (TextAlignedToPicture)	
		Valid values: 0: Text is not aligned to the image 1: Text is aligned to the image (default)	

Note

Enter %n in the softkey text to create a line break.

A maximum of 2 lines with 9 characters each are available.

Assigning access level

Operators can only access information on this access level and lower access levels (see also AUTOHOTSPOT).

Example

```
//S (Menu1) ; Start identifier of softkey menu
HS1="NEW", ac6, se2 ; Define softkey HS1, assign the label "NEW", protection level 6, and the status "disabled"
```

6.2 Defining softkey menus

```

HS2=("\\image1.png")                ; Assign a softkey to the graphic
HS3=("Exit")
HS4=(["Confirm","\\sk_ok.png"],PA0,TP1) ; Softkey with text and graphic, Text="Confirm", Im-
                                         age="sk_ok.png", Alignment of the softkey image: Left,
                                         text is aligned to the image

VS1=("sub mask")
VS2=($85011, ac7, se2)              ; Define softkey VS2, assign the text from the lan-
                                         guage file, protection level 1, and the status "disa-
                                         bled"

VS3=("Cancel", ac1, se3)            ; Define softkey VS3, assign the label "Cancel", pro-
                                         tection level 1 and the status "highlighted"

VS4=("OK", ac6, se1)                ; Define softkey VS4, assign the label "OK", protec-
                                         tion level 6 and the status "visible"

VS5=(SOFTKEY_CANCEL,,se1)           ; Define cancel standard softkey VS5 and assign the
                                         status "visible"

VS6=(SOFTKEY_OK,,se1)              ; Define OK standard softkey VS6 and assign the status
                                         "visible"

VS7=(["\\image1.png","OEM text"],,se1) ; Define softkey VS7, assign an image, assign the la-
                                         bel "OEM Text" and the status "visible"

VS8=(["\\image1.png",$83533],,se1)   ; Define softkey VS8, assign an image, assign text
                                         from language file and the status "visible"

PRESS(HS1)                          ; Method start identifier
    HS1.st=" Calculate"              ; Assign a label text to the softkey
...
END_PRESS                          ; Method end identifier

PRESS(RECALL)                      ; Method start identifier
    LM("Screen21")                  ; Load dialog
END_PRESS                          ; Method end identifier
//END                              ; End identifier of softkey menu

```

6.2.1 Changing softkey properties during runtime

Description

The softkey properties Text, Access Level and Status can be changed in the methods during runtime.

Programming

Syntax:	SK.st = "Text" SK.ac = Access level SK.se = Status SK.pa = "Alignment of the softkey image" SK.tp = "Text alignment in relation to the softkey image"		;Softkey with label ;Softkey with protection level ; Softkey with status ;Softkey with image ;Softkey with image and label
Description:	Assign properties		
Parameter:	Text		Label text in inverted commas
	Access level		Range of values: 0 ... 7
	Status	1: Visible and operator-controllable 2: Disabled (gray text) 3: Highlighted (last softkey used)	
	Alignment of the softkey image	0: Left 1: Right 2: Centered 3: Top (default) 4: Bottom	
	Text alignment in relation to the softkey image	0: Text is not aligned to the image 1: Text is aligned to the image (default)	

Example




Figure 6-8 Example 3: Graphics and softkeys

```
//S(Start)
HS7=("Example", ac7, sel)

PRESS(HS7)
  LM("Maske3")
END_PRESS

//END

//M(Maske3/"Example 2: showing graphic"/"example.png")
HS1=("")
HS2=("")
HS3=("")
HS4=("")
HS5=("")
HS6=("")
HS7=("")
HS8=("")
VS1=("")
VS2=("")
```

```

VS3=("")
VS4=("\\sp_ok.png",,SE1)
VS5=("\\sp_ok_small.png","OEM Text",,SE1)
VS6=("")
VS7=(SOFTKEY_OK,,SE1)
VS8=(SOFTKEY_CANCEL,,SE1)
PRESS (VS4)
    EXIT
END_PRESS
PRESS (VS5)
    EXIT
END_PRESS
PRESS (VS7)
    EXIT
END_PRESS
PRESS (VS8)
    EXIT
END_PRESS
//END

```

6.2.2 Language-dependent text

Overview

Language-dependent texts are used for:

- Softkey labels
- Headings
- Help texts
- Any other texts

The language-dependent texts for dialogs are stored in text files.

The text files are stored in the following directories:

- [System user-directory]/lng
- [System oem-directory]/lng
- [System addon-directory]/lng

Note

The text files must be saved in the same way as the project files.

For example:

[System user-directory]/lng/[Text file]

[System user-directory]/proj/[Configuration file]

alsc.txt Language-dependent texts for the Siemens standard cycles

almc.txt Language-dependent texts for the Siemens measuring cycles

The text files used during program runtime are specified in the "easyscreen.ini" file:

```
[LANGUAGEFILES]
LngFile03 = user.txt      ;->user<_xxx>.txt (e.g.: user_eng.txt)
```

In this instance, the "user.txt" file has been chosen as an example of a text file. The name can always be freely selected. Depending on the language of the texts within the file, the relevant language code must be added according to the following syntax. An underscore followed by the relevant language identifier is added after the name e.g. "user_eng.txt".

Note

You must not use LngFile01 and LngFile02 for user texts because they are already assigned in the standard "easyscreen.ini".

See also

AUTOHOTSPOT

Mask-specific language files

In order to avoid overlaps for the number ranges used in the language files, only certain language files can be used in a specific mask.

This is the reason that the language files to be used are listed in the mask definition line, separated by a comma. The file listed at the last location has the highest priority (analogous to the logic in "easyscreen.ini").

All of the language-dependent texts used in the mask are predominantly searched for in these language files. If the text is not found in these, then a search is made in text files configured in "easyscreen.ini".

If no language files have been defined in the mask, then a search is only made in the language files specified in "easyscreen.ini".

Note

The English language file is used (default) if a language file is not available in the currently selected language.

Examples:

```
//M(MyMask/$85597///// //"mytexts.txt, general.txt, mask.txt")
DEF ...
```

You can also use this procedure for the start softkeys:

```
//S(Start, "mytexts.txt, general.txt, mask.txt")
VS1=($85597)
PRESS (VS1)
    LM("MyMask", "masks.com")
END_PRESS
```

Format of text files

The text files must be saved in UTF-8 format.

Note

Make sure that the coding is set to UTF-8 in the editor that you are using when saving the configuration and language files.

Format of a text entry

Syntax:	8xxxx 0 0 "Text"		
Description:	Assignment between text number and text in the file		
Parameters:	xxxx	85,000 to 89,999 900,000 to 999,999	Text identification number range reserved for users. You must assign unique numbers.
	"Text"		Text that appears in the dialog
	%n		Control characters in the text for creating a line break

Parameters 2 and 3 are separated by blanks and act as control characters for alarm text output. To ensure that the text format is identical to that of the alarm texts, you must set zero.

Examples of language-dependent texts:

```
85000 0 0 "Retraction plane"
```

```
85001 0 0 "Drilling depth"
```

```
85002 0 0 "Pitch"
```

```
85003 0 0 "Pocket radius"
```

6.3 Configuring the online help

6.3.1 Overview

In addition to the existing extensive online help, you also have the option of generating a manufacturer-specific online help and then linking this into SINUMERIK Operate.

This online help is generated in the HTML format, i.e. it comprises HTML documents that are linked with one another. The subject being searched for is called in a separate window from a contents or index directory. Similar to a document browser (e.g. Windows Explorer), a list of possible selections is displayed in the left-hand half of the window and when you click on the required subject, the explanation is displayed in the right hand half of the window.

Context sensitive selection of online help pages is not possible.

Procedure

1. Generating HTML files
2. Generating a help book
3. Integrating the online help in SINUMERIK Operate
4. Saving help files

Other application cases

Online help for the following OEM-specific expansions can be created and used to supplement the SINUMERIK Operate online help system:

- Online help for **cycles and/or M functions** of the machine manufacturer which extend the programming options for SINUMERIK control systems. This online help is called in just the same way as the SINUMERIK Operate online help "Programming".
- Online help for OEM-specific **variables** of the machine manufacturer. This online help is called from the variable view of SINUMERIK Operate.

Programming online help

You can use the "SINUMERIK HMI programming package sl" for additional options for configuring the online help. Using this programming package, it is possible to develop high-level language applications in the C++ programming language for SINUMERIK Operate on the NCU 7x0.

Note

The "SINUMERIK HMI programming package sl" must be ordered separately as a software option. The associated documentation is provided together with the programming package.

6.3.2 Generating HTML files

Generating help files in the HTML format. It is possible to save all information in a single HTML file or to distribute the information over several HTML files.

You can assign the file names yourself, however, you must observe the following:

- References within HTML files should always be specified with relative paths. Only then can it be ensured that the references function in precisely the same way on both the development computer as well as on the target system.
- If jumps are to be made to certain points within an HTML file per link, then so-called anchors must be defined for this purpose.
Example of an HTML anchor:
`<a name="myAnchor">This is an anchor</a>`
- The contents of HTML documents must be saved with the UTF-8 coding. Only then is it guaranteed that the HTML documents are correctly displayed in all of the country languages supported by SINUMERIK Operate.
- The following sub-sets of the HTML functional scope are supported:

HTML tags

Tag	Description	Comment
a	Anchor or link	Supported attributes: href and name
address	Address	
big	Larger font	
block quote	Indented paragraph	
body	Document body	Supported attributes: bgcolor (#RRGGBB)
br	Line break	
center	Centered paragraph	
cite	Inline citation	Same effect as tag i
code	Code	Same effect as tag tt
dd	Definition data	
dfn	Definition	Same effect as tag i
div	Document division	The standard block attributes are supported

Tag	Description	Comment
dl	Definition list	The standard block attributes are supported
dt	Definition term	The standard block attributes are supported
em	Emphasized	Same effect as tag i
font	Font size, family, color	Supported attributes: size, face, and color (#RRGGBB)
h1	Level 1 heading	The standard block attributes are supported
h2	Level 2 heading	The standard block attributes are supported
h3	Level 3 heading	The standard block attributes are supported
h4	Level 4 heading	The standard block attributes are supported
h5	Level 5 heading	The standard block attributes are supported
h6	Level 6 heading	The standard block attributes are supported
head	Document header	
hr	Horizontal line	Supported attributes: width (can be specified as absolute or relative value)
html	HTML document	
i	Italic	
img	Image	Supported attributes: src, width, height
kbd	User-entered text	
meta	Meta information	
li	List item	
nobr	Non-breakable text	
ol	Ordered list	The standard attributes for lists are supported
p	Paragraph	The standard block attributes are supported (default setting: left-aligned)
pre	Preformatted text	
s	Strikethrough	
samp	Sample code	Same effect as tag tt
small	Small font	
span	Grouped elements	
strong	Strong	Continuous text is heavily emphasized, replaces tag b
sub	Subscript	
sup	Superscript	
table	Table	Supported attributes: border, bgcolor (#RRGGBB), cellpadding, cellspacing, width (absolute or relative), height
tbody	Table body	No effect
td	Table data cell	The standard attributes for table cells are supported
tfoot	Table footer	No effect
th	Table header cell	The standard attributes for table cells are supported
thead	Table header	This is used to print tables that extend over several pages
title	Document title	
tr	Table row	Supported attributes: bgcolor (#RRGGBB)
tt	Typewrite font	
u	Underlined	

Tag	Description	Comment
ul	Unordered list	The standard attributes for lists are supported
var	Variable	Same effect as tag tt

Block attributes

The following attributes are supported by the tags div, dl, dt, h1, h2, h3, h4, h5, h6, p:

- align (left, right, center, justify)
- dir (ltr, rtl)

Standard attributes for lists

The following attributes are supported by tags ol and ul:

- type (1, a, A, square, disc, circle)

Standard attributes for tables

The following attributes are supported by tags td and th:

- width (absolute, relative, no-value)
- bgcolor (#RRGGBB)
- colspan
- rowspan
- align (left, right, center, justify)
- valign (top, middle, bottom)

CSS properties

The following table includes the supported CSS functional scope:

Property	Values	Description
background color	<color>	Background color for elements
background-image	<uri>	Background image for elements
color	<color>	Foreground color for text
text-indent	<length>px	Indent the first line of a paragraph in pixels
white-space	normal pre nowrap pre-wrap	Defines how whitespace characters are handled in HTML documents
margin-top	<length>px	Width of the upper edge of the paragraph in pixels
margin-bottom	<length>px	Width of the lower edge of the paragraph in pixels
margin-left	<length>px	Length of the left hand edge of the paragraph in pixels
margin-right	<length>px	Width of the right-hand edge of the paragraph in pixels

Property	Values	Description
vertical-align	baseline sub super middle top bottom	Vertical alignment for text (in tables, only the values middle, top and bottom are supported)
border-color	<color>	Border color for text tables
border-style	none dotted dashed dot-dash dot-dot-dash solid double groove ridge inset outset	Border style for text tables
background	[<'background-color'> <'background-image'>]	Short notation for background property
page-break-before	[auto always]	Page break before a paragraph/table
page-break-after	[auto always]	Page break after a paragraph/table
background-image	<uri>	Background image for elements

Supported CSS selectors

All of the CSS 2.1 selector classes are supported, with the exception of so-called pseudo-selector classes, such as :first-child, :visited and :hover.

6.3.3 Generating the help book

The help book is an XML file in which the structure of the online help is defined. In this file, you define:

- HTML documents
- Contents and subject index

Syntax for the help book

Tag	Number	Meaning
HMI_SL_HELP	1	Root element of the XML document
I-BOOK 	+	Identifies a help book. The name can be freely selected under the constraint that no name predefined by the system is used (such as sinumerik_alarm_plc_pmc). In the example, the name of the help book is "hmi_myhelp" Attributes:
		ref Identifies the HTML document that is displayed as the entry page for the help book.
		title Title of the help book that is displayed in the table of contents.
		helpdir Directory that contains the online help of the help book.

Tag	Number	Meaning	
I-ENTRY II II II II II II	*	Section of the online help Attributes:	
		ref	Identifies the HTML document that is displayed as entry page for the section.
		title	Title of the section that is displayed in the table of contents.
II-INDEX_ENTRY II II II II II II	*	Subject (keyword) to be displayed Attributes:	
		ref	Identifies the HTML document that is jumped to for this subject index entry.
		title	Title of the subject that is displayed in the subject index.

The following applies for the "Number" column:

* means 0 or more


+ means 1 or more

Example for a help book

In the following example, the structure of a help book with the "My Help" name is described. Further, it forms the basis for the table of contents and subject index.


```
<?xml version="1.0" encoding="utf-8"?>
<HMI_SL_HELP language="en-US">
  <BOOK ref="index.html" title="My Help" helpdir="hmi_myhelp">
    <ENTRY ref="section_1.html" title="Section 1">
      <INDEX_ENTRY ref="section_1.html#Keyword_1" title="Keyword_1"/>
      <INDEX_ENTRY ref="section_1.html#Keyword_2" title="Keyword_2"/>
    </ENTRY>
    <ENTRY ref="section_2.html" title="Section 2">
      <INDEX_ENTRY ref="section_2.html#Keyword_3" title="Keyword_3"/>
    </ENTRY>
    <ENTRY ref="section_3.html" title="Section 3">
      <ENTRY ref="section_31.html" title="Section 31">
        <INDEX_ENTRY ref="section_31.html#test" title="test;section31"/>
      </ENTRY>
      <ENTRY ref="section_32.html" title="Section 32">
        <INDEX_ENTRY ref="section_32.html#test" title="test;section32"/>
      </ENTRY>
    </ENTRY>
  </BOOK>
</HMI_SL_HELP>
```

The book comprises three sections, whereby the third section has two subsections. The various subject words (keywords) are defined within the section.



You have the following three options to format the subject index:

1. Single entry:
`<INDEX_ENTRY ...title="index"/>`
2. Two two-stage entry, whereby each title has a main and a subentry. Separate the entries from one another using a comma.
`<INDEX_ENTRY ...title="mainIndex_1,subIndex_1 with mainIndex_1"/>`
3. Two-stage entry, whereby the first title is the main entry and the second title is the subentry. Separate the entries from one another using a semicolon.
`<INDEX_ENTRY ...title="mainIndex_2;subIndex_2 without mainIndex_1"/>`



6.3.4 Integrating the online help in SINUMERIK Operate

If you wish to integrate the generated help book into the online help system of SINUMERIK Operate, then you require the "slhlp.xml" file.

Format description of the "slhlp.xml"

Tag	Number	Meaning
CONFIGURATION	1	Root element of the XML document. Designates that this involves a configuration file.
I-OnlineHelpFiles	1	Introduces the section about the online help books.
II-<help_book>	*	Introduces the section of a help book.

Tag	Number	Meaning
III-EntriesFile III III III III	1	File name of the help book with the list of contents and subject (keyword) entries. Attributes: value Name of the XML file type Data type of the value (QString)
III-Technology III III III III III III III III III	0, 1	Specifies the technology that applies to the help book. "All" applies to all technologies. If the help book applies to several technologies, then the technologies are listed separated by comma. Possible values: All, Universal, Milling, Turning, Grinding, Stroking, Punching Attributes: value Technology data type Data type of the value (QString)
III -DisableSearch III III III III III	0, 1	Disable the subject (keyword) search for the help book. Attributes: value true, false type type, data type of the value (bool)
III-DisableFullTextSearch III III III III	0, 1	Disable the full text search for the help book. Attributes: value true, false type type, data type of the value (bool)
III-DisableIndex III III III III	0, 1	Disable the subject index for the help book. Attributes: value true, false type type, data type of the value (bool)
III-DisableContent III III III III	0, 1	Disable the table of contents for the help book. Attributes: value true, false type type, data type of the value (bool)
III-DefaultLanguage III III III III III	0, 1	Abbreviation for the language that should be displayed if the actual country language is available for the help book. Attributes: value chs, deu, eng, esp, fra, ita, ... type Data type of the value (QString)

The following applies for the "Number" column:

* means 0 or more

Example of a file "slhlp.xml"

The help book "hmi_myhelp.xml" is made known to SINUMERIK Operate in the following example.

The subject index has not been activated for the help book.

```
<?xml version="1.0" encoding="UTF-8" standalone="yes"?>
<!DOCTYPE CONFIGURATION>
<CONFIGURATION>
  <OnlineHelpFiles>
    <hmi_myHelp>
      <EntriesFile value="hmi_myhelp.xml" type="QString"/>
      <DisableIndex value="false" type="bool"/>
    </hmi_myHelp>
  </OnlineHelpFiles>
</CONFIGURATION>
```

6.3.5 Saving help files

Saving help files in the target system

1. Open the **/oem/sinumerik/hmi/hlp** directory and create a new folder for the required language. For this purpose, use the specified language code.
It is mandatory that the folder names are written in lower-case letters.
For instance, if you are integrating a help function for German and English, then create the "deu" and "eng" folders.
2. Place the help book, e.g. "hmi_myhelp.xml" in the "deu" and "eng" folders.
3. Copy the help files into the directories, e.g. **/oem/sinumerik/hmi/hlp/deu/hmi_myhelp** for German and **/oem/sinumerik/hmi/hlp/eng/hmi_myhelp** for English help files.
4. Place the configuration file "slhlp.xml" into the directory **/oem/sinumerik/hmi/cfg**.
5. Restart the HMI.

Note

When displaying the list of contents and subject index of a help book, the help files are saved in the binary format (slhlp_<Hilfe-Buch_*.hmi) under the directory **/siemens/sinumerik/sys_cache/hmi/hlp** for faster use. If you change the help book, you must always delete these files.

6.3.6 Help files in PDF format

In addition to help files in HTML format, you can also include PDF-format information in the operating software. Individual PDF helps can be opened with links from the table of contents or index, or directly from HTML files.

Storing PDF helps

Copy the PDF helps to one of the following directories:

```
/oem/sinumerik/hmi/hlp/<lng>/<hmi_myhelp>
```

```
/user/sinumerik/hmi/hlp/<lng>/<hmi_myhelp>
```

Including PDF helps

Bind in dialog configurations or configurations of table of contents and indexes with the extension "pdf" in the same manner as for the "html" extension:

```
<ENTRY ref="myFile.pdf" title="Help 1">
```

Create a link from HTML files to the PDF help:

```
<a href="myFile.pdf">My Help File</a>
```

Note

It is not possible to select context-sensitive jump labels in the PDF help, select jump labels or make jumps to other HTML or PDF files.

The search function is possible only within a PDF file. A higher-level search over multiple PDF helps is not supported.

Variables

7.1 Defining variables

Variable value

The major property of a variable is its value.

The value of variables can be assigned by means of:

- Default settings when defining variables
- Assignment to a system or user variable
- A method

Programming

Syntax:	Identifier. val = Variable value Identifier = Variable value	
Description:	Variable value val (value)	
Parameter:	Identifier:	Name of the variable
	Variable value:	Value of the variable
Example:	<pre>VAR3 = VAR4 + SIN (VAR5) VAR3.VAL = VAR4 + SIN (VAR5)</pre>	

Variable status

The "Variable status" property scans a variable for valid content during runtime. This property can be read and written with the value FALSE = 0.

Programming

Syntax:	Identifier. vld	
Description:	Variable status vld (validation)	
Parameter:	Identifier:	Name of the variable
	FALSE = TRUE =	The result of the scan can be: invalid value valid value
Example:	<pre>IF VAR1.VLD == FALSE VAR1 = 84 ENDIF</pre>	

7.2 Application examples

Help variables

Help variables are internal arithmetic variables. Arithmetic variables are defined like other variables, but have no other properties apart from variable value and status, i.e. help variables are not visible in the dialog. Help variables are of the VARIANT type.

Programming

Syntax:	DEF [identifier]	
Description:	Internal arithmetic variables of the VARIANT type	
Parameters:	Identifier:	Name of the help variable
Example:	DEF OTTO ;Definition of a help variable	

Syntax:	Identifier.val = Help variable value	
	Identifier = Help variable value	
Description:	A value is assigned to a help variable in a method.	
Parameters:	Identifier:	Name of the help variable
	Help variable value:	Content of the help variables

Example:

```

LOAD
    OTTO = "Test"                ; Assign the value "Test" to the help variable Otto
END_LOAD
LOAD
    OTTO = REG[9].VAL           ; Assign the value of the register to the help variable
                                Otto
END_LOAD

```

Calculation with variables

Variables are calculated every time you exit an I/O field (by pressing the ENTER or toggle key). The calculation is configured in a CHANGE method that is processed every time the value changes.

Whether a variable has a valid value can be queried via the variable status, e.g.:

```

IF VAR1.VLD == FALSE
    VAR1 = 84
ENDIF

```

7.3 Example 1: Assigning the variable type, texts, help display, colors, tooltips

Addressing system variables indirectly

A system variable can also be addressed indirectly, i.e. as a function of another variable:

```
PRESS (HS1)
  ACHSE=ACHSE+1
  WEG.VAR="$AA_DTBW["<<ACHSE<<"]"      ;Address axis address via variable
END_PRESS
```

Changing a softkey label

Example:

```
HS3.st = "New text"      ;Change softkey label
```

7.3 Example 1: Assigning the variable type, texts, help display, colors, tooltips

Example 1a

The following example defines a variable for which the properties variable type, texts, help display and colors are set.

DEF Var1 = (R///,"Actual value",,"mm"//"/Var1.png"////8,2)		
	Variable type:	REAL
	Texts:	
	Short text:	Actual value
	Unit text:	mm
	Help screen:	Var1.png
	Colors:	
	Foreground color:	8 (brown)
	Background color:	2 (orange)

Example 1b

The following example defines a variable for which the properties variable type, default setting, texts, tooltip, input mode and position of short text are set.

DEF Var2 = (I/5/,"Value",,""," Tooltip text"/wr2///20,250,50)		
	Variable type:	INTEGER
	Default setting:	5
	Texts:	
	Short text:	Value (possible language text ID)
	Tooltip:	ToolTipText
	Attributes:	
	Input mode:	Reading and writing
	Position of short text:	
	Distance from left:	20
	Distance from top:	250
	Width:	50

See also

Variable parameters (Page 91)

7.4 Example 2: Assigning the Variable Type, Limits, Attributes, Short Text Position properties

Example 2

The following example defines a variable for which the properties variable type, limits, input mode, alignment and position are set.

DEF Var2 = (I/0,10///wr1,al1///,,300)		
	Variable type:	INTEGER
	Limits or toggle field entries:	MIN: 0 MAX: 10
	Attributes:	
	Input mode:	Read-only
	Alignment of short text:	Right-justified
	Position of short text:	
	Width:	300

See also

Variable parameters (Page 91)

7.5 Example 3: Assigning the Variable Type, Default, System or User Variable, Input/Output Field Position properties

Example 3

The following example defines a variable for which the properties variable type, default setting, system or user variable and position are set.

DEF Var3 = (R//10///"\$R[1]"//300,10,200//)		
	Variable type:	REAL
	Default setting:	10
	System or user variable:	\$R[1] (R-Parameter 1)
	Position of short text:	Default position in relation to input/output field
	Position of input/output field:	
	Distance from left:	300
	Distance from top:	10
	Width:	200

See also

Variable parameters (Page 91)

7.6 Example 4: Toggle field and list field

Example 4a

Various entries in the toggle field:

```

DEF Var1 = (I/* 0,1,2,3)           ;Simple toggle field to toggle numeric values
DEF Var2 = (S/* "On", "Off")       ;Simple toggle field to toggle strings
DEF Var3 = (B/* 1="On", 0="Off")    ;Extended toggle field to toggle numeric values whereby a
                                   ;display text is assigned to each numeric value
DEF Var4 = (R/* ARR1)              ;Toggle field, which obtains its values to be toggled from an
                                   ;array

```

Example 4b

The list field corresponds to the configuration of a toggle field, but the display type for the list field (variable attribute DT = 4) must also be set.

DEF VAR_LISTBOX_Text = (S/*\$80000,\$80001,\$80002,\$80003,\$80004/\$80001//DT4////200,,340,60)		
	Variable type:	STRING
	Limits / toggle field:	*\$80000,\$80001,\$80002,\$80003,\$80004 (list of the language-dependent texts to be displayed)
	Default setting:	\$80001
	Attributes:	
	Display type:	4 (list field)
	Position of input/output field:	
	Distance from left:	200
	Width:	340
	Height:	60
	Colors:	
	Foreground color:	6 (blue)
	Background color:	10 (white)

7.7 Example 5: Image display

Example 5

Displaying an image instead of a short text: The size and position of the image is defined under "Position of input/output field (left, top, width, height)".

DEF VAR6= (V///,"\\image1.png" ////160,40,50,50)		
	Variable type:	VARIANT
	Texts:	
	Short text:	image1.png
	Position of input/output field:	
	Distance from left:	160
	Distance from the top:	40
	Width:	50
	Height:	50

7.8 Example 6: Progress bar

The progress bar is a special display type of the input/output field and is designed for display without input.

Basically there are two progress bar types:

1. Progress bars with up to two color changes, e.g. for temperature or utilization display (see example 6a)
2. Progress bars to display progress (no color change) in the Operate style (see example 6b)

Example 6a

Progress bar with two color changes:



Figure 7-1 Progress bar with two color changes

DEF PROGGY0 = (R/0,150,50,100//DT1,DO0//"\$R[10]"//,,150/3,4,,,,,9,7)		
Variable type:		REAL
Limits / toggle field:		
	MIN:	0
	MAX:	150
	Signal value SVAL1:	50
	Signal value SVAL2:	100
Attributes:		
	Display mode DT:	1 (progress bar)
	Display option DO:	0 (from left to right (default))
System or user variable:		\$R[10]
Position of input/output field:		
	Width:	150
Colors:		
	Foreground color:	3 (dark green)
	Background color:	4 (light gray)
	Signal color SC1:	9 (yellow)
	Signal color SC2:	7 (red)

To use a progress bar with color change, the display mode DT (DisplayType) must be set to 1.

The orientation of the progress bar is determined via the attribute display option DO (DisplayOption):

- 0: From left to right (default)
- 1: From right to left
- 2: From bottom to top
- 3: From top to bottom

A MIN and a MAX value must be specified for the display of the progress bar (in the example MIN: 0, MAX: 150).

Depending on the current value of the variable PROGGY0, this setting already displays a progress bar with the foreground color 3 (= dark green) and the background color 4 (= light gray).

7.8 Example 6: Progress bar

Optionally, one or two signal values SVAL1 and SVAL2 (limit parameters) can be defined (in the example SVAL1: 50 and SVAL2: 100). With these signal values, the foreground color of the progress bar changes. The appropriate signal colors are specified via parameters SC1 and SC2 (in the above example SC1: 9 (= yellow) and SC2: 7 (=red)).

The following rule applies when specifying limit values for the progress display:

$MIN < SVAL1 < SVAL2 < MAX$.

Example 6b

Progress bar without color change:



Figure 7-2 Progress bar

DEF PROGGY0 = (R/0,150//DT2,DO0//"\$R[10]"//,,150/6,10)		
Variable type:		REAL
Limits / toggle field:		
	MIN:	0
	MAX:	150
Attributes:		
	Display type DT:	2 (progress bar)
	Display option DO:	0 (from left to right (default))
System or user variable:		\$R[10]
Position of input/output field:		
	Width:	150
Colors:		
	Foreground color:	6 (blue)
	Background color:	10 (white)

To use a progress bar without color change, the display mode DT (DisplayType) must be set to 2.

The orientation of the progress bar is determined via the attribute display option DO (DisplayOption) (see description for example 6a).

A MIN and a MAX value must be specified for the display of the progress bar (in the example MIN: 0, MAX: 150).

Depending on the current value of the variable PROGGY0, this setting displays a progress bar with the foreground color 6 (= blue) and the background color 10 (= white).

7.9 Example 7: Password input mode (asterisk)

Example 7

To implement a field with hidden input, e.g. to enter a password, then display mode DT must be set to 5. Asterisks are then displayed instead of the entered characters.



Figure 7-3 Password input mode (asterisk)

DEF VAR_SET_PWD=(S/I//DT5)		
	Variable type:	STRING
	Default setting:	Empty string
	Attributes:	
	Display mode DT:	5 (password input mode)

7.10 Variable parameters

Parameters - overview

The following overview provides a brief explanation of the variable parameters. Subsequent chapters contain a more detailed description.

Parameter	Description
Variable type (Page 97)	The variable type must be specified.
	R[x]: REAL (+ digit for the decimal place) I: INTEGER S[x]: STRING (+ digit for string length) C: CHARACTER (individual character) B: BOOL V: VARIANT

7.10 Variable parameters

Parameter	Description	
Limits (Page 86)	Limit value MIN, limit value MAX Default setting: Empty The limit values are separated by a comma. Limits can be specified for types I, C and R in decimal formats or as characters in the form "A", "F". Optionally, two signal colors SC1 and SC2 can be configured for the display of a progress bar with color change (variable attribute DT = 1) which are displayed as the respective foreground color of the bar when the signal value SVAL1 or SVAL2 is exceeded. The signal values are specified as integer values. See application example for Progress bar (Page 88).	
Pre-assignment (Page 101)	If no default setting has been configured and no system or user variable has been assigned to the variable, the first element of the toggle field is assigned. If no toggle field has been defined, there is no default setting, which means the status of the variable is "not calculated". Default setting: No default	
Toggle field (Page 100)	List with predetermined entries in the IO field: The list is initiated by a *; the entries are separated by a comma. The entries can be assigned a value. For the toggle field, the entry for the limit is interpreted as a list. If only one * is entered, a variable toggle field is created. Default setting: None	
Texts (Page 85)	The sequence is specified. Instead of a short text, an image can also be displayed. Default setting: Empty	
	Long text: Short text: Graphic text: Unit text: Tooltip	Text in the display line Name of the dialog element Text refers to the terms in the graphics Unit of the dialog element Serves as brief information in a screen configuration for the display and toggle fields. The information is configured via plain text and language text ID.

Parameter	Description
Attributes (Page 86)	The attributes influence the following properties: • Display mode • Display option • Update rate • Toggle symbol • Tooltip • Input mode • Access level • Alignment of short text • Font size • Limits The attributes are separated by commas and appear in any order. A definition can be made for each component.
Display mode	dt0: Standard (input/output field or toggle field) (default) dt1: Progress bar with color change dt2: Progress bar without color change in the Operate style dt4: List field dt5: Password input mode (asterisk)
Display option	Particularly, e.g. for the display modes dt1 and dt2 (progress bars), a display option may also have to be configured in combination. do0: From left to right (default) do1: From right to left do2: From bottom to top do3: From top to bottom
Update rate	The attribute UR (update rate) controls the update of the display and therefore the processing of the associated, configured CHANGE block of variables or grid columns. Depending on the configuration, the CPU load can be drastically reduced and therefore shorter response times achieved on the user interface. ur0: SLCap::standardUpdateRate() (currently = 200 ms, default value) ur1: 50 ms ur2: 100 ms ur3: 200 ms ur4: 500 ms ur5: 1000 ms ur6: 2000 ms ur7: 5000 ms ur8: 10000 ms
Toggle symbol	tg0: Toggle symbol off (default) tg1: Toggle symbol on If the attribute TG is set to 1, the toggle symbol also appears in the tooltip of the input field. Example: DEF OFFS = (R//123.456/,,,,"My ToolTip"/TG1)

Parameter	Description
	Tooltip The tooltip text can also be changed during runtime via the variable property "TT". Example: <pre>PRESS (VS1) MyVar.TT = "My new ToolTip" END_PRESS or DEF MyVar=(R///,,"My ToolTip-text")</pre>
	Input mode wr0: IO field invisible, short text visible wr1: Read (no focus possible for input) wr2: Read and write (line appears in white) wr3: wr1 with focus wr4: All variable elements invisible, no focus possible wr5: The value entered is saved immediately on every keystroke (in contrast to wr2, where it is only saved when the field is exited or RETURN is pressed). Default setting: wr2
	Access level Empty: Can always be written ac0...ac7: Protection levels If the access level is not adequate, then the first line is displayed in gray, default setting: ac7
	Alignment of short text al0: Left-justified al1: Right-justified al2: Centered Default setting: al0
	Font size fs1: Default font size (8 pt.) fs2: Double font size Default setting: fs1 The clearances between the lines is defined. With the default font size, 16 lines will fit into the dialog. Graphics and unit text can only be configured in the default font size.
	Limits Consequently, it is possible to check whether the values of the variable are within the MIN and MAX limits specified. Default setting: Determined by specified limits li0: No check li1: Check with respect to min. li2: Check with respect to max. li3: Check with respect to min. and max.
	Behavior when opening cb attributes specified for a variable in a variables definition take priority over the cb default setting in the dialog definition. Multiple attributes are separated by commas (see also AUTOHOTSPOT).
	Calling the CHANGE method CB0: The CHANGE method is triggered when the screen is displayed if the variable has a valid value at this time (e.g. through default setting or NC/PLC variable).

Parameter	Description	
		CB1: The CHANGE method is not explicitly triggered when the screen is displayed. If the variable has a configured NC/PLC variable, then the CHANGE method is of course still called.
	Empty Input (EI)	The variable attribute "EI" (= Empty Input) can be used to specify how the input field is to respond if an empty string is entered. EI0: Standard, i.e. empty inputs into the input field are accepted. EI1: Empty inputs lead to an error status for the input field, and the previous value is set again (Undo).
Help display (Page 85)	Help display file:	Name of the png file Default setting: Empty
	The name of the Help display file appears in double quotation marks. The display appears automatically (instead of the previous graphic) if the cursor is positioned on this variable.	
System or user variable (Page 87)	System or user data from the NC/PLC can be assigned to the variable. The system or user variable appears in double quotation marks. Reference: List Manual System Variables, /PGAs//	
Position of short text (Page 102)	Position of short text (distance from left, distance from top, width) The positions are entered in pixels and relate to the upper left-hand corner of the main body of the dialog. The entries are separated by commas.	
Position of input/output field (Page 102)	Position of input/output field (distance from left, distance from top, width, height) The positions are entered in pixels and relate to the upper left-hand corner of the main body of the dialog. The entries are separated by commas. If this position changes, the positions of the short text, graphic text and unit text also change.	
Colors (Page 85)	Foreground and background colors for input/output fields, short texts, graphic texts, unit texts and signal colors for progress bars: The colors are separated by a comma. For specification of the color, see Chapter AUTOHOTSPOT. Default setting for input/output field: Foreground color: Black, background color: White The default colors of the input/output field depend on the "wr" write mode: Default setting for short text, graphic text, unit text: Foreground color: Black, background color: Transparent.	
	Optionally, two signal colors SC1 and SC2 can be configured for the display of a progress bar with color change (variable attribute DT = 1) which are displayed as the respective foreground color of the bar when the signal value SVAL1 or SVAL2 is exceeded. See application example for Progress bar (Page 88).	
	The colors are expected in the following order in the variables definition: 1. Foreground color of the input/output field: FC 2. Background color of the input/output field: BC 3. Foreground color of the short text: FC_ST 4. Background color of the short text: BC_ST 5. Foreground color of the graphic text: FC_GT 6. Background color of the graphic text: BC_GT 7. Foreground color of the unit text: FC_UT 8. Background color of the unit text: BC_UT 9. Signal color 1 10. Signal color 2	

7.10 Variable parameters

Parameter	Description
Online help file	The name of the online help file appears in double quotation marks.
I/O field with integrated unit selection	You can use the input/output fields with integrated unit selection to toggle between different units. If the cursor is moved to the input field, the integrated unit selection is highlighted (focus does not have to be explicitly placed on it). A tooltip with a toggle symbol is also displayed with the appropriate reference to this functionality. Examples: <pre>DEF VarEdit=(R/////////200,,100// "VarTgl") VarTgl=(S/*0="mm",1="inch"/0//WR2////302,,40)</pre> or <pre>DEF VarEdit_2={TYP="R", VAL=1.234, X=200, W=100, LINK_TGL="vartgl_2"}, VARTgl_2={TYP="S", TGL="* 0="mm", 1="inch",WR=2, X=302, W=40}</pre>

Variable: Changing properties

A new value is assigned to the variables in the notation Identifier.Property = Value when changing. The expression to the right of the equality sign is evaluated and assigned to the variable or variable property.

Identifier. ac = Access level	(ac: access level)
Identifier. al = Text alignment	(al: alignment)
Identifier. bc = Background color of the input/output field	(bc: back color)
Identifier. bc_gt = Background color of the graphic text	(bc: back color) (gt: graphic text)
Identifier. bc_st = Background color of the short text	(bc: back color) (st: short text)
Identifier. bc_ut = Background color of the unit text	(bc: back color) (ut: unit text)
Identifier. do = Display option	(do: display option)
Identifier. dt = Display mode	(dt: display type)
Identifier. fc = Foreground color of the input/output field	(fc: front color)
Identifier. fc_gt = Foreground color of the graphic text	(fc: front color) (gt: graphic text)
Identifier. fc_st = Foreground color of the short text	(fc: front color) (st: short text)
Identifier. fc_ut = Foreground color of the unit text	(fc: front color) (ut: unit text)
Identifier. fs = Font size	(fs: font size)
Identifier. gt = Graphic text	(gt: graphic text)
Identifier. hlp = Help display	(hlp: help)
Identifier. li = Limit	(li: limit)
Identifier. lt = Long text	(lt: long text)
Identifier. max = MAX limits	(max: maximum)
Identifier. min = MIN limits	(min: minimum)

Identifier. sc = Signal color	(sc: signal color)
Identifier. st = Short text	(st: short text)
Identifier. tg = Toggle symbol	(tg: toggle)
Identifier. tt = Tooltip	(tt: tooltip)
Identifier. typ = Variable type	(typ: type)
Identifier. ur = Update rate	(ur: update rate)
Identifier. ut = Unit text	(ut: unit text)
Identifier. val = Variable value	(val: value)
Identifier. var = System or user variable	(var: variable)
Identifier. vld = Variable status	(vld: validation)
Identifier. wr = Input mode	(wr: write)

See also

Extended configuration syntax (Page 45)

7.11 Details on the variable type

Variable type INTEGER

The following extensions for determining the display in the input/output field and the memory utilization are possible for the "INTEGER" type:

2nd character in the extension data type

Representation format	
B	Binary
D	Decimal signed
H	Hexadecimal
Not specified	Decimal signed

3rd and/or 4th character in the extension data type

Memory utilization	
B	Byte
W	Word
D	Doubleword
BU	Byte, unsigned
WU	Word, unsigned
DU	Double word, unsigned

Sequence of characters for the INTEGER data type

1. "I" Basic INTEGER designation
2. Representation format
3. Memory utilization
4. "U" Unsigned

Valid INTEGER type specifications:	
IB	Integer variable 32 bits in binary notation
IBD	Integer variable 32 bits in binary notation
IBW	Integer variable 16 bits in binary notation
IBB	Integer variable 8 bits in binary notation
I	Integer variable 32 bits in decimal notation signed
IDD	Integer variable 32 bits in decimal notation signed
IDW	Integer variable 16 bits in decimal notation signed
IDB	Integer variable 8 bits in decimal notation signed
IDDU	Integer variable 32 bits in decimal notation unsigned
IDWU	Integer variable 16 bits in decimal notation unsigned
IDBU	Integer variable 8 bits in decimal notation unsigned
IH	Integer variable 32 bits in hexadecimal notation
IHDU	Integer variable 32 bits in hexadecimal notation
IHWU	Integer variable 16 bits in hexadecimal notation
IHBU	Integer variable 8 bits in hexadecimal notation

Variable type VARIANT

The VARIANT variable type is determined by the data type of the last value assignment. If the assigned or entered value starts with '-', '+', '.' or a number ('0'-'9'), then the value is interpreted as numeric. In all other cases as a string.

It can be scanned using the ISNUM or ISSTR function. The VARIANT type is mainly suited to the purpose of writing either variable names or numerical values to the NC code.

Programming

The data type of variables can be checked:

Syntax:	ISNUM (VAR)	
Parameters:	VAR	Name of the variable whose data type is to be checked.
	FALSE = TRUE =	The result of the scan can be: not a numerical variable (data type = STRING) numerical variable (data type = REAL)

Syntax:	ISSTR (VAR)	
Parameters:	VAR	Name of the variable whose data type is to be checked.
	FALSE = TRUE =	The result of the scan can be: numerical variable (data type = REAL) not a numerical variable (data type = STRING)
Example:	<pre>IF ISNUM(VAR1) == TRUE IF ISSTR(REG[4]+2) == TRUE</pre>	

The display mode of variables can be changed:

- For INTEGER, the display type can be changed.

B	Binary
D	Decimal signed
H	Hexadecimal
unsigned	
With the addition of U for Unsigned	

- For REAL data types, only the number of places after the decimal point can be changed. Changing the type is illegal and generates an error message in the "easyscreen_log.txt" file.
Example:

```
Var1.typ = "IBW"
Var2.typ = "R3"
```

Number formats

Numbers can be represented in either binary, decimal, hexadecimal or exponential notation:

Binary	B01110110
Decimal	123.45
Hexadecimal	HF1A9
Exponential	-1.23EX-3
Examples:	
	VAR1 = HF1A9
	REG[0] = B01110110
	DEF VAR7 = (R/-1.23EX-3)

Note

When codes are generated with the "GC" function, only numerical values in decimal or exponential notation are evaluated, but **not** those in binary or hexadecimal notation.

See also

Variable parameters (Page 91)

7.12 Details on the toggle field

Description

The toggle field extension function displays texts (entries in toggle field) as a function of NC/PLC variables. A variable, which makes use of a toggle field extension, is read-only. The list of the toggle field is opened by pressing the ENTER key.

Programming

Syntax:	DEF VAR1=(IB/+ \$85000/15///"DB90.DBB5") or DEF VAR_TGL = (S/* "Hello", "Run", "MyScreens"/"Run")	
Description:	When the dialog is opened, the content of text number \$85015 is displayed in the IO field. Default value 15 is entered in system variable DB90.DBB5. If the value saved in system variable DB90.DBB5 changes, the displayed text number \$(85000 + <DB90.DBB5>) is recalculated in response to every change.	
Parameter:	Variable type	Type of variables specified in the system or user variable.
	Text number	Number (basis) of the language-specific text valid as the basis number.
	System or user variable	System or user variable (offset) via which the final text number (basis + offset) is displayed.

Toggle-field-dependent displays

The toggle field is overlaid with graphics, which change depending on the value of the memory byte. If the value of the memory byte is 1, "image1.png" will appear. If it is 2, "image2.png" will appear.

```
DEF VAR1=(IDB/*1="\image1.png", 2="\image2.png"//,$85000/wr1//"MB[130]"//160,40,50,50)
```

The size and position of the image is defined under "Position of IO field (left, top, width, height)".

Virtual toggle key

There is no list for toggle fields without configured list, e.g. `DEF NoTglList=(R/*)`. The next element is not generated until the toggle key is actuated or the associated `CHANGE()` method of the corresponding variable run through.

For this case, a small virtual keyboard (comprising only a toggle key) is displayed on the right next to the variable toggle field for operation with a touch panel.

The display of the virtual toggle key can also be forced via the following entry in the configuration file "slguiconfig.ini" irrespective of a touch panel.

```
[VirtualKeyboard]
```

```
; Forces easyscreen virtual toggle keyboard function
ForceEasyscreenVirtualToggleKey = true
```

See also

Variable parameters (Page 91)

7.13 Details on the default setting

Overview

A variable can assume various states depending on whether a default value, or a system or user variable, or both, is assigned to the variable field (input/output field or toggle field), (not calculated: toggling is only possible if a valid value has been assigned to the variable).

Scope of the default settings

Condition			Reaction of field type
Field type	Default setting	System or user variable	
I/O field	Yes	Yes	Write default value to system or user variable
	No	Yes	Use system or user variable as default value
	Fault	Yes	Not calculated, system or user variable is not written/used.
	Yes	No	Default setting
	No	No	Not calculated
	Fault	No	Not calculated
	Yes	Fault	Not calculated
	No	Fault	Not calculated
	Fault	Fault	Not calculated
Toggle	Yes	Yes	Write default value to system or user variable
	No	Yes	Use system or user variable as default value
	Fault	Yes	Not calculated, system or user variable not written/used
	Yes	No	Default setting
	No	No	Default = first toggle field element
	Fault	No	Not calculated
	Yes	Fault	Not calculated
	No	Fault	Not calculated
	Fault	Fault	Not calculated

See also

Variable parameters (Page 91)

7.14 Details on the position of the short text, position of the input/output field

Overview

The short text and graphic text, as well as the input/output field and unit text, are each treated like a unit, i.e., position settings for short text apply to the graphic text and data for the input/output field and to unit text.

Programming

The configured position entry overwrites the default value, i.e., only one value can be changed. If no position settings have been configured for subsequent screen form elements, then the position settings for the preceding screen form element are applied.

The default setting is used if positions are not specified for any of the dialog elements. The column width for the short text and input-output field is calculated as standard for each line from the number of columns and maximum line width, i.e. $\text{column width} = \text{maximum line width} / \text{number of columns}$.

The width of the graphics and unit text is predefined and optimized to suit the requirements of programming support. If graphics or unit text has been configured, the width of the short text or I/O field is reduced accordingly.

The order of short text and I/O field can be reversed by position settings.

Distance between the input/output field and unit field and width of the unit field

You can configure the distance between an input/output field and a unit field as well as the width of the unit field.

In the definition line, in the section for the input/output position, enter the distance from the input/output field to the unit field, separated by a comma (e.g. 7 pixels) and/or the width of the unit field (e.g. 60 pixels):

```
DEF VarDT=(R3//0.000/,"DT",,"s"///0,,24/39,,71,,7,60)
```

Or:

```
DEF VarDT={TYP="R3", VAL="0.000", ST="DT", UT="s", TXT_X=0,  
TXT_W=24, X=39, W=71, UT_DX=7, UT_W=60}
```

In this case, the distance between the input/output field/unit field and/or the width of the unit field have/has been configured and the following points should be taken into account:

- The configured width of the input/output field does **not** include the fixed width of the unit field (this is fixed at 50 pixels). This means that you directly configure the width of the input/output field.
- A 50 pixel width applies as default if a width is not configured for the unit field.
- 0 pixels applies as default if a distance is not configured between the input/output field / unit field.

Special feature regarding the associated toggle field

Requirements:

- An associated toggle field is configured for a variable,
- For the variable, a distance is configured between the input/output field and unit field and/or a width for the unit field, and
- The variable has no unit text.

In this particular case, the associated toggle field is positioned at the configured position of the unit field of the variable.

A position possibly configured for the input/output component of the associated toggle field is ignored.

Example

In the following example, the associated toggle field **F_Unit** is automatically set with a distance of **7 pixels** to the input/output field of variable **VarF**, and with a width of **59 pixels**.

```
DEF VarF=(R//0.0/,"F",,,///0,,24/39,,85,,7,59///"F_Unit"), F_Unit =
(I/*3="mm/min", 1="mm/U"/3// ///181,,155)
```

See also

Variable parameters (Page 91)

7.15 Use of strings

Strings

Strings can be used as part of the configuration. These allow text to be displayed dynamically or different texts to be chained for the purpose of code generation.

Rules

The following rules must be observed with regard to string variables:

- Logic operations are processed from left to right.
- Nested expressions are solved from the inside outwards.
- No distinction is made between uppercase and lowercase type.
- String variables are generally displayed left justified.

Strings can be deleted simply by assigning a blank string.

Strings can be appended after the equality sign using the operator "<<". Quotation marks (") in the string are represented by two successive quotation mark symbols. Strings can be checked for equality in IF instructions.

Example

Default settings for the following examples:

```
VAR1.VAL = "This is an"
```

```
VAR8.VAL = 4
```

```
VAR14.VAL = 15
```

```
VAR2.VAL = "Error"
```

```
$85001 = "This is an"
```

```
$85002 = "Alarm text"
```

Editing strings:

- Chaining of strings:
VAR12.VAL = VAR1 << " Error." ;Result: "This is an error"
- Deleting a variable:
VAR10.VAL = "" ;Result: Blank string
- Setting a variable with a text variable:
VAR11.VAL = VAR1.VAL ;Result: "This is an"
- Data type matching:
VAR13.VAL = "This is the " << (VAR14 - VAR8) << ". error"
;Result: "This is the 11th error"
- Treatment of numerical values:
VAR13.VAL = "Error" << VAR14.VAL << ": " << \$85001 << \$85002
;Result: "Error 15: "This is an alarm text"
IF VAR15 == "Error" ;Strings in IF statement
VAR16 = 18.1234
;Result: VAR16 equals 18.1234,
;if VAR15 equals "Error".
ENDIF

- Quotation marks within a string:

```
VAR2="Hello, this is a " Test"  
;Result: Hello, this is a " Test"
```
- System or user-variable strings dependent on variable content:

```
VAR2.Var = "$R[" << VAR8 << "]" ;Result: $R[4]
```

See also

STRING functions (Page 177)

7.16 CURPOS variable

Description

The CURPOS variable calls or manipulates the position of the cursor in the active input field of the current dialog. The variable shows how many characters are in front of the cursor. If the cursor is located at the start of the input field, then CURPOS assumes the value of 0. If the value of CURPOS is changed, then the cursor is positioned at the appropriate location in the input field.

In order to be able to respond to changes in the variable value, it is possible to monitor for changes using a CHANGE method. If the value of CURPOS changes, then a jump is made to the CHANGE method and the instructions contained there are executed.

7.17 CURVER variable

Description

The CURVER (CURrent VERsion) property allows the programming to be adapted in order to handle different versions. The CURVER variable is read-only.

Note

Even if previously recompiled with an older version, the code is automatically generated with the most recent version. The "GC" command always generates the most recent version. An additional identifier indicating the generated version is inserted in the user comment of the generated code in versions > 0.

Rules

The most recent dialog with all its variables is always displayed.

- Variables used previously may not be changed.
- New variables are inserted in the existing (cycle) programming in arbitrary order.

- It is not permissible to delete variables from a dialog from one version to the next.
- The dialog must contain all variables of all versions.

Example

```
(IF CURVER==1 ...) ; When the code is recompiled, CURVER is automati-
                    cally assigned the version of the recompiled
                    code.
```

7.18 ENTRY variable

Description

The ENTRY variable can be used to check by what method a dialog has been called.

Programming

Syntax:	ENTRY	
Description:	The ENTRY variable is a read only variable.	
Return Value:		The result of the scan can be:
	0 =	No programming support
	1 =	Start of a screen via softkey; no code has been generated yet (default as configured)
	2 =	Start of a screen via softkey; code has been generated (default from the code generated last by this screen)
	3 =	Recompilation with user comment (# lines)
	4 =	Code_type = 0: NC code with user comment (# lines)
	5 =	Code_type = 1: NC code without user comment (# lines)

Example

```
IF ENTRY == 0
  DLGL ("The dialog was not called under programming")
ELSE
  DLGL ("The dialog was called under programming")
ENDIF
```

7.19 ERR variable

Description

Variable ERR checks whether the preceding line has been executed correctly.

Programming

Syntax:	ERR	
Description:	The ERR variable is read-only.	
Return value:		The result of the scan can be:
	FALSE =	previous line was executed error-free
	TRUE =	previous line was not executed error-free

Example

```

VAR4 = Thread[VAR1,"CDM",3]           ; Output value from array
IF ERR == TRUE                         ; Query whether the value has been found in
                                     the array
    VAR5 = "Error accessing array"

                                     ; If the value has not been found in the ar-
                                     ray, the value "Error accessing array" is as-
                                     signed to the variables.
ELSE
    VAR5 = "All OK"                   ; If the value has been found in the array,
                                     the value "All OK" is assigned to the varia-
                                     bles.
ENDIF

```

7.20 FILE_ERR variable

Description

Variable FILE_ERR can be used to check whether the preceding GC or CP command has been executed correctly.

Programming

Syntax:	FILE_ERR	
Description:	The FILE_ERR variable is read-only.	

Return value:		Possible results are:
	0 =	Operation okay
	1 =	Drive/path not available
	2 =	Path/file access error
	3 =	Drive not ready
	4 =	Incorrect file name
	5 =	File is already open
	6 =	Access denied
	7 =	Target path not available or not permitted
	8 =	Copy source same as target
	10 =	Internal error: FILE_ERR = 10 means that the error cannot be classified in the other categories.

Example

```
CP("D:\source.mpf","E:\target.mpf")
```

```

; Copy from source.mpf to E:\target.mpf
; Query whether error has occurred
; Query specific error numbers and
; output associated error text

IF FILE_ERR > 0
    IF FILE_ERR == 1
        VAR5 = "Drive/path not available"
    ELSE
        IF FILE_ERR == 2
            VAR5 = "Path/file access error"
        ELSE
            IF FILE_ERR == 3
                VAR5 = "incorrect file name"
            ENDIF
        ENDIF
    ENDIF
ELSE
    VAR5 = "All OK"
; If no errors have occurred in CP
; (or GC), "All OK" is output
ENDIF
```

7.21 FOC variable

Description

With the variable FOC, the input focus (current active input/output field) is controlled in a dialog. The reaction of the cursor left, right, up, down as well as PGUP, PGDN are predefined.

Note

The FOC function must not be initiated as a result of a navigation event. The cursor position may only be changed in softkey PRESS methods, CHANGE methods, etc.

The FOC function cannot be applied to variables with input mode $wr = 0$ and $wr = 4$ or to Help variables.

Programming

Syntax:	FOC	
Description:	The variable can be read and written.	
Return value:	Read	The result is the name of the variable to which the FOC function has been applied.
	Write	It is possible to assign either a string or a numerical value. A string is interpreted as a variable name and a numerical value as a variable index.

Example

```

IF FOC == "Var1"                ; Read focus
    REG[1] = Var1
ELSE
    REG[1] = Var2
ENDIF

FOC = "Var1"                    ; The input focus is assigned to variable 1.
FOC = 3                        ; The input focus is assigned to the 3rd dialog ele-
                              ; ment with WR ≥ 2.

```

See also

FOCUS (Page 123)

7.22 Variable S_ALEVEL

Description

The current access level can be queried in the configuration with the screen property S_ALEVEL.

Programming

Syntax:	S_ALEVEL
Description:	Query of the current access level
Return value:	0: System 1: Manufacturer 2: Service 3: User 4: Key switch 3 5: Key switch 2 6: Key switch 1 7: Key switch 0

Example

```
REG[0] = S_ALEVEL
```

See also

ACCESSLEVEL (Page 120)

7.23 S_CHAN variable

Description

The S_CHAN variable determines the number of the current channel for display or evaluation purposes.

Programming

Syntax:	S_CHAN
Description:	Query of the current channel number
Return value:	Channel number

Example

```
REG[0] = S_CHAN
```

See also

CHANNEL (Page 122)

7.24 Variable S_CONTROL

Description

The current control name can be queried in the configuration with the screen property S_CONTROL.

Programming

Syntax:	S_CONTROL
Description:	Query of the current control name
Return value:	The control name is the section name in the "mmc.ini"

Example

```
REG[0] = S_CONTROL
```

See also

CONTROL (Page 122)

7.25 Variable S_LANG

Description

The current language can be queried in the configuration with the screen property S_LANG.

Programming

Syntax:	S_LANG
Description:	Query of the current language
Return value:	Language code from resources.xml, e.g. "deu", "eng", etc.

Example

```
REG[0] = S_LANG
```

See also

LANGUAGE (Page 123)

7.26 Variable S_NCCODEREADONLY

Description

The screen property S_NCCODEREADONLY is only relevant when a cycle is recompiled in the editor with a "Run MyScreens" dialog. S_NCCODEREADONLY determines whether a recompiled NC code from the editor can be changed or not.

The following applies for the return value:

- TRUE: The recompiled NC code from the editor can be changed
- FALSE: The recompiled NC code from the editor cannot be changed (read-only), because, for example, it is already in the preprocessing (= TRUE).

7.27 Variables S_RESX and S_RESY

Description

The current resolution or its X and Y component can be queried in the configuration with the screen properties S_RESX and S_RESY.

Example

```
REG[0] = S_RESY
```

See also

RESOLUTION (Page 128)

Programming commands

8.1 Operators

Overview

The following operators can be used when programming:

- Mathematical operators
- Relational operators
- Logic (Boolean) operators
- Bit operators
- Trigonometric functions

8.1.1 Mathematical operators

Overview

Mathematical operators	Designation
+	Addition
-	Subtraction
*	Multiplication
/	Division
MOD	Modulo operation
()	Parentheses
AND	AND operator
OR	OR operator
NOT	NOT operator
ROUND	Round off numbers with decimal places

Example: `VAR1.VAL = 45 * (4 + 3)`

ROUND

The ROUND operator is used to round off numbers with up to 12 decimal places during execution of a dialog configuration. The variable fields cannot accept the decimal places in the display.

8.1 Operators

Use

ROUND is controlled by the user with two parameters:

```
VAR1 = 5.2328543
```

```
VAR2 = ROUND ( VAR1, 4 )
```

Result: VAR2 = 5.2339

VAR1 contains the number to be rounded. The parameter "4" indicates the number of decimal places in the result, which is placed in VAR2.

Trigonometric functions

Trigonometric functions	Designation
SIN(x)	Sine of x
COS(x)	Cosine of x
TAN(x)	Tangent of x
ATAN(x, y)	Arc tangent of x/y
SQRT(x)	Square root of x
ABS(x)	Absolute value of x
SDEG(x)	Conversion to degrees
SRAD(x)	Conversion to radian
CALC_ASIN(x)	Arc sine of x
CALC_ACOS(x)	Arc cosine of x

Note

The functions operate with radian measure. The functions SDEG() and SRAD() can be used for conversion.

Example: VAR1.VAL = SQRT(2)

Mathematical functions

Mathematical functions	Designation
CALC_CEIL(x)	Determines the next highest integer of x (round up)
CALC_FLOOR(x)	Determines the next lowest integer of x (round down)
CALC_LOG(x)	Determines the (natural) logarithm for the base e of x
CALC_LOG10(x)	Determines the logarithm for the base 10 of x
CALC_POW(x, y)	Determines x to the power of y
CALC_MIN(x, y)	Determines the lower number of x and y
CALC_MAX(x, y)	Determines the higher number of x and y

Random function: Random number

Syntax:	RANDOM (lower limit value, upper limit value)	
Description:	The RANDOM function returns a pseudo random number in a specified range.	
Parameters:	Lower limit value	Lower limit value $\geq$ -32767, Lower limit value $<$ upper limit value
	Upper limit value	Upper limit value $\leq$ 32767

Example

REG[0] = RANDOM(-10,10) ; Possible result = -3	
--	--

Constants

Constants	
PI	3.14159265358979323846
FALSE	0
TRUE	1

Example: VAR1.VAL = PI

Relational operators

Relational operators	
==	Equal to
<>	Not equal to
>	Greater than
<	Less than
>=	Greater than or equal to
<=	Less than or equal to

Example:

```
IF VAR1.VAL == 1
    VAR2.VAL = TRUE
ENDIF
```

8.1 Operators

Conditions

The nesting depth is unlimited.

Condition with one command:	IF
	...
	ENDIF
Condition with two commands:	IF
	...
	ELSE
	...
	ENDIF

8.1.2 Bit operators

Overview

Bit operators	Designation
BOR	Bit-serial OR
BXOR	Bit-serial XOR
BAND	Bit-serial AND
BNOT	Bit-serial NOT
SHL	Shift bits to left
SHR	Shift bits to right

SHL operator

Bits are shifted to the left using the SHL (SHIFT LEFT) operator. You can specify both the value to be shifted and the number of shift increments directly or via a variable. If the limit of the data format is reached, the bits are shifted beyond the limit without displaying an error message.

Use

Syntax:	variable = value SHL increment	
Description:	Shift Left	
Parameters:	value	value to be shifted
	increment	number of shift increments

Example

```

PRESS (VS1)
  VAR01 = 16 SHL 2      ; Result = 64
  
```

```

VAR02 = VAR02 SHL VAR04      ; Convert content of VAR02 to 32-bit unsigned
                              , and shift content to left by number of bits specified
                              in VAR04. Then convert 32-bit value back to format of
                              variable VAR02.

END_PRESS

```

SHR operator

Bits are shifted to the RIGHT using the SHR (SHIFT RIGHT) function. You can specify both the value to be shifted and the number of shift increments directly or via a variable. If the limit of the data format is reached, the bits are shifted beyond the limit without displaying an error message.

Use

Syntax:	variable = value SHR increment	
Description:	Shift Right	
Parameters:	value	value to be shifted
	increment	number of shift increments

Example

```

PRESS (VS1)
  VAR01 = 16 SHR 2           ; Result = 4
  VAR02 = VAR02 SHR VAR04    ; Convert content of VAR02 to 32-bit unsigned
                              , and shift content to right by number of bits
                              specified in VAR04. Then convert 32-bit value back
                              to format of variable VAR02.

END_PRESS

```

8.2 Methods

Overview

Various types of event (exit input field, actuate softkey) can initiate specific actions in dialogs and dialog-dependent softkey menus (softkey menus that are called from a newly configured dialog). These actions are configured in methods.

The following table shows the basic principle used to program a method:

Definition block	Comment	Section reference
PRESS (HS1)	;Method start identifier	
LM... LS...	;Functions	See Chapter Functions (Page 131)

Definition block	Comment	Section reference
Var1.st = ...	;Changing properties	see Section Defining softkey menus (Page 63) and Section Defining dialog properties (Page 51).
Var2 = Var3 + Var4 ... EXIT	;Calculation with variables	See Chapter Defining variables (Page 83)
END_PRESS	;Method end identifier	

8.2.1 ACCESSLEVEL

Description

The ACCESSLEVEL method is run through when the current access level has changed for an opened screen.

Programming

Syntax:	ACCESSLEVEL <instructions> END_ACCESSLEVEL
Description:	Access level
Parameters:	- None -

See also

Variable S_ALEVEL (Page 110)

8.2.2 CHANGE

Description

CHANGE methods are executed when a variable value changes. This means that variable calculations that are performed as soon as a variable value changes are configured within a CHANGE method.

There are two types of CHANGE method, i.e., element-specific and global:

- The **element-specific CHANGE method** is executed if the value of a specified variable changes. If a system or user variable is assigned to a variable, cyclic updating of the variable value can be configured in a CHANGE method.
- The **global CHANGE method** is executed if the value of any variable changes and no element-specific CHANGE method has been configured.

"Element-specific" programming

Syntax:	CHANGE(identifier) ... END_CHANGE	
Description:	Changes the value of a specific variable	
Parameters:	Identifier	Name of the variable

Example

```

DEF VAR1=(I////////"DB20.DBB1")          ; A system variable is assigned to Var1
CHANGE (VAR1)
  IF VAR1.Val <> 1
    VAR1.st="Tool OK!"                    ; If the value of the system variable ≠ 1, the
                                          short text of the variable states: Tool OK!

    otto=1
  ELSE
    VAR1.st="Attention: Error!"            ; If the value of the system variable = 1, the
                                          short text of the variable states: Attention:
                                          Error!

    otto=2
  ENDIF
  VAR2.Var=2
END_CHANGE

```

"Global" programming

Syntax:	CHANGE() ... END_CHANGE
Description:	Changes any variable value
Parameters:	- None -

Example

```

CHANGE ()
  EXIT                                  ; If any of the variable values change, the di-
                                          alog will be terminated.
END_CHANGE

```

8.2.3 CHANNEL

Description

The CHANNEL method is run through when the current channel has changed for an opened screen, i.e. a channel switchover has been performed.

Programming

Syntax:	CHANNEL <instructions> END_CHANNEL
Description:	Channel switchover
Parameters:	- None -

See also

S_CHAN variable (Page 110)

8.2.4 CONTROL

Description

The CONTROL method is run through when the current control has changed for an opened screen, i.e. typically at a 1:n switchover.

Programming

Syntax:	CONTROL <instructions> END_CONTROL
Description:	Control switchover
Parameters:	- None -

See also

Variable S_CONTROL (Page 111)

8.2.5 FOCUS

Description

The FOCUS method is executed if the focus (cursor) is positioned on another field in the dialog.

The FOCUS method must not be initiated as a result of a navigation event. The cursor position may only be changed in softkey PRESS methods, CHANGE methods, etc. The response of cursor movements is predefined.

Note

Within the FOCUS method, it is not possible to select a different variable, nor can a new dialog be loaded.

Programming

Syntax:	FOCUS ... END_FOCUS
Description:	Positions the cursor
Parameters:	- None -

Example

```
FOCUS
  DLGL("The focus has been placed on variable << FOC << ".)
END_FOCUS
```

See also

FOC variable (Page 109)

8.2.6 LANGUAGE

Description

The LANGUAGE method is run through when the current language has changed for an opened screen.

Programming

Syntax:	LANGUAGE <instructions> END_LANGUAGE
Description:	Language
Parameters:	- None -

See also

Variable S_LANG (Page 111)

8.2.7 LOAD

Description

The LOAD method is executed after the variable and softkey definitions (DEF Var1= ..., HS1= ...) have been interpreted. At this time, the dialog is not yet displayed.

Programming

Syntax:	LOAD ... END_LOAD
Description:	Download
Parameters:	- None -

Example

```
LOAD                                ; Start identifier
  Screen form1.Hd = $85111         ; Assign text for dialog header from language file
  VAR1.Min = 0                     ; Assign MIN variable limit
  VAR1.Max = 1000                  ; Assign MAX variable limit
END_LOAD                           ; End code
```

See also

Defining graphic elements (Page 189)

8.2.8 UNLOAD

Description

The UNLOAD method is executed before a dialog is unloaded.

Programming

Syntax:	UNLOAD ... END_UNLOAD
Description:	Unload
Parameters:	- None -

Example

```
UNLOAD
    REG[1] = VAR1           ; Save variable in register
END_UNLOAD
```

8.2.9 OUTPUT

Description

The OUTPUT method is executed if the "GC" function is called. Variables and Help variables are configured as an NC code in an OUTPUT method. The individual elements in a code line are linked by means of blanks.

Note

The NC code can be generated in an extra file by means of file functions and transferred to the NC.

Programming

Syntax:	OUTPUT(identifier) ... END_OUTPUT	
Description:	Outputs variables in the NC program.	
Parameters:	Identifier	Name of OUTPUT method

Block numbers and skip identifiers

The OUTPUT method must not contain line numbers or skip identifiers if you wish to keep the line numbers and skip identifiers directly set with active program support in the parts program in case of recompilations.

Editor changes in the parts program produce the following response:

Condition	Response
Number of blocks remains unchanged.	Block numbers are retained.
Number of blocks is reduced.	The highest block numbers are canceled.
Number of blocks is increased.	New blocks are not numbered.

Example

```
OUTPUT (CODE1)
  "CYCLE82 (" Var1.val ", " Var2.val ", " Var3.val ", " Var4.val ", " Var5.val ", "
Var6.val ") "
END_OUTPUT
```

8.2.10 PRESS

Description

The PRESS method is executed when the corresponding softkey is pressed.

Programming

Syntax:	PRESS(softkey) ... END_PRESS		
Designation:	Pressing a softkey		
Parameters:	Softkey	Name of softkey: HS1 - HS8 and VS1 - VS8	
	RECALL	<RECALL> key	
	ENTER	For the <ENTER> key, see PRESS(ENTER) (Page 127)	
	TOGGLE	For the <TOGGLE> key, see PRESS(TOGGLE) (Page 127)	
	PU	Page Up	Screen up
	PD	Page Down	Screen down
	SL	Scroll left	Cursor left
	SR	Scroll right	Cursor right
	SU	Scroll up	Cursor up
	SD	Scroll down	Cursor down

Example

```

HS1 = ("another softkey menu")
HS2 = ("no function")
PRESS (HS1)
    LS("Menu1")                ; Load another softkey menu
    Var2 = Var3 + Var1
END_PRESS
PRESS (HS2)
END_PRESS
PRESS (PU)
    INDEX = INDEX -7
    CALL ("UP1")
END_PRESS

```

8.2.11 PRESS(ENTER)**Description**

The PRESS(ENTER) method is always called when the Enter key is pressed for a variable with input/output field with input mode WR3 or WR5:

- WR3: Navigation to field and pressing of the Enter key
- WR5: In the input mode, transfer of the value with the Enter key

Programming

Syntax:	PRESS(ENTER) <instructions> END_PRESS
Description:	Enter key pressed
Parameters:	- None -

8.2.12 PRESS(TOGGLE)**Description**

The PRESS(TOGGLE) method is always called when the toggle key is pressed irrespective of the currently focused variable.

When required, the FOC screen property can be used to determine which variable is currently in focus.

Programming

Syntax:	PRESS(TOGGLE) <instructions> END_PRESS
Description:	Toggle key pressed
Parameter:	- None -

Example

```
PRESS (TOGGLE)
    DLGL("Toggle key pressed at variable " << FOC)      ; The FOC screen property determines which
                                                            variable is currently in focus
END_PRESS
```

8.2.13 RESOLUTION

Description

The RESOLUTION method is run through when the current resolution has changed for an opened screen, i.e. typically at a TCU switchover.

Programming

Syntax:	RESOLUTION <instructions> END_RESOLUTION
Description:	Resolution
Parameters:	- None -

See also

Variables S_RESX and S_RESY (Page 112)

8.2.14 RESUME

Description

The RESUME method is called when the screen was interrupted, e.g. for an area change, and is now shown again. The value changes are processed again, if required, the timers started and the RESUME block executed.

Note

The functions LS, LM, DLGL, EXIT and EXITLS must not be configured in the methods SUSPEND or RESUME. When using the functions in these methods, the execution of the functions is prevented.

Programming

Syntax:	RESUME <instruction> END_RESUME
Description:	Screen active again
Parameters:	- None -

8.2.15 SUSPEND

Description

The SUSPEND method is called when the screen is interrupted and not unloaded. This is the case, for example, when the screen is exited by a simple area change, but not explicitly unloaded. The screen is retained in the background, but no value change or timers are processed. The screen is paused.

Note

The functions LS, LM, DLGL, EXIT and EXITLS must not be configured in the methods SUSPEND or RESUME. When using the functions in these methods, the execution of the functions is prevented.

Programming

Syntax:	SUSPEND <instruction> END_SUSPEND
Description:	Interruption of the screen
Parameters:	- None -

Example

```
SUSPEND
    MyVar1 = MyVar1 + 1
END_SUSPEND
```

8.2.16 Example: Version management with OUTPUT methods

Overview

Additional variables can be added to existing dialogs when expanding the user interface. A version identifier in parentheses is appended to the additional variables in the definition following the variable name: (0 = Original, is not written), 1 = Version 1, 2 = Version 2, etc.

Example:

```
DEF var100=(R//1)           ; Original, corresponds to Version 0
DEF var101(1)=(S// "Hello") ; Extension as of Version 1
```

When writing the OUTPUT method, you can specify which variables are written, with reference to a particular version identifier.

Example:

```
OUTPUT(NC1)                ; Only the variables of the original are offered in
                           ; the OUTPUT method.
OUTPUT(NC1,1)              ; The variables of the original and the extensions
                           ; with version identifier 1 are offered in the OUTPUT
                           ; method.
```

The OUTPUT method for the original does not need a version identifier, however you can specify it with 0. OUTPUT(NC1) is equivalent to OUTPUT(NC1,0). Version identifier n in the OUTPUT method includes all variables of the originals 0, 1, 2, ... up to and including n.

Programming with version identifier

//M(XXX)	Version 0 (default)
DEF var100=(R//1)	
DEF var101=(S// "Hello")	
DEF TMP	
VS8= ("GC")	
PRESS (VS8)	
GC ("NC1")	
END_PRESS	
OUTPUT (NC1)	
var100",,"var101	
END_OUTPUT	
; ***** Version 1, extended definition *****	
//M(XXX)	
DEF var100=(R//1)	
DEF var101=(S// "Hello")	
DEF var102(1)=(V// "HUGO")	
DEF TMP	
VS8= ("GC")	
PRESS (VS8)	
GC ("NC1")	
END_PRESS	
...	
OUTPUT (NC1)	Original and the new version in addition
var100",,"var101	
END_OUTPUT	
...	
OUTPUT (NC1,1)	Version 1
var100",,"var101", " var102	
END_OUTPUT	

8.3 Functions

Overview

A variety of functions are available in dialogs and dialog-dependent softkey menus. These can be activated by specific events (exit input field, actuate softkey) and configured in methods.

Subprograms

Repeatedly used configuring instructions or others, which define the process for a particular operation can be configured in subprograms. Subprograms can be loaded into the main program or other subprograms at any time and executed as often as necessary, i.e. the instructions they contain do not need to be configured repeatedly. The definition blocks of the dialogs/softkey menu constitute a main program.

External functions

Additional, user-specific functions can be integrated by means of external functions. The external functions are stored in a DLL file and identified by an entry in the definition lines of the configuration file.

PI services

The PI_START function starts PI Services (Program Invocation Services) from the PLC in the NC area.

See also

Function (FCT) (Page 151)

PI services (Page 166)

8.3.1 Reading and writing drive parameters: RDOP, WDOP, MRDOP

Description

You can read and write drive parameters using RDOP, WDOP and MRDOP functions.

Note

Do not read drive parameters faster than in a 1 second cycle, slower is better.

Reason: The communication with the drives can otherwise be extremely disturbed or even cause failures.

Note

If errors occur when reading and writing drive parameters, the screen property ERR is set appropriately.

Programming

Syntax:	RDOP("Identifier of the drive object", "Parameter number")
Description:	Reading a drive parameter (Drive Object Parameter)

Parameters:	Identifier of the drive object	The identifier of the drive object can be found in the "DO name" column in "Drive system diagnostics" in the diagnostics operating area (> ETC > HSK 8: drive system) (see diagram below).
	Parameter number	




Figure 8-1 Identifier of the drive object

Syntax:	MRDOP ("Identifier of the drive object", "Parameter number1"*"Parameter number"[*...], Register index)	
Description:	Multi-read of drive parameters. The MRDOP command transfers several drive parameters or drive objects in a single register access. This access method is significantly faster than reading via individual access attempts.	
Parameters:	Identifier of the drive object	The identifier of the drive object can be taken, for example, from the root screen of the "Setup" operating area.
	Parameter number1 ... n	In the variable names, "*" is the separator. The values are transferred to register REG[Register index] in the order that the variable names appear in the command.
	Register index	The value of the first variable is located in REG[Register index]. The value of the second variable is located in REG[Register index + 1]

Syntax:	WDOP ("Identifier of the drive object", "Parameter number", Value)	
Description:	Writing a drive parameter (Drive Object Parameter)	
Parameters:	Identifier of the drive object	The identifier of the drive object can be taken, for example, from the root screen of the "Setup" operating area.
	Parameter number	Parameter number
	Value	Value to be written

Examples

Read motor temperature r0035 of drive object "SERVO_3.3:2":

```
MyVar=RDOP ("SERVO_3.3:2", "35") ;
```

Read motor temperature r0035 and actual torque value r0080 of drive object "SERVO_3.3:2" and store the respective results as of register index 10:

```
MRDOP ("SERVO_3.3:2", "35*80", 10)
```

8.3.2 Subprogram call (CALL)

Description

The CALL function calls a loaded subprogram from any point in a method. Subprogram nesting is supported, i.e. you can call a subprogram from another subprogram.

Programming

Syntax:	CALL ("Identifier")	
Description:	Subprogram call	
Parameters:	Identifier	Name of subprogram

Example

```
//M(SCREEN1)
DEF VAR1 = ...
DEF VAR2 = ...
CHANGE (VAR1)
...
CALL ("MY_UP1")           ; Call subprogram and execute
...
END_CHANGE
```

```
//M(SCREEN1)
CHANGE (VAR2)
...
CALL ("MY_UP1")           ; Call subprogram and execute
...
END_CHANGE

SUB (MY_UP1)
...                       ; Do something
END_SUB
//END
```

8.3.3 Define block (//B)

Description

In the program file, subprograms are identified by the block identifier //B and terminated with //END. Several subprograms can be defined under each block identifier.

Note

The variables used in the subprogram must be defined in the dialog in which the subprogram is called.

Programming

A block is structured in the following way:

Syntax:	//B(Block name) SUB(Identifier) END_SUB [SUB(Identifier)] ... END_SUB] ... //END	
Description:	Defines a subprogram	
Parameters:	Block name	Name of block identifier
	Identifier	Name of subprogram

Example

```
//B(PROG1)                ; Block start
SUB(UP1)                   ; Start of subprogram
...
REG[0] = 5                 ; Assign value 5 to register 0
...
END_SUB                   ; End of subprogram
SUB(UP2)                   ; Start of subprogram
  IF VAR1.val=="Otto"
    VAR1.val="Hans"
    RETURN
  ENDIF
  VAR1.val="Otto"
END_SUB                   ; End of subprogram
//END                     ; Block end
```

8.3.4 Check Variable (CVAR)

Description

You can use the CVAR (Check Variable) function to run a scan to ascertain whether all or only certain variables or Help variables in a screen are error-free.

It may be useful to check if variables contain a valid value before an NC code with the GC function.

A variable is error-free if the state of the variable Identifier.vld = 1.

Programming

Syntax:	CVAR(VarN)	
Description:	Checks variables for valid content	
Parameters:	VarN	List of variables to be checked. Up to 29 variables, each separated by a comma, can be checked. A character length of 500 must not be exceeded. The result of the scan can be:
	1 =	TRUE (all variables have valid content)
	0 =	FALSE (at least one variable has invalid content)

Example

```
IF CVAR == TRUE                ; Check all variables
```

```

VS8.SE = 1                                ; If all variables are error-free, soft-
                                         key VS8 is visible

ELSE
    VS8.SE = 2                            ; If a variable has an invalid value,
                                         softkey VS8 is disabled
ENDIF

IF CVAR("VAR1", "VAR2") == TRUE

                                         ; Check variables VAR1 and VAR2

    DLGL ("VAR1 and VAR2 are OK")

                                         ; If the values of VAR1 and VAR2 are er-
                                         ror-free, "VAR1 and VAR2 are OK" appears
                                         in the dialog line

ELSE
    DLGL ("VAR1 and VAR2 are not OK")

                                         ; If the values of VAR1 and VAR2 are in-
                                         valid, "VAR1 and VAR2 are not OK" appears
                                         in the dialog line

ENDIF

```

8.3.5 Copy Program file function (CP)

Description

The CP (Copy Program) function copies files within the HMI file system or within the NC file system.

Programming

Syntax:	CP("Source file", "Target file")	
Description:	Copies a file	
Parameters:	Source file	Complete path to the source file
	Target file	Complete path data of the target file

The return value (VAR1 defined as help variable) queries whether the function was successful:

```
CP ("//NC/MPF.DIR/HOHO.MPF", "//NC/MPF.DIR/ASLAN.MPF", VAR1)
```

Example

Application with return value:

```

CP ("//NC/MPF.DIR/HOHO.MPF", "//NC/MPF.DIR/ASLAN.MPF", VAR1)
CP ("CF_CARD:/wks.dir/MESS_BILD.WPD/MESS_BILD.MPF", "//NC/WKS.DIR/AAA.WPD/HOHO2.MPF", VAR1)

```

```
CP ("//NC/MPF.DIR/HOHO.MPF", "CF_CARD:/wks.dir/WST1.WPD/MESS.MPF", VAR1) ; WPD must exist
```

Application without return value:

```
CP ("//NC/MPF.DIR/HOHO.MPF", "//NC/MPF.DIR/ASLAN.MPF")
CP ("CF_CARD:/mpf.dir/MYPROG.MPF", "//NC/MPF.DIR/HOHO.MPF")
CP ("//NC/MPF.DIR/HOHO.MPF", "CF_CARD:/XYZ/MYPROG.MPF") ; XYZ must exist
```

See also

Support of FILE_ERR: FILE_ERR variable (Page 107)

8.3.6 Delete Program file function (DP)

Description

The DP (Delete Program) function deletes a file from the passive HMI or active NC file system.

Programming

Syntax:	DP("File")	
Description:	Delete file	
Parameters:	File	Complete path name of file to be deleted

Example

The following data management syntax is used for this function:

- With return value


```
DP ("//NC/MPF.DIR/MYPROG.MPF", VAR1)
DP ("//NC/WKS.DIR/TEST.WPD/MYPROG.MPF", VAR1)
DP ("//NC/CMA.DIR/MYPROG.SPF", VAR1)
VAR1 = 0      File was deleted.
VAR1 = 1      File was not deleted.
```
- Without return value:


```
DP ("//NC/MPF.DIR/MYPROG.MPF")
DP ("//NC/WKS.DIR/TEST.WPD/MYPROG.MPF")
DP ("//NC/CMA.DIR/MYPROG.SPF")
```

8.3.7 Exist Program file function (EP)

Description

The EP (Exist Program) function checks whether a particular NC program is stored on the specified path in the NC or HMI file system.

Programming

Syntax:	EP("File")	
Description:	Checks the existence of the NC program	
Parameters:	File	Complete path to the file in the NC or HMI file system
Return value:	Name of a variable to which the result of the scan should be assigned	

The EP function can handle the new syntax and the old logic (with adapted syntax).

The file is directly addressed using a qualifying name:

//NC/MPF.DIR/XYZ.MPF

or

CF_CARD: /MPF.DIR/XYZ.MPF (points to /user/sinumerik/data/prog)

or

LOC: (corresponds to CF_CARD)

Examples of new syntax:

```
EP("//NC/WKS.DIR/TEST.WPD/XYZ.MPF",VAR1)
EP("CF_CARD:/mpf.dir/XYZ.MPF",VAR1)
EP("LOC:/mpf.dir/XYZ.MPF",VAR1)
; With return value:
; VAR1 = 0 File exists.
; VAR1 = 1 File does not exist.
```

Example of old syntax:

```
EP("/MPF.DIR/CFI.MPF", VAR1)
; With return value:
; VAR1 = M File is located in the HMI file system.
; VAR1 = N File is located in the NC file system.
; VAR1 = B File is located in the HMI and the NC file system.
```

Example

```

EP("/MPF.DIR/GROB.MPF",VAR1) ; Old - path now with / instead of \

IF VAR1 == "M"
    DLGL("File is located in the HMI file system")
ELSE
    IF VAR1 == "N"
        DLGL("File is located in the NC file directory")
    ELSE
        DLGL("File is located neither in the HMI nor in the NC
file system")
    ENDIF
ENDIF
ENDIF

```

8.3.8 Move Program file function (MP)

Description

The MP (Move Program) function copies files within the HMI file system or within the NC file system.

Programming

Syntax:	MP("Source", "Target")	
	MP ("CF_CARD:/MPF.DIR/MYPROG.MPF", "//NC/MPF.DIR")	
Description:	Move file	
Parameters:	Source file	Complete path data
	Target file	Complete path data
Return value	Result of the query	

Examples

With return value:

```

MP("//NC/MPF.DIR/123.MPF", "//NC/MPF.DIR/ASLAN.MPF", VAR1) ;Within NC
MP("//NC/MPF.DIR/123.MPF", VAR0, VAR1) ;Target via variable
MP(VAR4, VAR0, VAR1) ;Source and target via variable
MP("CF_CARD:/mpf.dir/myprog.mpf", "//NC/MPF.DIR/123.MPF", VAR1) ;From CF card to NC
MP("//NC/MPF.DIR/HOHO.MPF", "CF_CARD:/XYZ/123.mpf", VAR1) ;From NC to CF card

```

```
; With return value:
; VAR1 = 0 Executed
; VAR1 = 1 Not executed
```

8.3.9 Select Program file function (SP)

Description

The SP (Select Program) function selects a file in the active NC file system for execution, i.e. the file must be loaded into the NC beforehand.

Programming

Syntax:	SP("File")	
Designation:	Select program	
Parameters:	"File"	Complete path name of NC file

Example

The following data management syntax is used for this function:

- With return value


```
SP (" //NC/MPF.DIR/MYPROG.MPF", VAR1)
VAR1 = 0      File was loaded.
VAR1 = 1      File was not loaded without return value.
```
- Without return value:


```
SP (" //NC/MPF.DIR/MYPROG.MPF")
```

8.3.10 File accesses: RDFILE, WRFILE, RDLINEFILE, WRLINEFILE

Description

The RDFILE and WRFILE functions are available for read and write access to files with INI syntax.

The RDLINEFILE and WRLINEFILE functions are available for read and write access to individual lines of a file.

Programming

Syntax:	RDFILE("File name + path", "Section", "Key")
Description:	Reading from a file

8.3 Functions

Parameters:	File name + path	Path and file name
	Section	Section in the INI file
	Key	Key in the INI file

Syntax:	WRFILE (Value, "File name + path", "Section", "Key")	
Description:	Writing to a file	
Parameters:	Value	Value to be written
	File name + path	Path and file name
	Section	Section in the INI file
	Key	Key in the INI file

Syntax:	RDLINEFILE ("File name + path", Line number)	
Description:	Reading a line from a file	
Parameters:	File name + path	Path and file name
	Line number	Line number Numbering begins at 0 for the first line.

Syntax:	WRLINEFILE (Value, "File name + path")	
Description:	Writing of a line at the end of a file	
Parameters:	Value	Value to be written
	File name + path	Path and file name

Note

- The files must not be in the file system of the NC (data management).
- If the file does not exist, or the end of the file is reached or other errors occur, the variables FILE_ERR and ERR are set accordingly. You can check whether a file exists first with the Exist Program (EP) file function.
- The processed file is generated in "UTF-8" coding (without BOM (Byte Order Mask)). When reading a file, it is expected in "UTF-8" coding.
- You can delete the file explicitly when required with the Delete Program (DP) file function.

Examples

Reading from an INI file:

Requirement/assumption:

Content of file "C:/tmp/myfile.ini":

```
<...>
[MyData]
MyName=Daniel
<...>
```

```
MyVar = RDFILE("C:/tmp/myfile.ini", "MyData", "MyName")
```

Result:

MyVar now contains the value "Daniel".

Writing to an INI file:

Requirement/assumption:

VARs=12

```
WRFILE(VARS, "C:/tmp/myfile.ini", "MySession", "NrOfSessions")
```

Result:

Content of file "C:/tmp/myfile.ini":

```
<...>
[MySession]
NrOfSessions=12
<...>
```

Reading the 4th line of a file:

Requirement/assumption:

Content of c:/tmp/myfile.mpf:

```
R[0]=0
F3500 G1
MYLOOPIDX1: X0 Y-50 Z0
           X150 Y50 Z10
           R[0]=R[0]+1
GOTOB MYLOOPIDX1
M30
```

```
MyVar = RDLINFILE("C:/tmp/myfile.mpf", 4)
```

Result:

MyVar now contains the value " R[0]=R[0]+1 "

Writing at the end of a file:

Requirement/assumption:

VARX=123

VARY=456

```
WRLINEFILE("F100 X" << VARX << " Y" << VARY, "C:/tmp/mypp.mpf")
```

Result:

Content of c:/tmp/mypp.mpf:

<...>

F100 X123 Y456

8.3.11 Dialog line (DLGL)

Description

It is possible to configure short texts (messages or input tips) for output in the dialog line of the dialog in response to certain situations.

Possible number of characters in the default font size: approx. 50

Note

The functions LS, LM, DLGL, EXIT and EXITLS must not be configured in the methods SUSPEND or RESUME. When using the functions in these methods, the execution of the functions is prevented.

Programming

Syntax:	DLGL("String")	
Description:	Outputs text in the dialog line	
Parameters:	String	Text, which is displayed in the dialog line

Example

```
IF Var1 > Var2
    ; The text "Value too large!" appears in the dialog
    ; line if variable1 > variable2.
    DLGL("Value too large!")
ENDIF
```

8.3.12 DEBUG

Description

The DEBUG function provides an analysis help during the draft phase of Run MyScreen user screens. An expression in brackets transferred with the DEBUG function is evaluated during runtime. The result is attached to the "easyscreen_log.txt" logbook as a separate entry.

Each entry has the current time stamp in square brackets as prefix (see example below).

It is recommended that the DEBUG outputs are removed in time-critical parts when possible. Particularly after completing the draft phase, it is recommended that you comment out the DEBUG outputs. The write access to the constantly expanding "easyscreen_log.txt" logbook may slow down the processing.

Programming

Syntax:	DEBUG (expression)
Description:	Makes an entry in the "easyscreen_log.txt" logbook
Parameters:	Expression to be evaluated from which an entry is generated in the logbook

Example

```
IF Var1 > Var2
    DEBUG("Value of ""Var1"": " << Var1)
                                ; Entry in the "easyscreen_log_txt:
                                [10:22:40.445] DEBUG: Value of "Var1":
                                123.456
ENDIF
```

8.3.13 Exit dialog (EXIT)

Description

The EXIT function is used to exit a dialog and return to the master dialog. If no master dialog is found, you will exit the newly configured user interfaces and return to the standard application.

Note

The functions LS, LM, DLGL, EXIT and EXITLS must not be configured in the methods SUSPEND or RESUME. When using the functions in these methods, the execution of the functions is prevented.

Programming (without parameters)

Syntax:	EXIT
Description:	Exits a dialog
Parameters:	- None -

Example

```

PRESS (HS1)
    EXIT
END_PRESS

```

Description

If the current dialog has been called with a transfer variable, the value of the variables can be changed and transferred to the output dialog.

The variable values are each assigned to the variables transferred from the output dialog to the subsequent dialog using the "LM" function. Up to 20 variable values, each separated by a comma, can be transferred.

Note

The sequence of variables or variable values must be the same as the sequence of transfer values programmed for the LM function to preclude assignment errors. Any unspecified variable values will not be changed when the transfer is made. The modified transfer variables are immediately valid in the output dialog on execution of the LM function.

Programming with a transfer variable

Syntax:	EXIT[(VARx)]	
Description:	Exits the dialog and transfers one or more variables	
Parameters:	VARx	Label variables

Example

```

//M(Screen1)
...
PRESS (HS1)
    LM("SCREEN2","CFI.COM",1, POSX, POSY,
    DIAMETER)
; Interrupt Screen1 and open Screen2. In
; doing this, transfer variables POSX, POSY
; and DIAMETER.

```

; After returning from Screen2, the following text appears in the dialog line of Screen1: Screen2 ended.

Programming

Syntax:	LISTINSERTITEM (Variable name, Position, ItemValue[, ItemDispValue])	
Description:	Inserts an element at a specific position; reading from a file	
Parameters:	Variable name	
	Position	Position at which an element is to be inserted in the list
	ItemValue	Value of the list entry
	ItemDispValue	Value as it is to be displayed in the list

Syntax:	LISTADDITEM (Variable name, ItemValue[, ItemDispValue])	
Description:	Adds an element to the end of the list	
Parameters:	Variable name	
	ItemValue	Value of the list entry
	ItemDispValue	Value as it is to be displayed in the list

Syntax:	LISTDELETEITEM (Variable name, Position)	
Description:	Deletes a specific element	
Parameters:	Variable name	
	Position	Position of the element to be deleted in the list

Syntax:	LISTCOUNT (Variable name)	
Description:	Returns the current number of elements in the list	
Parameters:	Variable name	

Syntax:	LISTCLEAR (Variable name)	
Description:	Deletes the complete list	
Parameters:	Variable name	

Examples

Note

The following examples build upon each other. The sequence of the examples is relevant in order to understand the respective results.

Requirement/assumption:

```
DEF VAR_AC = (I/* 0="Off",1="On"/1/, "Switch"/WR2)
```

Adding an element -1="Undefined" to the end of the list:

```
LISTADDITEM("VAR_AC", -1, ""Undefined"")
```

Result: 0="Off", 1="On", -1="Undefined"

Inserting an element 99="Maybe" at position 2:

```
LISTINSERTITEM("VAR_AC", 2, 99, ""Maybe"")
```

Result: 0="Off", 1="On", 99="Maybe", -1="Undefined"

Determining the current number of list elements:

```
REG[10]=LISTCOUNT("VAR_AC")
```

Result: REG[10] = 4

Deleting the element at position 1:

```
LISTDELETEITEM("VAR_AC", 1)
```

Result: 0="Off", 99="Maybe", -1="Undefined"

Deletion of the complete list:

```
LISTCLEAR("VAR_AC")
```

Result: List is empty

8.3.15 Evaluate (EVAL)

Description

The EVAL function evaluates a transferred expression and then executes it. With this function, expressions can be programmed during runtime. This can be useful, for example, for indexed access operations to variables.

Programming

Syntax:	EVAL(exp)	
Description:	Evaluates an expression	
Parameters:	exp	Logic expression

Example

```
VAR1=(S)
VAR2=(S)
VAR3=(S)
VAR4=(S)
CHANGE()
  REG[7] = EVAL("VAR"<<REG[5]) ; The expression in parentheses produces VAR3 if the
                                value of REG[5] is equal to 3. The value of VAR3 is,
                                therefore, assigned to REG[7].

  IF REG[5] == 1
    REG[7] = VAR1
  ELSE
    IF REG[5] == 2
      REG[7] = VAR2
    ELSE
      IF REG[5] == 3
        REG[7] = VAR3
      ELSE
        IF REG[5] == 4
          REG[7] = VAR4
        ENDIF
      ENDIF
    ENDIF
  ENDIF
END_CHANGE
```

8.3.16 Exit Loading Softkey (EXITLS)

Description

You can use the EXITLS function to exit the current user interface and load a defined softkey menu.

Note

The functions LS, LM, DLGL, EXIT and EXITLS must not be configured in the methods SUSPEND or RESUME. When using the functions in these methods, the execution of the functions is prevented.

Programming

Syntax:	EXITLS ("Softkey menu"[, "Path name"])	
Description:	Exits dialog and loads a softkey menu	
Parameters:	Softkey menu	Name of the softkey menu to be loaded
	Path name	Directory path of the softkey menu to be loaded

Example

```
PRESS (HS1)
    EXITLS ( "Menu1", "AEDITOR.COM" )
END_PRESS
```

8.3.17 Function (FCT)

Description

The external functions are stored in a DLL file and identified by an entry in the definition lines of the configuration file.

Note

The external function must have at least one return parameter.

Programming

Syntax:	FCT Function name = ("File"/Type of return/Types of permanent parameters/Types of variable parameters)
	FCT InitConnection = ("c:\tmp\xyz.dll"//R,I,S/I,S)

8.3 Functions

Description:	An external function can, for example, be called from the LOAD method or executed in the PRESS method.	
Parameters:	Function name	Name of external function
	File	Complete path to DLL file
	Type of return	Data type of the return value
	Type of fixed parameter	Value parameter
	Type of variable parameter	Reference parameter
	The data types are separated by commas.	

The external function can, for example, be called from the LOAD method or executed in the PRESS method.

Example:

```
press(vs4)
RET = InitConnection(VAR1,13,"Servus",VAR2,VAR17)
end_press
```

Structure of the external function

The external function must take into account a certain, specific signature:

Syntax:	extern "C" dllexport void InitConnection (ExtFctStructPtr FctRet, ExtFctStructPtr FctPar, char cNrFctPar)	
Description:	DLL export, only when implemented in Windows Specifiers and transfer parameters are strictly defined. The actual call parameters are transferred using the transferred structures.	
Parameters:	cNrFctPar	Number of call parameters = number of structure elements in FctPar
	FctPar	Pointer to a field of structure elements, which contain the particular call parameter with data type.
	FctRet	Pointer to a structure for the function value return with data type.

Definition of the transfer structure

```
union CFI_VARIANT
(
    char                b;
    short int           i;
    double              r;
    char*               s;
)
typedef struct ExtFctStructTag
```

```
(
    char                                cTyp;
    union CFI_VARIANT                  value;
) ExtFctStruct;
typedef struct ExtFct* ExtFctStructPtr;
```

If the external function is to be developed independently of the platform (Windows, Linux), then it is not permissible to use the keyword `__declspec(dllexport)`. This keyword is only required under Windows. For instance, the following macro can be used under Qt:

```
#ifdef Q_WS_WIN
    #define MY_EXPORT __declspec(dllexport)
#else
    #define MY_EXPORT
#endif
```

The function is declared as follows:

```
external "C" MY_EXPORT void InitConnection
(ExtFctStructPtr FctRet, ExtFctStructPtr FctPar, char cNrFctPar)
```

If the screens, configured with "Run MyScreens", are used on the NCU and PCU/PC, then the extension of the binary file must be omitted:

```
FCT InitConnection = ("xyz"/I/R,I,S/I,S)
```

When the absolute path information is omitted, "Run MyScreens" first searches for the binary file in the configured directory.

8.3.18 Generate code (GC)

Description

The GC (Generate Code) function generates NC code from the OUTPUT method.

Programming

Syntax:	GC ("Identifier"[,"Target file"][,Opt],[Append])
Description:	Generating NC code (the GC function can only be used within the NC)

Parameters:	Identifier	Name of the OUTPUT method from which code is generated
	Target file	Path name of target file for HMI or NC file system If the target file is not specified (only possible within Programming Support), the code will be written to the location of the cursor within the file that is currently open.
	Opt	Option for generating comments.
	0:	(Default setting) Generate code with comment for the purpose of recompilability (see also Recompile (Page 171)).
	1:	Do not create comments in the generated code. Note: This code cannot be recompiled (see also Recompile (Page 171)).
	Append	This parameter is only relevant if a target file is specified.
	0:	(Default setting) If the file already exists, the old content is deleted.
	1:	If the file already exists, the new code is written at the start of the file.
	2:	If the file already exists, the new code is written at the end of the file.

Example

```
//M(TestGC/"Code generation:")
DEF VAR1 = (R//1)
DEF VAR2 = (R//2)
DEF D_NAME
LOAD
  VAR1 = 123
  VAR2 = -6
END_LOAD
OUTPUT(CODE1)
  "Cycle123(" VAR1 "," VAR2 ")"
  "M30"
END_OUTPUT

PRESS(VS1)
  D_NAME = "\\MPF.DIR\MESSEN.MPF"
  GC("CODE1",D_NAME)           ; Write NC code from the OUTPUT method to file
                                ; \\MPF.DIR\MESSEN.MPF:
                                Cycle123(123, -6)
                                M30
END_PRESS
```

Storing the target file

The GC function can only be used within the NC. Use the function CP or MP to move the file. See the following examples:

```
; Windows directory
GC ("Code", "//NC/MPF.DIR/NC1.MPF")
MP ("//NC/MPF.DIR/NC1.MPF", "d:/tmp/WIN1.MPF")

; LOCAL_DRIVE
GC ("Code", "//NC/MPF.DIR/NC1.MPF")
MP ("//NC/MPF.DIR/NC1.MPF", "LOCAL_DRIVE:/WIN_LD1.MPF")
```

Recompile

- **No entry for target file:**
The GC function can only be used in the Programming Support and writes the NC code to the file currently open in the editor. Recompilation of the NC code is possible. If the GC function is configured without a target file being specified under "Run MyScreens", an error message is output when it is executed.
- **Entry for target file:**
The code generated from the OUTPUT method is entered in the target file. If the target file does not already exist, it is set up in the NC file system. If the target file is stored in the HMI file system, it is stored on the hard disk. User comment lines (information required to recompile code) are not set up, i.e. the code cannot be recompiled.

Special features of recompilation

The GC function cannot be called in sub-dialogs because variables originating from master dialogs can be used in sub-dialogs. These variables would not, however, be available in response to a direct call.

When generated code is processed manually with the editor, the number of characters for values created by the code generation program must not be changed. Changing these values would make it impossible to recompile the code.

Remedy:

1. Recompile
2. Make change using the configured dialog (e.g. 99 → 101)
3. GC

8.3.19 Password functions

Overview

The following password functions are available:

- Set password
- Delete password
- Change password

HMI_LOGIN function: Set new password

Syntax:	HMI_LOGIN (Passwd)	
Description:	A password which sets the current access level is sent to the NCK with the HMI_LOGIN() function.	
Parameters:	Passwd	Password

Example

```
REG[0] = HMI_LOGIN("CUSTOMER") ; Result = TRUE if the password has been set
                                successfully, otherwise FALSE
```

HMI_LOGOFF function: Delete password

Syntax:	HMI_LOGOFF	
Description:	The actual access level can be reset using the HMI_LOGOFF function.	
Parameters:	- None -	

Example

```
REG[0] = HMI_LOGOFF ; Result = TRUE if the password has been de-
                    leted successfully, otherwise FALSE
```

HMI_SETPASSWD function: Change password

Syntax:	HMI_SETPASSWD (AC, Passwd)	
Description:	The password of the current level or a lower level can be changed with the HMI_SETPASSWD function.	
Parameters:	AC	Access level
	Passwd	Password

Example

```
REG[0] = HMI_SETPASSWD(4,"MYPWD")      ; Result = TRUE if the password has been
                                         changed successfully, otherwise FALSE
```

8.3.20 Load Array (LA)**Description**

The LA (Load Array) function can be used to load an array from another file.

Programming

Syntax:	LA (Identifier [, File])	
Description:	Loads an array from a file	
Parameters:	Identifier	Name of array to be loaded
	File	File in which the array is defined

Note

If an array in the current configuration file must be replaced by an array from another configuration file, then both arrays must have the same name.

Example

```

                                         ; Extract from file maske.com
DEF VAR2 = (S/*ARR5/"Out"/,"Toggle field")
PRESS(HS5)
  LA("ARR5","arrayext.com")           ; Load array ARR5 from file arrayext.com
  VAR2 = ARR5[0]                      ; "Above"/"Below"/"Right"/"Left" appears
                                         in the VAR2 toggle field
                                         instead of "Out/In"

END_PRESS
//A(ARR5)
("Out"/"In")
//END

                                         ; Extract from file arrayext.com
//A(ARR5)
("Above"/"Below"/"Right"/"Left")
//END
```

Note

Please note that a valid value must be assigned to a variable after the LA function has been used to assign another array to the toggle field of the variable.

8.3.21 Load Block (LB)

Description

The LB (Load Block) function can be used to load blocks containing subprograms during runtime. LB should be configured in a LOAD method so that the loaded subprograms can be called at any time.

Note

Subprograms can also be defined directly in a dialog so that they do not have to be loaded.

Programming

Syntax:	LB("Block name"[, "File"])	
Description:	Loads subprogram during runtime	
Parameters:	Block name	Name of block identifier
	File	Path name of configuration file Default setting = Current configuration file

Example

```
LOAD
```

```
  LB("PROG1")           ; Block "PROG1" is searched for in the current configura-
                        ; tion file and then loaded.
```

```
  LB("PROG2", "XY.COM") ; Block "PROG2" is searched for in the configuration file
                        ; XY.COM and then loaded.
```

```
END_LOAD
```

8.3.22 Load Mask (LM)

Description

The LM function loads a new dialog. Depending on the mode of the dialog change (see table below), a message dialog can also be implemented with this function.

Note

The functions LS, LM, DLGL, EXIT and EXITLS must not be configured in the methods SUSPEND or RESUME. When using the functions in these methods, the execution of the functions is prevented.

Master dialog / sub-dialog

A dialog, which calls another dialog, but is not ended itself, is referred to as a master dialog. A dialog that is called by a master dialog is referred to as a sub-dialog.

Programming

Syntax:	LM ("Identifier"[,"File"] [,MSx [, VARx]])	
Description:	Loads a dialog	
Parameters:	Identifier	Name of the dialog to be loaded
	File	Path name (HMI file system or NC file system) of the configuration file; default setting: Current configuration file
	MSx	Mode of dialog change
	0:	(Default setting) The current dialog is rejected, the new dialog is loaded and displayed. EXIT will send you back to the standard application. You can use the MSx parameter to determine whether or not the current dialog should be terminated when changing dialogs. If the current dialog is retained, variables can be transferred to the new dialog. The advantage of the MSx parameter is that the dialogs do not always need to be reinitialized when they are changed. Instead, the data and layout of the current dialog are retained and data transfer is made easier.
	1:	The current master dialog is interrupted when the LM function is initiated. The new sub-dialog is loaded and displayed (e.g. for the implementation of a message dialog). EXIT will end the sub-dialog and return to the point at which the master dialog was interrupted. In the master dialog, the UNLOAD block is not processed during the interruption.
	VARx	Precondition: MS1 List of variables which can be transferred from the master dialog to the sub-dialog. Up to 20 variables, each separated by a comma, can be transferred.

Note

Parameter VARx transfers only the value of the variable in each case, i.e. variables can be read and written in the sub-dialog, but are not visible in it. Variables can be returned from the sub-dialog to the master dialog by means of the EXIT function.

Example

SCREEN1 (master dialog): Jump to the sub-dialog SCREEN2 with variable transfer

```

PRESS (HS1)

LM("SCREEN2","CFI.COM",1, POSX, POSY, DIAMETER)
                                ; Interrupt Screen1 and open Screen2: In doing
                                ; this, variables POSX, POSY and DIAMETER are
                                ; transferred.

DLGL("Screen2 ended")          ; After returning from Screen2, the following
                                ; text appears in the dialog line of Screen1:
                                ; Screen2 ended.

END_PRESS

```

SCREEN2 (sub-dialog): Return to master dialog SCREEN1 with transfer of the variable contents

```

PRESS (VS8)

EXIT(POSX, POSY, DIAMETER)
                                ; Hide Screen2 and continue Screen1: In doing
                                ; this, the changed variables POSX, POSY and DI-
                                ; AMETER are transferred.

END_PRESS

```

8.3.23 Load Softkey (LS)**Description**

The LS function can be used to display another softkey menu.

Note

The functions LS, LM, DLGL, EXIT and EXITLS must not be configured in the methods SUSPEND or RESUME. When using the functions in these methods, the execution of the functions is prevented.

Programming

Syntax:	LS ("Identifier"[, "File"][, Merge])	
Description:	Displays the softkey menu	
Parameters:	Identifier	Name of the softkey menu
	File	Path (HMI file system or NC file system) to the configuration file Default setting: Current configuration file
	Merge	
	0:	All existing softkeys are deleted; the newly configured softkeys are entered.
	1:	Default setting Only the newly configured softkeys overwrite the available softkeys. The other softkeys (= softkeys of the HMI application) are kept with their functionality and text.

Example

```

PRESS (HS4)
  LS ("Menu2",,0)      ; Menu2 overwrites the existing softkey menu, the softkeys
                        ; that are displayed are deleted.
END_PRESS

```

Note

As long as the Interpreter has not displayed a dialog, i.e. no LM function has yet been processed, only one LS or one LM command, but no other action, can be configured in the PRESS method of the definition block for the start softkey and the softkey menu.

The LS and LM functions may only be called within a softkey PRESS method and will not react if navigation keys are pressed (PU, PD, SL, SR, SU, SD).

8.3.24 Load Grid (LG)

Description

The table description (grid) can be dynamically provided within methods (e.g. LOAD) using the LG method.

In order to assign a table using the LG method, the variable must have already been defined as a grid variable and cross-referenced to an existing, valid table.

Programming

Syntax:	LG (Grid name, Variable name [,File name])
Description:	Loads a table

Parameters:	Grid name	Name of the table (grid) in inverted commas
	Variable name	Name of the variable to which the table is to be assigned, in inverted commas
	File name	Name of the file in which the table (grid) is defined, in inverted commas. Only needs to be specified if the table is not defined within the file that also contains the definition of the variable.

Example

```
//M(MyGridSample/"My Grid Sample")
DEF MyGridVar=(R/% MyGrid1//WR2///100,,351,100)
LOAD
    LG("MyGrid1","MyGridVar","mygrids.com")
END_LOAD
```

Content of mygrids.com:

```
//G(MyGrid1/0/5)
(I///,"MyGrid1"/wr1/"1"/80/1)
(R3///"LongText1","R1-R4"/wr2/"$R[1]"/80/1)
(IBB///"LongText2","M2.2-M2.5"/wr2/"M2.2"/80/1)
(R3///"LongText3","R9,R11,R13,R15"/wr2/"$R[9]"/110/2)
//END
```

8.3.25 Multiple selection SWITCH

Description

You can check a variable for different values with a SWITCH command.

The expression configured in the SWITCH statement is compared in succession to all the values configured in the following CASE statements.

If not the same, a comparison is made with the following CASE statement. If a DEFAULT statement follows and up to now no CASE statement was the same as the expression configured in the SWITCH statement, the statements following the DEFAULT statement are executed.

If the same, the following statements are executed until a CASE, DEFAULT or END_SWITCH statement occurs.

Example

```

FOCUS
  SWITCH (FOC)
    CASE "VarF"
      DLGL("Variable ""VarF"" has the input focus.")
    CASE "VarZ"
      DLGL("Variable ""VarZ"" has the input focus.")
    DEFAULT
      DLGL("Any other variable has the input focus.")
  END_SWITCH
END_FOCUS

```

8.3.26 Multiple Read NC PLC (MRNP)

Description

This MRNP command transfers several NC/PLC variables in a single register access. This access method is significantly faster than reading via individual access attempts. The NC/PLC variables must be included within an MRNP command of the same area.

The areas of the NC/PLC variables are organized as follows:

- General NC data (\$MN..., \$SN..., /nck/...)
- Channel-specific NC data (\$MC..., \$SC..., /channel/...)
- PLC data (DB..., MB..., /plc/...)
- Axis-specific NC data on the same axis (\$MA..., \$SA..)

Programming

Syntax:	MRNP (Variable name 1*Variable name 2[* ...], Register index)
Description:	Reads several variables
Parameters:	In the variable names, "*" is the separator. The values are transferred to register REG[Register index] and those following in the order that the variable names appear in the command. The following therefore applies: The value of the first variable is located in REG[Register index]. The value of the second variable is located in REG[Register index + 1], etc.

Note

It should be noted that the number of registers is restricted and the list of variables cannot exceed 500 characters.

Example

```
MRNP("$R[0]*$R[1]*$R[2]*$R[3]",1) ;The values of variables $R[0] to $R[3] are
                                   written to REG[1] to REG[4].
```

NC variable

All machine and setting data and R-parameters are available, but only certain system variables (see also: AUTOHOTSPOT).

All global and channel-specific user variables (GUDs) can be accessed. However, local and program-global user variables cannot be processed.

Machine data	
Global machine data	\$MN_...
Axis-specific machine data	\$MA_...
Channel-specific machine data	\$MC_...

Setting data	
Global setting data	\$SN_...
Axis-specific setting data	\$SA_...
Channel-specific setting data	\$SC_...

System variables	
R parameter 1	\$R[1]

PLC variable

All PLC data are available.

PLC data	
Byte y bit z of data block x	DBx.DBXy.z
Byte y of data block x	DBx.DBBy
Word y of data block x	DBx.DBWy
Double word y v. of data block x	DBx.DB Dy
Real y of data block x	DBx.DBRy
Flag byte x bit y	Mx.y

PLC data	
Flag byte x	MBx
Flag word x	MWx
Flag double word x	MDx
Input byte x bit y	Ix.y or Ex.y
Input byte x	IBx or EBx
Input word x	IWx or EWx
Input double word x	IDx or EDx
Output byte x bit y	Qx.y or Ax.y
Output byte x	QBx or ABx
Output word x	QWx or AWx
Output double word x	QDx or ADx
String y with length z from data block x	DBx.DB\$y.z

8.3.27 P_LOGICAL_FILEPATH

Description

The P_LOGICAL_FILEPATH function returns the name and logical path of the currently edited subprogram in the editor.

Note

The function is only available in the context of cycle masks.

Programming

Syntax:	P_LOGICAL_FILEPATH()	
Description:	Determines the name and logical path of the currently edited subprogram in the editor e.g. "//NC/MPF.DIR/HUGO.MPF"	
Parameters:	- None -	

See also

P_REAL_FILEPATH (Page 166)

8.3.28 P_REAL_FILEPATH

Description

The P_REAL_FILEPATH function returns the name and real path of the currently edited subprogram in the editor.

Note

The function is only available in the context of cycle masks.

Programming

Syntax:	P_REAL_FILEPATH()	
Description:	Determines the name and real path of the currently edited subprogram in the editor e.g. "/_N_MPF_DIR/_N_HUGO_MPF"	
Parameters:	- None -	

See also

P_LOGICAL_FILEPATH (Page 165)

8.3.29 PI services

Description

The PI_START function starts PI Services (Program Invocation Services) from the PLC in the NC area.

Note

A list of the available PI services can be found in the Basic Functions Function Manual.

Programming

Syntax:	PI_START("Transfer string")	
Description:	Executes the PI service	
Parameters:	"Transfer string"	Unlike the OEM documentation, the transfer string should be entered in inverted commas.

Example

```
PI_START("/NC,001,_N_LOGOUT")
```

Note

Channel-dependent PI Services always refer to the current channel.

PI services of the tool functions (TO area) always refer to the TO area that is assigned to the current channel.

8.3.30 Reading (RNP) and writing (WNP) system or user variables**Description**

The RNP (Read NC PLC) command can be used to read NC or PLC variables or machine data.

Programming

Syntax:	RNP ("System or user variable", value)	
Description:	Reads NC or PLC variable or machine data	
Parameters:	System or user variable	Name of NC or PLC variable
	Value	Value that is to be written to the system or user variable. If the value is a String type, it must be written in double quotation marks.

Example

```
VAR2=RNP("$AA_IN[2]"); Read NC variable
```

Description

The WNP (Write NC PLC) command can be used to write NC or PLC variables or machine data.

NC/PLC variables are accessed anew every time the WNP function is executed, i.e., NC/PLC access is always executed in a CHANGE method. It is advisable to use this option in cases where a system or user variable changes value frequently. If an NC/PLC variable is to be accessed only once, then it must be configured in a LOAD or UNLOAD method.

Programming

Syntax:	WNP ("System or user variable", value)	
Description:	Writes NC or PLC variable or machine data	
Parameters:	System or user variable	Name of NC or PLC variable
	Value	Value that is to be written to the system or user variable. If the value is a String type, it must be written in double quotation marks.

Example

<pre>WNP("DB20.DBB1",1) ; Write PLC variable</pre>	
---	--

8.3.31 RESIZE_VAR_IO and RESIZE_VAR_TXT

Description

The `RESIZE_VAR_IO()` and `RESIZE_VAR_TXT()` commands changes the geometry of the input/output component or text component of a variable.

After setting the new geometry, all fields of the screen are positioned as if the screen had been configured with these positions from the start. In this way, all fields are correctly aligned, depending on the configuration.

Programming

Syntax:	RESIZE_VAR_IO (Variable name, [X], [Y], [Width], [Height]) RESIZE_VAR_TXT (Variable name, [X], [Y], [Width], [Height])	
Description:	Changes the geometry of the input/output component or text component of a variable.	
Parameters:	Variable name	Name of the variable whose geometry of the input/output component or text component of a variable is to be changed.
	X	X-coordinate, top left
	Y	Y-coordinate, top left
	Width	Width
	Height	Height

Note

The previous value is retained for each value of X, Y, Width or Height that is not specified. If -1 is specified for one of these values, "Run MyScreens" sets the specified component of the default position.

Example

<pre>RESIZE_VAR_IO("MyVar1", 200, , 100)</pre>	; The I/O component of the "MyVar1" variable is moved to the X position 200 pixels, the width is set to 100 pixels. The Y position and the height of the previous value are kept.
--	--

8.3.32 Register (REG)**Register description**

Registers are needed in order to exchange data between different dialogs. Registers are assigned to each dialog. These are created when the first dialog is loaded and assigned the value 0 or an empty string.

Note

Registers must not be used directly in an OUTPUT method for generating NC code.

Programming

Syntax:	REG[x]	
Description:	Defines a register	
Parameters:	x	Register index with x = 0...19; Type: REAL or STRING = VARIANT Registers with x ≥ 20 have already been assigned by Siemens.

Description of register value

The assignment of values to registers is configured in a method.

Note

If a new dialog is generated from an existing dialog by means of the LM function, register content is automatically transferred to the new dialog at the same time and is available for further calculations in the second dialog.

Programming

Syntax:	Identifier.val = Register value or Identifier = Register value
Description:	

8.3 Functions

Parameters:	Identifier	Name of the register
	Register value	Value of register

Example

```

UNLOAD
    REG[0] = VAR1          ; Assign value of variable 1 to register 0
END_UNLOAD

UNLOAD
    REG[9].VAL = 84        ; Assign value 84 to register 9
END_UNLOAD

                                ; These registers can then be assigned to local variables
                                ; again in a method in the next dialog.

LOAD
    VAR2 = REG[0]
END_LOAD
    
```

Description of register status

The Status property can be used to scan a register for valid content.

One possible use for the register scan function is to ensure that a value is written to a register only if the relevant dialog is a "master dialog".

Programming

Syntax:	Identifier.vld	
Description:	The property can only be read.	
Parameters:	Identifier	Name of the register
Return value:		The result of the scan can be:
	FALSE =	invalid value
	TRUE =	valid value

Example

```

IF REG[15].VLD == FALSE      ; Scan validity of register value
    REG[15] = 84
ENDIF

VAR1 = REG[9].VLD            ; Assign the value of the REG[9] status request to Var1.
    
```

8.3.33 RETURN

Description

The RETURN function can be used to prematurely terminate execution of the current subprogram and to return to the branch point of the last CALL command.

If no RETURN command is configured in the subprogram, the subprogram will run to the end before returning to the branch point.

Programming

Syntax:	RETURN	
Description:	Returns to the branch point	
Parameters:	- None -	

Example

```
//B (PROG1)           ; Block start
SUB (UP2)             ; Start of subprogram
  IF VAR1.val=="Otto"
    VAR1.val="Hans"
    RETURN             ; If the variable value = Otto, the value "Hans" is as-
                      ; signed to the variable, and the subprogram ends at this
                      ; point.
  ENDIF
  VAR1.val="Otto"      ; If the variable value ≠ Otto, the value "Otto" is as-
                      ; signed to the variable.
END_SUB              ; End of subprogram
//END                ; Block end
```

8.3.34 Recompile

Description

In the programming support system, it is possible to **recompile** NC code that has been generated with the GC function and to display the variable values in the input/output field of the associated entry dialog again.

Programming

Variables from the NC code are transferred to the dialog. At the same time, the variable values from the NC code are compared with the calculated variable values from the configuration file. If the values do not coincide, an error message is written to the log book because values have been changed during NC code generation.

If the NC code contains the same variable several times, it is evaluated at the point where it last occurs during recompilation. A warning is also written to the log book.

Variables not utilized in NC code during code generation are stored as user comment. The term "user comment" refers to all information required to recompile codes. User comment must not be altered.

Note

The block consisting of NC code and user comment can be recompiled only if it starts at the beginning of a line.

Examples:

The programm contains the following NC code:

```
DEF VAR1=(I//101)
OUTPUT (CODE1)
  "X" VAR1 " Y200"
  "X" VAR1 " Y0"
END_OUTPUT
```

The following code is then stored in the parts program:

```
;NCG#TestGC#\cus.dir\aeditor.com#CODE1#1#3#
X101 Y200
X101 Y0
;#END#
```

The Editor reads the following during recompilation:

```
X101 Y200
X222 Y0           ; The value for X has been changed in the part program (X101 → X222)
```

The following value is displayed for VAR1 in the input dialog: VAR1 = 222

See also

Generate code (GC) (Page 153)

8.3.35 Recompile without user comment

Description

In the Programming Support, it is possible to **recompile without user comments** the NC code that has been generated with the GC function and to display the variable values in the input/output field of the associated entry dialog again.

Programming

The GC command can be executed in the following way in order to suppress comment lines that are generated for standard code generation:

```
GC ("CODE1", D_NAME, 1)
```

Normally, the resulting code cannot be recompiled. The following steps are required in order to be able to recompile the cycle calls generated in this way:

- **Extend the file "easyscreen.ini"**

The section [RECOMPILE_INFO_FILES] is introduced into the "easyscreen.ini" file. In this section, all ini files are listed that contain descriptions for cycles recompiled without user comment:

```
[RECOMPILE_INFO_FILES]
IniFile01 = cycles1.ini
IniFile02 = cycles2.ini
```

Several ini files can be specified, whose names can be freely selected.

- **Creating an ini file for a cycle description**

Save the ini file with the cycle descriptions under the following path:

```
[System user-directory]/cfg
[System oem-directory]/cfg
[System addon-directory]/cfg
```

A separate section is required for each cycle. The section name corresponds to the name of the cycle:

```
[Cycle123]
Mname = TestGC
Dname = testgc.com
OUTPUT = Code1
Anzp = 3
Version = 0
Code_type = 1
Icon = cycle123.png
Desc_Text = This is describing text
```

Mname	Screen name
Dname	Name of the file in which the screen is defined
OUTPUT	Name of the relevant OUTPUT method
Anzp	Number of parameters of the screen to be recompiled (all with DEF-created variables, also help variables)
Version	(optional) version specification for cycle

Icon	(optional) icon for display in the machining step program, format *.png Screen size for corresponding resolution: 640 x 480 mm → 16 x 16 pixels 800 x 600 mm → 20 x 20 pixels 1024 x 768 mm → 26 x 26 pixels 1280 x 1024 mm → 26 x 26 pixels 1280 x 768 mm → 26 x 26 pixels Storage: [System user-directory]/ico/ico<resolution> Notes: - For resolutions of 1280, the folder for 1024 x 768 mm is used (only suitable for machining step programs). - The screen size is not just dependent on the resolution, but also on the font size set in the editor.
Desc_Text	(optional) Explanation text for display in the machining step program, max. length of string is 17 characters (only suitable for machining step programs)
Param_Text	(optional) Text for the parameter list T=%1 D=%2

Note

Notes on Icon, Desc_Text and Param_Text:

- The user icon is always displayed in the G code editor. The G code icon is always displayed in the ShopMill/ShopTurn editor. This helps to better distinguish between ShopMill/ShopTurn steps and NON-ShopMill/ShopTurn steps.
- The Run MyScreens step is dependent on the editor setting "Display cycles as machining step". This applies to both the G code and the JobShop editor. This means that when "Display cycles as machining step" = "YES", the "Desc_Text" of the Run MyScreens configuration is taken; when "NO", the cycle is displayed.
- Desc_Text and Param_Text
 - can be specified according to language via the \$xxxx notation.
 - The parameters of the cycle call generated can be accessed via %1, %2, etc. This involves the placeholder being replaced by the parameter that is specified after the '%' in the parameter list generated.

Example

```
//M(TestGC/"Code generation:")
DEF VAR1 = (R//1)
DEF VAR2 = (R//2)
DEF D_NAME
LOAD
VAR1 = 123
```

```

VAR2 = -6
END_LOAD
OUTPUT (CODE1)
    "Cycle123(" VAR1 " ," VAR2 " )"
    "M30"
END_OUTPUT

PRESS (VS1)
    D_NAME = "\MPF.DIR\MESSEN.MPF"
    GC ("CODE1", D_NAME)                                ;Write NC code from the OUTPUT method to
                                                         file \MPF.DIR\MESSEN.MPF:
                                                         Cycle123(123, -6)
                                                         M30
END_PRESS

```

Supplementary conditions

- The "Recompile without user comment" functionality does not have the full range of functions as "Recompile with user comment". Typical cycle calls, such as MYCYCLE(PAR1, PAR2, PAR3, ...), are supported during "Recompile without user comment". However, there must not be a user comment in the line of the function call. Optional parameters that are not transferred during the function call and are of the string S type must however be at least specified with empty quotation marks, e.g. "". Otherwise, "Run MyScreens" attempts to fill these parameters using commas so that the "filled cycle call" can then be recompiled.
- Parameters of the string type must not have any commas or semicolons in the string to be transferred.
- During "Recompile without user comment", all variables contained in the OUTPUT method must always be within the brackets so that the "Fill in missing cycle parameters with commas" functionality can take effect.

Example:

Permitted:

```

OUTPUT
    "MYCYCLE (" MYPAR1 " ," MYPAR2 " ," MYPAR3 " )"
END_OUTPUT

```

Not permitted (variable MYCOMMENT is positioned after the closing bracket.):

```

OUTPUT
    "MYCYCLE (" MYPAR1 " ," MYPAR2 " ," MYPAR3 " )" MYCOMMENT
END_OUTPUT

```

8.3.36 Search Forward, Search Backward (SF, SB)

Description

The **SF, SB (Search Forward, Search Backward)** function is used to search for a string from the current cursor position in the NC program currently selected in the Editor and to output its value.

Programming

Syntax:	SF ("String")	
Designation:	Search Forward: Search forward from the current cursor position	
Syntax:	SB ("String")	
Designation:	Search Backward: Search backward from the current cursor position	
Parameters:	String	Text to be found

Rules governing text search

- A blank must be inserted before and after the search concept unit, consisting of search string and its value, in the currently selected NC program.
- The system does not search for concepts within comment text or other strings.
- The value to be output must be a numerical expression. Expressions in the form of "X1=4+5" are not recognized.
- The system recognizes hexadecimal constants in the form of X1='HFFFF', binary constants in the form of X1='B10010' and exponential components in the form of X1='-.5EX-4'.
- The value of a string can be output if it contains the following between string and value:
 - Nothing
 - Blanks
 - Equality sign

Example

The following notations are possible:

```
X100 Y200                ; The variable Abc is assigned the value 200
Abc = SB("Y")
X100 Y 200                ; The variable Abc is assigned the value 200
Abc = SB("Y")
X100 Y=200                ; The variable Abc is assigned the value 200
Abc = SB("Y")
```

8.3.37 SL_HMI_INSTALL_DIR

Description

The SL_HMI_INSTALL_DIR function returns the path of the installation directory of SINUMERIK Operate.

Programming

Syntax:	SL_HMI_INSTALL_DIR()	
Description:	Determines the installation directory of SINUMERIK Operate	
Parameters:	- None -	

8.3.38 SL_TEMP_DIR

Description

The SL_TEMP_DIR function returns a path for temporary files in SINUMERIK Operate.

Note

The contents of this directory are not persistent, i.e. they are deleted each time SINUMERIK Operate is started.

Programming

Syntax:	SL_TEMP_DIR()	
Description:	Determines the path of the SINUMERIK Operate non-persistent (volatile) directory	
Parameters:	- None -	

8.3.39 STRING functions

Overview

The following functions enable strings to be processed:

- Determine length of string
- Find a character in a string
- Extract substring from left
- Extract substring from right
- Extract substring from mid-string

8.3 Functions

- Replace substring
- Compare strings
- Insert a string in another string
- Remove a string from a string
- Remove spaces (from left or from the right)
- Insert values or strings with formatting identifiers

LEN function: Length of a string

Syntax:	LEN (string varname)	
Description:	Determines the number of characters in a string	
Parameters:	string	Every valid string expression. NULL is output if string is empty.
	varname	Any valid declared variable name
	Only one of the two parameters is allowed.	

Example

```

DEF VAR01
DEF VAR02

LOAD
  VAR01="HALLO"
  VAR02=LEN (VAR01)           ; Result = 5
END_LOAD

```

INSTR function: Search for character in string

Syntax:	INSTR (Start, String1, String2 [,Direction])	
Description:	Searches for characters	
Parameters:	Start	Starting position for searching for string1 in string2. Enter 0 to start searching at the beginning of string2.
	String1	Character that is being searched for.
	String2	Character string in which the search is being made.
	Direction (optional)	Direction in which the search is being made. 0: From left to right (default setting) 1: From right to left
	0 is returned if string1 does not occur in string2.	

Example

```

DEF VAR01
DEF VAR02

LOAD
  VAR01="HALLO/WELT"
  VAR02=INST(1,"/",VAR01)      ; Result = 6
END_LOAD

```

LEFT Function: String from left

Syntax:	LEFT (string, length)	
Description:	LEFT returns a string containing the specified number of characters starting from the left-hand side of a string.	
Parameters:	string	Character string or variable with the character string to be processed
	length	Number of characters that are to be read out

Example

```

DEF VAR01
DEF VAR02

LOAD
  VAR01="HALLO/WELT"
  VAR02=LEFT(VAR01,5)          ; Result = "HELLO"
END_LOAD

```

RIGHT function: String from right

Syntax:	RIGHT (string, length)	
Description:	RIGHT returns a string containing the specified number of characters starting from the right-hand side of a string.	
Parameters:	string	Character string or variable with the character string to be processed
	length	Number of characters that are to be read out

Example

```

DEF VAR01
DEF VAR02

```

```

LOAD
  VAR01="HALLO/WELT"
  VAR02=LEFT (VAR01,4)           ; Result = "WORLD"
END_LOAD

```

MIDS function: String from mid-string

Syntax:	MIDS (string, start [, length])	
Description:	MIDS returns a string containing the specified number of characters starting at the specified position in the string.	
Parameters:	string	Character string or variable with the character string to be processed
	start	Start from where characters are to be read in the string
	length	Number of characters that are to be read out

Example

```

DEF VAR01
DEF VAR02
LOAD
  VAR01="HALLO/WELT"
  VAR02=LEFT (VAR01,4,4)           ; Result = "LO/W"
END_LOAD

```

REPLACE Function: Replacing characters

Syntax:	REPLACE (string, FindString, ReplaceString [, start [, count]])	
Description:	REPLACE replaces a character/string in a string with another character/string.	
Parameters:	string	String in which FindString is to be replaced with ReplaceString.
	FindString	String to be replaced
	ReplaceString	Replacement string (is used instead of the FindString)
	start	Starting position for search and replace operations
	count	Number of characters that are to be searched from the starting position after FindString
Return value:		
	string = Empty string	Copy of string
	FindString = Empty string	Copy of string
	ReplaceString = Empty string	Copy of string, in which all occurrences of FindString are deleted
	start > Len(String)	Empty string
	count = 0	Copy of string

STRCMP function: Compare strings

Syntax:	STRCMP (string1, string2 [, CaseInsensitive])	
Description:	STRCMP compares a character string with another character string.	
Parameters:	string1	Character string that is to be compared with a second character string
	string2	Character string that is to be compared with the first character string
	CaseInsensitive	Comparison with/without consideration of upper/lower case: Not specified or FALSE = upper/lower case is considered TRUE = upper/lower case is not considered

Example

REG[0]=STRCMP("Hugo", "HUGO")			; Result = 32
			; (> 0, strings are not identical)
REG[0]=STRCMP("Hugo", "HUGO", TRUE)			; Result = 0
			; (== 0, strings are identical)

STRINSERT function: Insert string

Syntax:	STRINSERT (string1, string2 , insert position)	
Description:	STRINSERT inserts a character string at a specific position in a character string.	
Parameters:	string1	Character string in which a character string is to be inserted
	string2	Character string that is to be inserted
	insert position	Position at which the character string is to be inserted

Example

REG[0]=STRINSERT("Hello!", " world", 5)			; Result = "Hello world!"
---	--	--	---------------------------

STRREMOVE function: Remove string

Syntax:	STRREMOVE (string1, remove position , count)	
Description:	STRREMOVE removes a specific number of characters at a specific position within a character string.	
Parameters:	string1	Character string from which characters are to be removed
	remove position	Position at which characters are to be removed from the character string
	count	Number of characters to be removed

Example

```
REG[0]=STRREMOVE("Hello world!", 5, 6) ; Result = "Hello!"
```

TRIMLEFT function: Remove blanks from the left of the string

Syntax:	TRIMLEFT (string1)	
Description:	TRIMLEFT removes blanks on the left from a character string.	
Parameters:	string1	Character string from which blanks are to be removed from the left of the character string

Example

```
REG[0]=TRIMLEFT(" Hello!") ; Result = "Hello!"
```

TRIMRIGHT function: Remove blanks from the right of the string

Syntax:	TRIMRIGHT (string1)	
Description:	TRIMLEFT removes blanks on the right from a character string.	
Parameters:	string1	Character string from which blanks are to be removed from the right of the character string

Example

```
REG[0]=TRIMRIGHT("Hello! ") ; Result = "Hello!"
```

FORMAT function: Insert values or string with formatting identifier

Syntax:	FORMAT (Text with formatting identifier [, Value1] ... [, Value28])	
Description:	Through the use of formatting identifiers, the FORMAT function enables up to 28 values or strings to be inserted at specified positions in a specific text.	

Formatting identifiers:	Syntax	%[Flags] [Width] [.decimal places] type
	Flags	Optional character for defining output formatting: • Right-justified or left-justified (" ") for left-justified • Add leading zeros ("0") • default: Fill in with blanks if the value to be output has fewer positions than specified with [Width].
	Width	The argument defines the minimum output width for a non-negative number. If the value has fewer positions than specified by the argument, the missing spaces are filled with blanks.
	Decimal places	With floating-point numbers, the optional parameter defines the number of decimal places.
	Type	The type character defines which data formats are transferred to the print statement. These characters need to be specified. • d: Integer value • f: Floating-point number • s: String • o: Octal • x: Hexadecimal • b: Binary

Example

```

DEF VAR1
DEF VAR2
LOAD
VAR1 = 123
VAR2 = FORMAT("Hello %08b %.2f %s!", VAR1 + 1, 987.654321, "world")
; Result = "Hello 01111100 987.65 world!"
END_LOAD

```

See also

Use of strings (Page 103)

8.3.40 WHILE/UNTIL loops

Description

A loop can be implemented with the DO LOOP commands. Depending on the configuration, it is run through as long as a condition is satisfied (WHILE) or until a condition occurs (UNTIL).

As loops can impair the system performance, depending on the configuration, they should be used carefully and without time-intensive actions in the loops.

It is recommended that a register (REG[]) be used as run variable, because normal display variables (particularly those with system or user variables connection) also impair the system performance due to the frequent updates or write operations.

The runtime of "Run MyScreens" methods can be determined with the DEBUG function (see Section DEBUG (Page 145)). Problems caused by loops (high CPU load, reduced response capability) may be identified in this way.

Note

As each FOR loop can be replaced by a WHILE loop, the syntax to formulate a FOR loop is not supported in EasyScreen.

Programming

```
DO
    <instructions>
LOOP_WHILE <Condition to continue the loop>

DO
    <instructions>
LOOP_UNTIL <Condition to terminate the loop>

DO_WHILE <Condition to continue the loop>
    <instructions>
LOOP

DO_UNTIL <Condition to terminate the loop>
    <instructions>
LOOP
```

Example

```
REG[0] = 5
DO
    DEBUG("OUTER: " << REG[0])
    REG[0] = REG[0] + 1
    REG[1] = -5

    DO
        DEBUG("INNER: " << REG[1])
```

```
        REG[1] = REG[1] + 1
    LOOP_WHILE REG[1] < 0

LOOP_WHILE REG[0] < 10
```

```
    REG[0] = 5
DO
    DEBUG("OUTER: " << REG[0])
    REG[0] = REG[0] + 1
    REG[1] = -5

    DO
        DEBUG("INNER: " << REG[1])
        REG[1] = REG[1] + 1
        LOOP_UNTIL 0 <= REG[1]

LOOP_WHILE 10 > REG[0]
```

```
    REG[0] = 5
DO_WHILE 10 > REG[0]
    DEBUG("OUTER: " << REG[0])
    REG[0] = REG[0] + 1
    REG[1] = -5

    DO_UNTIL 0 <= REG[1]
        DEBUG("INNER: " << REG[1])
        REG[1] = REG[1] + 1
    LOOP

LOOP
```

```
    REG[0] = 5
DO_WHILE 10 > REG[0]
    DEBUG("OUTER: " << REG[0])
    REG[0] = REG[0] + 1
    REG[1] = -5

    DO
        DEBUG("INNER: " << REG[1])
```

```

    REG[1] = REG[1] + 1
    LOOP_UNTIL 0 <= REG[1]

LOOP

```

8.3.41 Cyclic execution of scripts: START_TIMER, STOP_TIMER

Description

SUB methods can be called cyclically with the aid of timers. The START_TIMER() and STOP_TIMER() functions are available for this purpose.

Note

Only one timer can be configured for each SUB method.

Programming

Syntax:	START_TIMER ("SUB-Name", Interval)	
Description:	Starts cyclic processing of a SUB method	
Parameters:	SUB name:	Name of the SUB method to be called cyclically
	Interval:	Interval in milliseconds

Syntax:	STOP_TIMER ("SUB name", Interval)	
Description:	Stops cyclic processing of a SUB method	
Parameters:	SUB name:	Name of the SUB method whose timer is to be stopped.

Example

```

//M(TimerSample/"My timer")
DEF MyVariable=(I//0/,"Number of cyclic calls:"/WR1)
VS1=("Start%ntimer")
VS2=("Stop%ntimer")

SUB(MyTimerSub)
    MyVariable = MyVariable + 1
END_SUB

```

```
//M(TimerSample/"My timer")  
PRESS(VS1)  
    ;Calls SUB "MyTimerSub" every 1000 milliseconds  
    START_TIMER("MyTimerSub", 1000)  
END_PRESS  
  
PRESS(VS2)  
    STOP_TIMER("MyTimerSub")  
END_PRESS
```

If START_TIMER is called again for a timer already assigned to a SUB method, then the new interval is taken over if it is different. Otherwise, the second call is ignored.

The smallest interval for the system is 100 milliseconds.

If STOP_TIMER is called for a SUB method for which no timer is currently running, the call is ignored.

Graphic and logic elements

9.1 Line, dividing line, rectangle, circle and ellipse

9.1.1 Defining graphic elements

Description

Lines, dividing lines, rectangles and ellipses/circles are configured in the LOAD method:

- Transparent rectangles are created by setting the fill color to the system background color.
- With the ELLIPSE element, a circle is created by setting the height and the width to the same value.
- Horizontal and vertical dividing lines always have the exact window width or window height. No scrollbars are produced by dividing lines.

If you previously used the RECT element to display dividing lines, e.g.

RECT(305,0,1,370,0,0,1), this is detected by the Programming Support and automatically converted to V_SEPARATOR(305,1,"#87a5cd", 1). This applies to both vertical and horizontal dividing lines.

LINE element

Programming:

Syntax:	LINE (x1, y1, x2, y2, color, style, tag, visible)	
Description:	Defines a line	
Parameter:	x1	Start point x-coordinate
	y1	Start point y-coordinate
	x2	End point x-coordinate
	y2	End point y-coordinate
	color	Color of the line
	style	Line style: 1 = solid 2 = dashed 3 = dotted 4 = dashed and dotted
	tag	Use this tag to show, hide or delete a graphic element or group of graphic elements with the functions SHOW_GRAPHIC, HIDE_GRAPHIC and DELETE_GRAPHIC.
	visible	Graphic element visible (TRUE/FALSE)

RECT element

Programming:

Syntax:	RECT (x, y, w, h, frame color, fill color, style, tag, visible)	
Description:	Defines a rectangle	
Parameter:	x	x-coordinate, top left
	y	y-coordinate, top left
	w	Width
	h	Height
	frame color	Color of the border
	fill color	Fill color
	style	Border style: 1 = solid 2 = dashed 3 = dotted 4 = dashed and dotted
	tag	Use this tag to show, hide or delete a graphic element or group of graphic elements with the functions SHOW_GRAPHIC, HIDE_GRAPHIC and DELETE_GRAPHIC.
	visible	Graphic element visible (TRUE/FALSE)

ELLIPSE element

Programming:

Syntax:	ELLIPSE(x, y, w, h, frame color, fill color, style, tag, visible)	
Description:	Defines an ellipse or circle	
Parameter:	x	x-coordinate, top left
	y	y-coordinate, top left
	w	Width
	h	Height
	frame color	Color of the border
	fill color	Fill color
	style	Border style: 1 = solid 2 = dashed 3 = dotted 4 = dashed and dotted
	tag	Use this tag to show, hide or delete a graphic element or group of graphic elements with the functions SHOW_GRAPHIC, HIDE_GRAPHIC and DELETE_GRAPHIC.
	visible	Graphic element visible (TRUE/FALSE)

A circle is created when the values for height and width are the same.

V_SEPARATOR element

Programming:

Syntax:	V_SEPARATOR (x,w,color,pen)	
Description:	Defines a vertical dividing line	
Parameter:	x	x position
	pen width	Line weight
	color	Color
	style	Line style: 1 = solid 2 = dashed 3 = dotted 4 = dashed and dotted
	tag	Use this tag to show, hide or delete a graphic element or group of graphic elements with the functions SHOW_GRAPHIC, HIDE_GRAPHIC and DELETE_GRAPHIC.
	visible	Graphic element visible (TRUE/FALSE)

H_SEPARATOR element

Programming:

Syntax:	H_SEPARATOR (y,h,color,pen)	
Description:	Defines a horizontal dividing line	
Parameter:	y	y position
	pen width	Line weight
	color	Color
	style	Line style: 1 = solid 2 = dashed 3 = dotted 4 = dashed and dotted
	tag	Use this tag to show, hide or delete a graphic element or group of graphic elements with the functions SHOW_GRAPHIC, HIDE_GRAPHIC and DELETE_GRAPHIC.
	visible	Graphic element visible (TRUE/FALSE)

More information

The Graphic functions (Page 192) section describes the features SHOW_GRAPHIC, HIDE_GRAPHIC, CLEAR_BACKGROUND, and DELETE_GRAPHIC. These functions allow you to control the display of the graphic elements.

9.1.2 Graphic functions

Overview

The following graphic functions are available:

- CLEAR_BACKGROUND
- DELETE_GRAPHIC
- HIDE_GRAPHIC
- SHOW_GRAPHIC

You can apply these functions to the LINE, RECT, ELLIPSE, V_SEPARATOR and H_SEPARATOR (Page 189) graphic elements.

CLEAR_BACKGROUND function: Deletion of graphic elements

The CLEAR_BACKGROUND function allows you to delete graphic elements.

Syntax:	CLEAR_BACKGROUND()	
Description:	Deletion of graphic elements. The memory space taken up by the graphic objects is freed.	
Parameter(s):	- None -	

DELETE_GRAPHIC function: Deletion of a graphic element or group of graphic elements

The DELETE_GRAPHIC function allows you to delete a specific graphic element or group of graphic elements. A value in the "tag" parameter must be defined for the corresponding graphic elements.

- In contrast to the the CLEAR_BACKGROUND function, you can delete specific graphic elements with DELETE_GRAPHIC.
- In contrast to the the HIDE_GRAPHIC function, the memory space taken up by the graphic objects can be freed with DELETE_GRAPHIC.

Syntax:	DELETE_GRAPHIC(tag)	
Description:	Deletion of a graphic element or group of graphic elements whose value is the same as that of the "tag" parameter.	
Parameter(s):	tag	The "tag" parameter can be defined in the graphic elements. You can also define multiple graphic elements with the same value to form a group of graphic elements.

Example

```

LINE(0, 10, 100, 10, "black", "dotted", 1, true)
...
LINE(0, 10, 100, 10, "red", "dotted", 5, true)
LINE(0, 20, 100, 20, "red", "dotted", 5, true)

```

```

LINE(0, 30, 100, 30, "red", "dotted", 5, true)
...
DELETE_GRAPHIC(5)

```

;the 3 graphic elements
of type LINE with tag=5
are deleted

HIDE_GRAPHIC function: Hiding of a graphic element or group of graphic elements

The HIDE_GRAPHIC function allows you to hide a specific graphic element or group of graphic elements. A value in the "tag" parameter must be defined for the corresponding graphic elements.

Syntax:	HIDE_GRAPHIC(tag)	
Description:	Hiding of a graphic element or group of graphic elements whose value is the same as that of the "tag" parameter.	
Parameter(s):	tag	The "tag" parameter can be defined in the graphic elements. You can also define multiple graphic elements with the same value to form a group of graphic elements.

Example

```

LINE(0, 10, 100, 10, "black", "dotted", 1, true)
...
LINE(0, 10, 100, 10, "red", "dotted", 5, true)
LINE(0, 20, 100, 20, "red", "dotted", 5, true)
LINE(0, 30, 100, 30, "red", "dotted", 5, true)
...
HIDE_GRAPHIC(5)

```

;the 3 graphic elements
of type LINE with tag=5
are hidden

SHOW_GRAPHIC function: Showing of a graphic element or group of graphic elements

The SHOW_GRAPHIC function allows you to show a specific graphic element or group of graphic elements. A value in the "tag" parameter must be defined for the corresponding graphic elements.

Syntax:	SHOW_GRAPHIC(tag)	
Description:	Showing of a graphic element or group of graphic elements whose value is the same as that of the "tag" parameter.	
Parameter(s):	tag	The "tag" parameter can be defined in the graphic elements. You can also define multiple graphic elements with the same value to form a group of graphic elements.

Example

```

LINE(0, 10, 100, 10, "black", "dotted", 1, true)
...
LINE(0, 10, 100, 10, "red", "dotted", 5, true)
LINE(0, 20, 100, 20, "red", "dotted", 5, true)
LINE(0, 30, 100, 30, "red", "dotted", 5, true)
...
SHOW_GRAPHIC(5)

```

;the 3 graphic elements
of type LINE with tag=5
are shown

9.2 Defining an array

Definition

An array can be used to organize data of the same data type stored in the memory in such a way that it is possible to access the data via an index.

Description

Arrays can be one- or two-dimensional. A one-dimensional array is treated like a two-dimensional array with just one line or column.

Arrays have start identifier //A and end identifier //END. The number of lines and columns is optional. An array is structured in the following way:

Programming

Syntax:	//A(Identifier) (a/b...) (c/d...) ... //END	
Description:	Defines array	
Parameters:	Identifier	Name of array
	a, b, c, d	Values of array Values of the STRING type must be enclosed in double quotation marks.

Example

```

//A(Thread)
; Size/lead/core diameter

```

```

(0.3 / 0.075 / 0.202)
(0.4 / 0.1   / 0.270)
(0.5 / 0.125 / 0.338)
(0.6 / 0.15  / 0.406)
(0.8 / 0.2   / 0.540)
(1.0 / 0.25  / 0.676)
(1.2 / 0.25  / 0.676)
(1.4 / 0.3   / 1.010)
(1.7 / 0.35  / 1.246)
//END

```

9.2.1 Accessing the value of an array element

Description

The value of an array access operation can be transferred with property Value (identifier.val).

The line index (line number of the array) and the column index (column number of the array) each begin at 0. If a line index or column index is outside the array, the value 0 or a blank string is output and the ERR variable is set to TRUE. Variable ERR is also set to TRUE if a search concept cannot be found.

Programming

Syntax:	Identifier [Z,[M[,C]]].val or Identifier [Z,[M[,C]]]
Description:	Access to one-dimensional array with only one column
Syntax:	Identifier [S,[M[,C]]].val or Identifier [S,[M[,C]]] or
Description:	Access to one-dimensional array with only one line
Syntax:	Identifier [Z,S,[M[,C]]].val or Identifier [Z,S,[M[,C]]]
Description:	Access to two-dimensional array

9.2 Defining an array

Parameters:	Identifier:	Name of array	
	Z:	Line value (line index or search concept)	
	S:	Column value (column index or search concept)	
	M:	Access mode	
		0	Direct
		1	Searches the line, column directly
		2	Searches the column, line directly
		3	Searches
		4	Searches line index
		5	Searches column index
	C:	Compare mode	
		0	Search concept must be located in the range of values of the line or column.
		1	Search concept must be located exactly.
Example:	<pre>VAR1 = MET_G[REG[3],1,0].VAL ;Assign Var1 a value from array MET_G</pre>		

Access mode

- **"Direct" access mode**

With "Direct" access mode (M = 0), the array is accessed with the line index in Z and the column index in S. Compare mode C is not evaluated.

- **"Search" access mode**

In the case of access mode M = 1, 2 or 3, the search always commences in line 0 or column 0.

Mode M	Line value Z	Column value S	Output value
0	Line index	Column index	Value from line Z and column S
1	Search concept: Search in column 0	Column index of column from which value is read	Value from line found and column S
2	Line index of line from which return value is read	Search concept: Search in line 0	Value from line Z and column found
3	Search concept: Search in column 0	Search concept: Search in line 0	Value from line and column found
4	Search concept: Search in column S	Column index of search col- umn	Line index
5	Line index of search line.	Search concept: Search in line Z	Column index

Compare mode

When compare mode $C = 0$ is used, the content of the search line or search column must be sorted in ascending order. If the search concept is smaller than the first element or greater than the last, the value 0 or a blank string is output and the error variable ERR is set to TRUE.

When compare mode $C = 1$ is used, the search concept must be present in the search line or search column. If the search concept cannot be found, the value 0 or a blank string is output and the error variable ERR is set to TRUE.

9.2.2 Example Access to an array element

Prerequisite

Two arrays are defined below. These are the basis for the following examples:

```
//A(Thread)
```

```
(0.3 / 0.075 / 0.202)
(0.4 / 0.1   / 0.270)
(0.5 / 0.125 / 0.338)
(0.6 / 0.15  / 0.406)
(0.8 / 0.2   / 0.540)
(1.0 / 0.25  / 0.676)
(1.2 / 0.25  / 0.676)
(1.4 / 0.3   / 1.010)
(1.7 / 0.35  / 1.246)
```

```
//END
```

```
//A(Array2)
```

```
("DES" /      "PTCH" /      "CDM" )
(0.3 /      0.075 /      0.202 )
(0.4 /      0.1 /      0.270 )
(0.5 /      0.125 /      0.338 )
(0.6 /      0.15 /      0.406 )
(0.8 /      0.2 /      0.540 )
(1.0 /      0.25 /      0.676 )
(1.2 /      0.25 /      0.676 )
(1.4 /      0.3 /      1.010 )
(1.7 /      0.35 /      1.246 )
```

```
//END
```

Examples

- Access mode example 1:**
 The search concept is in Z. This key is always sought in column 0. The value from column S is output with the line index of the concept found.
`VAR1 = Thread[0.5,1,1] ;VAR1 has the value 0.125`
 Explanation:
 Search for value 0.5 in column 0 of "Thread" array and output the value found in column 1 of the same line.
- Access mode example 2:**
 The search concept is in S. This concept is always searched for in line 0. The value from line Z is output with the column index of the concept found:
`VAR1 = ARRAY2[3,"PTCH",2] ;VAR1 has the value 0.125`
 Explanation:
 Search for column containing "PTCH" in line 0 of array "Array2". Output the value from the column found and the line with index 3.
- Access mode example 3:**
 A search concept is in each of Z and S. The line index is searched for in column 0 with the concept in Z and the column index in line 0 with the concept in S. The value from the array is output with the line index and column index found:
`VAR1 = ARRAY2[0.6,"PTCH",3] ;VAR1 has the value 0.15`
 Explanation:
 Search for the line with the content 0.6 in column 0 of array "Array2", search for the column with the content "STG" in line 0 of Array2. Transfer the value from the line and column found to VAR1.
- Access mode example 4:**
 The search concept is in Z. S contains the column index of the column in which concept is being searched for. The line index of the concept found is output:
`VAR1 = Thread[0.125,1,4] ;VAR1 has the value 2`
 Explanation:
 Search for value 0.125 in column 1 of array "Thread" and transfer the line index of the value found to VAR1.
- Access mode example 5:**
 Z contains the line index of line in which concept is being searched for. The search concept is in S. The column index of the concept found is output:
`VAR1 = Thread[4,0.2,5,1] ;VAR1 has the value 1`
 Explanation:
 Search in line 4 of the "Thread" array for the value 0.2 and transfer the column index of the value found to VAR1. Comparison mode 1 was selected because the values of line 4 are not sorted in ascending order.

9.2.3 Scanning the status of an array element

Description

The Status property can be used to run a scan to find out whether an array access operation is supplying a valid value.

Programming

Syntax:	Identifier [Z, S, [M[,C]]].vld
Description:	The property can only be read.
Parameters:	Identifier Name of array
Return Value:	FALSE = invalid value TRUE = valid value

Example

```

DEF MPIT = (R///"MPIT",,"MPIT",""/wr3)
DEF PIT  = (R///"PIT",,"PIT",""/wr3)
PRESS (VS1)
    MPIT = 0.6
    IF MET_G[MPIT,0,4,1].VLD == TRUE
        PIT  = MET_G[MPIT,1,0].VAL
        REG[4] = PIT
        REG[1] = "OK"
    ELSE
        REG[1] = "ERROR"
    ENDIF
END_PRESS

```

9.3 Table description (grid)

Definition

In contrast to the array, the values of a table (grid) are continually updated. It is a tabular display of values that can come from the NC or PLC. The table is organized in columns and always has variables of the same type in one column.

Assignment

The reference to a table description is performed in the variables definition:

- The variables definition determines the values to be displayed, and the definition of table elements determines the appearance and arrangement on the screen window. The properties of the input/output fields from the definition line of the variables are taken over in the table.
- The visible area of the table is determined by the width and height of the input/output field. Any lines or columns than cannot be seen can be displayed by scrolling horizontally and vertically.

Table identifiers

Identifiers of a table containing NCK or PLC values of the same type, which can be addressed via a channel block. The table identifier is differentiated from limits or toggle fields by the addition of a % sign in front of it. The file containing the table description can be specified by adding a comma after the identifier and then inserting the name of the file.

Identifier of a table for values of the same type, e.g. from the NCK or PLC. The table identifier is specified at the position at which the limit values or the toggle field are configured. The table identifier starts with a leading % character. This can be followed by a file name with a comma as separator. It specifies the file in which the table description is defined. Per default, the table is sought in the configuration file in which the screen is configured.

A table definition can also be loaded dynamically, e.g. in the LOAD method via the Load Grid (LG) function.

System or user variable

This parameter remains empty for tables because the column definition lines contain detailed information about the variables to be displayed. The table description can be provided dynamically.

Example

Definition of a MyGridVar variable which displays a "MyGrid1" grid in its input/output field (distance from left: 100, distance from top: Standard, width: 350, height: 100).

```
DEF MyGridVar=(V/% MyGrid1////////100,,350,100)
```

See also

Parameters of variables (Page 91)

Load Grid (LG) (Page 161)

9.3.1 Defining a table (grid)

Description

The table block comprises:

- Header
- 1 to n column descriptions

Programming

Syntax:	//G(table identifier/table type/number of rows/ [attribute fixed row],[attribute fixed column])
Description:	Defines a table (grid)

Parameters:	Table identifier	The table identifier is used without a leading % sign. It can only be used once in a dialog.	
	Table type	0 (default)	Table for PLC or user data (NCK- and channel-specific data)
		1	and others, reserved
	Number of lines	Number of lines including header	
		The fixed line or fixed column is not scrolled. The number of columns is the number of columns configured.	
	Display of column header line	-1:	The column header line is not displayed
		0:	The column header line is displayed (default)
	Number of fixed columns	0:	No fixed column
		1 ... n:	Number of columns that are to be permanently visible, i.e. not scrolled horizontally

Examples

```
//G(grid1/0/5/-1,2)
```

Column header line is hidden and two fixed columns

```
//G(grid1/0/5/,1)
```

Column header line is displayed and one fixed column

```
//G(grid1/0/5)
```

Column header line is displayed and no fixed columns

9.3.2 Defining columns

Description

For tables (grids), it is advisable to use variables with an index. For PLC or NC variables, the index number with one or more indices is of significance.

The values displayed in a table can be modified directly within the restrictions of the rights granted by the attributes and within any defined limits.

Programming

Syntax:	(Type/Limits/Empty/Long text,column header/Attributes/Help display/System or user variable/Column width/Offset1, Offset2, Offset3) See also Extended configuration syntax (Page 45).
Description:	Defining columns

9.3 Table description (grid)

Parameters:	Similar to variables	
	Type	Data type
	Limits	Limit value MIN, limit value MAX
	Long text, column header	
	Attributes	
	Help display	
	System or user variable	As variable, PLC or NC variables should be entered in double quotation marks.
	Column width	Entry in pixels.
	Offset	The increment sizes to increment each index in order to fill the column are specified in the assigned offset parameter: • Offset1: Step width for the 1st index • Offset2: Step width for the 2nd index • Offset3: Step width for the 3rd index

Column header from text file

The column header can be entered as text or text number (\$8xxxx) and is not scrolled.

Modifying column properties

The column properties which can be modified dynamically (written) are:

- Limits (min,max),
- Column header (st),
- Attributes (wr, ac and li),
- Help screens (hlp)

Column properties are modified via the variable identifier in the definition line and the column index (starting at 1).

Example: `VAR1[1].st="Column 1"`

The wr, ac and li attributes can be specified for column definitions.

See also

Load Grid (LG) (Page 161)

9.3.3 Focus control in the table (cell)

Description

The Row and Col properties can be used to set and calculate the focus within a table:

- Identifier.**Row**
- Identifier.**Col**

Programming

Each cell in a table has the Val and Vld properties.

In order to read and write cell properties, a line and column index must be specified in addition to the variable identifiers from the definition list.

Syntax:	Identifier[Line index, column index].val or Identifier[Line index, column index]
Description:	Val properties
Syntax:	Identifier[Line index, column index].vld
Description:	Vld properties

Example

```
Var1[2,3].val=1.203
```

If the line and column indices are not specified, the indices of the focused cell apply. This corresponds to:

```
Var1.Row =2
```

```
Var1.Col=3
```

```
Var1.val=1.203
```

9.4 Custom widgets

9.4.1 Defining custom widgets

Description

User-specific display elements are configured in the dialog using a custom widget.



Software option

In order to use custom widgets in dialog boxes, you require the following additional software option:

"SINUMERIK Integrate Run MyHMI /3GL" (6FC5800-0AP60-0YB0)

Programming

Definition:	DEF (name)	
Syntax:	(W//"/", "(library name).(class name)"/"/a,b,c,d);	
Description:	W	Defining custom widgets
Parameters:	Name	Custom widget name, freely selectable
	Library name	Can be freely selected, name of the dll (Windows) or (Linux) library file
	Class name	Freely selectable, name of the class function from the previously named library
	a, b, c, d	Position and size of the configuration

Example

A custom widget is defined in the dialog configuration in the following way:

```
DEF Cus = (W//"/", "slestestcustomwidget.SlEsTestCustomWidget"/"/20,20,250,100);
```

9.4.2 Structure of the custom widget library

Description

Essentially, the custom widget library contains a defined class. The name of this class must be specified in the dialog configuration in addition to the library names. Starting from library names, "Run MyScreens" accesses a dll file with the same name, e.g.:

slestestcustomwidget.dll

Programming

The class definition of the dll file should look like this:

```
#define SLESTESTCUSTOMWIDGET_EXPORT Q_DECL_EXPORT

class SLESTESTCUSTOMWIDGET_EXPORT SlEsTestCustomWidget : public QWidget
{
    Q_OBJECT
    ....
public slots:
    bool serialize(const QString& szFilePath, bool bIsStoring);
    ....
}
```

9.4.3 Structure of the custom widget interface

Description

The library is supplemented by an interface in order to display the custom widget in the dialog. This contains macro definitions with which "Run MyScreens" initiates the custom widget. The interface is available in the form of a cpp file. The file name can be freely selected, e.g.: `sleswidgetfactory.cpp`

Programming

The interface is defined as follows:

```
#include "slestestcustomwidget.h"      ; The header file for the relevant custom wid-
                                      ets is inserted at the beginning of the file

....

//Makros                               ; Macro definitions are not changed

....

WIDGET_CLASS_EXPORT(SlEsTestCustom-   ; The relevant custom widget is declared at
Widget)                               the end of the file
```

Example

Content of the file `sleswidgetfactory.cpp` for a custom widget with the class name `SlEsTestCustomWidget`:

```
#include <Qt/qglobal.h>
#include "slestestcustomwidget.h"

////////////////////////////////////
// MAKROS FOR PLUGIN DLL-EXPORT - DO NOT CHANGE
////////////////////////////////////

#ifndef Q_EXTERN_C
#ifdef __cplusplus
#define Q_EXTERN_C    extern "C"
#else
#define Q_EXTERN_C    extern
#endif
#endif

#define SL_ES_FCT_NAME(PLUGIN) sl_es_create_ ##PLUGIN
#define SL_ES_CUSTOM_WIDGET_PLUGIN_INSTANTIATE( IMPLEMENTATION , PARAM) \
{ \
    IMPLEMENTATION *i = new PARAM; \
```

```

    return i; \
}

#ifdef Q_WS_WIN
#   ifdef Q_CC_BOR
#       define EXPORT_SL_ES_CUSTOM_WIDGET_PLUGIN(PLUGIN,PARAM) \
Q_EXTERN_C __declspec(dllexport) void* \
__stdcall SL_ES_FCT_NAME(PLUGIN) (QWidget* pParent) \
SL_ES_CUSTOM_WIDGET_PLUGIN_INSTANTIATE( PLUGIN,PARAM )
#   else
#       define EXPORT_SL_ES_CUSTOM_WIDGET_PLUGIN(PLUGIN,PARAM) \
Q_EXTERN_C __declspec(dllexport) void* SL_ES_FCT_NAME(PLUGIN) \
(QWidget* pParent) \
SL_ES_CUSTOM_WIDGET_PLUGIN_INSTANTIATE( PLUGIN,PARAM )
#   endif
#else
#   define EXPORT_SL_ES_CUSTOM_WIDGET_PLUGIN(PLUGIN,PARAM) \
Q_EXTERN_C void* SL_ES_FCT_NAME(PLUGIN) (QWidget* pParent) \
SL_ES_CUSTOM_WIDGET_PLUGIN_INSTANTIATE( PLUGIN,PARAM )
#endif

#define WIDGET_CLASS_EXPORT(CLASSNAME) \
EXPORT_SL_ES_CUSTOM_WIDGET_PLUGIN(CLASSNAME,CLASSNAME(pParent))

////////////////////////////////////
// FOR OEM USER - please declare here your widget classes for export
////////////////////////////////////

WIDGET_CLASS_EXPORT(SlEsTestCustomWidget)

```

9.4.4 Interaction between custom widget and dialog box - Automatic data exchange

Custom widgets interact with dialog boxes and can display values or manipulate them.

Conditions

Automatic data exchange takes place under the following conditions:

Condition	Direction
When starting or recompiling a dialog	Dialog → custom widget
When executing the GC command for generating cycle calls	Custom widget → Dialog

Programming

The following definitions are necessary for the interaction:

Expansion of the dialog configuration

Definition:	DEF (variable)	
Syntax:	((type)//5/"", "(variable)", ""/wr2/)	
Variable type:	Type	Standard input field (no grid or toggle) with any data type (no W)
Parameters:	Variable	Any designation of a variable for data exchange
Input mode:	wr2	Reading and writing

Example

```
DEF CUSVAR1 = (R//5/"", "CUSVAR1", ""/wr2/)
```

Expansion of the class definition

In the class definition of the custom widgets, a QProperty must be created whose name is identical to the selected variable of the dialog configuration, e.g.:

```
Q_PROPERTY(double CUSVAR1 READ cusVar1 WRITE setCusVar1);
```

Example

The class definition of the dll file should look like this:

```
#define SLESTESTCUSTOMWIDGET_EXPORT Q_DECL_EXPORT

class SLESTESTCUSTOMWIDGET_EXPORT SlEsTestCustomWidget : public QWidget
{
    Q_OBJECT
    Q_PROPERTY(double CUSVAR1 READ cusVar1 WRITE setCusVar1);
    ....
    ....
}
```

9.4.5 Interaction between custom widget and dialog box - Manual data exchange

Besides automatic data exchange, manual data exchange is also possible. Data exchange is dynamic, i.e. takes place while the dialog box is running. The following actions are possible:

- Properties of the custom widget can be read and written.
- Methods of the custom widget can be called from the Run MyScreens configuration.
- A response to a particular signal of the custom widget can be implemented in order to call subprograms (SUB) in the Run MyScreens configuration.

9.4.5.1 Reading and writing properties

Description

The functions `ReadCWProperties` and `WriteCWProperties` are provided in the Run MyScreens configuration for reading and writing properties of the custom widgets.

Programming

Syntax:	ReadCWProperty ("Variablename", "Propertyname")	
Description:	Reading a property of a custom widget	
Parameters:	Variablename	Name of a dialog box variable to which a custom widget is assigned
	Propertyname	Name of the custom widget property to be read
Return value:	Current value of the custom widget property	

Syntax:	WriteCWProperty ("Variablename", "Propertyname", "Value")	
Description:	Writing the property of a custom widget	
Parameters:	Variable name	Name of a dialog box variable to which a custom widget is assigned
	Propertyname	Name of the custom widget property to be written
	Value	Value to be written to the property of the custom widget

Examples

Example 1:

Read property "MyStringVar" of the custom widget that is linked to dialog box variable "MyCWVar1" and assign the value to register 7.

Custom widget class declaration:

```
class SLESTESTCUSTOMWIDGET_EXPORT SLEstTestCustomWidget : public QWidget
{
    Q_OBJECT
    Q_PROPERTY(QString MyStringVar
                READ myStringVar
                WRITE setMyStringVar);
    ...
}
```

Dialog box configuration:

```

DEF MyCWVar1 = (W///,"slesteTestCustomWidget.SlEsTestCustomWidget")
PRESS (VS1)
    REG[7]=ReadCWProperty("MyCWVar1", "MyStringVar")
END_PRESS

```

Example 2:

Write the result of the calculation "3 + sin(123.456)" into property "MyRealVar" of the custom widget that is linked to dialog box variable "MyCWVar1."

Custom widget class declaration:

```

class SLESTESTCUSTOMWIDGET_EXPORT SlEsTestCustomWidget : public QWidget
{
    Q_OBJECT
    Q_PROPERTY(double MyRealVar
                READ myRealVar
                WRITE setMyRealVar);
    ...
}

```

Dialog box configuration:

```

DEF MyCWVar1 = (W///,"slesteTestCustomWidget.SlEsTestCustomWidget")
PRESS (VS1)
    WriteCWProperty("MyCWVar1", "MyRealVar", 3 + sin(123.456))
END_PRESS

```

9.4.5.2 Executing a method of the custom widget**Description**

The function CallCWMethod is available in the Run MyScreens configuration for executing methods of the custom widget.

The custom widget method to be called must have no more than 10 transfer parameters.

The following transfer parameter data formats are supported:

- bool
- uint
- int
- double
- QString
- QByteArray

Programming

Syntax:	CallCWMMethod ("Variablename", "Methodname[, Argument 0][, Argument 1 ...[,Argument 9]")	
Description:	Calling a custom widget method	
Parameters:	Variable name	Name of a dialog box variable to which a custom widget is assigned
	Method name	Name of the custom widget name to be called
	Argument 0 - 9	Transfer parameter for the custom widget method Supported data formats: see above Note: The transfer parameters are always transferred with "ByVal," i.e. only the value is transferred and not, for example, the reference to a variable.
Return value:	Return value of the custom widget method The following transfer parameter data formats are supported: • void • bool • uint • int • double • QString • QByteArray Note: Even if the data format of the return value of the custom widget method is "void," it must be formally assigned to a variable, for example.	

Example

Custom widget class declaration:

```
class SLESTESTCUSTOMWIDGET_EXPORT SLEstTestCustomWidget : public QWidget
{
    Q_OBJECT
    public slots:
        void myFunc1(int nValue, const QString& szString, double dValue);
    ...
}
```

Dialog box configuration:

```
DEF MyCWVar1 = (W///,"sleestestcustomwidget.SLEstTestCustomWidget")

DEF MyStringVar1 = (S)
DEF MyRealVar = (R)

PRESS (VS3)
    REG[9] = CallCWMMethod("MyCWVar1", "myFunc1", 1+7, MyStringVar1, sin(MyRealVar) -
8)
END_PRESS
```

Note

The custom widget must implement the "serialize" method. Here, you have the option of writing the internal data of a custom widget to a specified file, or restoring it again. This is especially necessary, if, with the "Run MyScreens" screen open, you change to another operating area and then return again. Otherwise, internal data are lost when redisplaying.

Syntax:	public slots: bool serialize (const QString& szFilePath, bool blsStoring);	
Description:	Reading and writing internal data and states to and from a file	
Parameters:	szFilePath	Name of the file with complete path data, in which the internal data and states of the custom widget are written to – or from which they are to be read. If necessary, the file must create the custom widget itself.
	blsStoring	TRUE = write FALSE = read

Example

```
bool SLEsTestCustomWidget::serialize(const QString& szFilePath, bool bIsStoring)
```

```
{
    QFile fi(szFilePath);
    bool bReturn = false;
    QDir dir;
    if (dir.mkpath(fi.canonicalPath()))
    {
        QFile fileData(szFilePath);
        QIODevice::OpenMode mode;

        if (bIsStoring)
        {
            mode = QIODevice::WriteOnly;
        }
        else
        {
            mode = QIODevice::ReadOnly;
        }

        if (fileData.open(mode))
        {
            QDataStream streamData;
            streamData.setDevice(&fileData);

            if (bIsStoring)
            {
                streamData << m_nDataCount << m_dValueX;
            }
        }
    }
}
```

```

bool SLEsTestCustomWidget::serialize(const QString& szFilePath, bool bIsStoring)
{
    else
    {
        streamData >> m_nDataCount >> m_dValueX;
    }

    streamData.setDevice(0);
    fileData.flush();
    fileData.close();
    bReturn = true;
}
}
return bReturn;
}

```

9.4.5.3 Response to a custom widget signal

Description

In Run MyScreens it is possible to respond to a particular signal (invokeSub()) of the custom widget and call up a subprogram (SUB).

10 global variables, the so-called SIGARG, are available for passing values (custom widget signal -> SUB), which are comparable to registers (REG) in configuration. This is where the values transferred with the custom widget signal are stored.

The following transfer parameter data formats are supported:

- bool
- uint
- int
- double
- QString
- QByteArray

Programming

Calling the subroutine:

Syntax:	<code>void invokeSub(const QString& rszSignalName, const QVariantList& rvntList);</code>
Description:	Custom widget signal with which a Run MyScreens subprogram is called.

Parameters:	rszSignalName	Name of the Run MyScreens subprogram to be called
	rvntList	QVariantList array for transferring parameters that are stored in the global parameter SIGARG and which are available in the configuration. Maximum size: 10 elements Data formats supported: see above Note: The transfer parameters are always passed "ByVal," i.e. only the value and not, for example, the reference to a variable is passed.

Subroutine to be called:

Syntax:	SUB (on_<Variablename>_<Signalname>) ... END_SUB	
Description:	Response to a custom widget signal	
Parameters:	Variable name	Name of a dialog box variable to which a custom widget is assigned.
	Signal name	Name of the custom widget signal
	SIGARG 0 - 9	Transfer parameters for the custom widget method. Supported data formats: See above Note: The transfer parameters are always passed "ByVal," i.e. only the value and not, for example, the reference to a variable is passed.

Example**Customer widget class declaration:**

```
class SLESTESTCUSTOMWIDGET_EXPORT SLEstTestCustomWidget : public QWidget
{
    Q_OBJECT
signals:
    void invokeSub(const QString& szSubName, const QVariantList& vntList);
    ...
}
```

Custom widget class:

```
QVariantList vntList;
vntList << 123.456;
emit invokeSub("MySub", vntList);
```

Dialog box configuration:

```
DEF MyCWVar1 = (W///,"sleestestcustomwidget.SLEstTestCustomWidget")
SUB (on_MyCWVar1_MySub)
```

```

DEF MyCWVar1 = (W///,"slesteestcustomwidget.SIEsTestCustomWidget")
    DEBUG("SUB(on_MyCWVar1_MySub) was called with parameter: "" << SIGARG[0] <<
    """)
END_SUB

```

Result "easyscreen_log.txt":

```
[10:22:40.445] DEBUG: SUB(on_MyCWVar1_MySub) was called with parameter: "123.456"
```

9.5 SIEsGraphCustomWidget

9.5.1 SIEsGraphCustomWidget

General

Using SIEsGraphCustomWidget, you can display geometrical objects (point, line, square, square with rounded corners, ellipse, arc, text) and curves from interpolation points (e.g. measured values, characteristic).

The objects are organized in one or several contours. These can then be displayed, either individually or combined; they can also be entered, selected and deleted.

Using functions, the objects are added to the currently selected contour, and these are then drawn in this particular sequence. If you wish to draw the object in a specific color, then you must set the appropriate pen color before adding. All objects subsequently added will be drawn in this pen color. In addition to the pen color, you can also influence the pen width and pen style. For closed objects such as square, square with rounded edges and ellipse, before adding the objects you can set a fill color.

Every contour can be brought into various modes:

- Standard display of all object types.
- Points can be connected to create a polyline, and can therefore be displayed as curve/graph.
- The area between points, lines or arcs up to the X axis can be filled in with the currently selected fill color. For instance, you can use this option to visualize residual material when turning.
If, in this mode, points are displayed in addition as polyline, then the complete area below the curve up to the X axis is filled. The points, lines and arcs can be located in all four quadrants.

You can move along one or several contours using a special cursor mode. To do this, the cursor is set to the first or last point object of a contour or, starting from the actual cursor position is moved either forward or backward within the contour of a point object.

When required, a second Y axis (right) can be displayed with its own scaling. This is coupled to the first Y axis (left) through an offset and a factor.

Based on a specified X coordinate, using a search function, a point previously added to the contour can be found, and if required, the cursor can be set to this point.

You can also configure contours as ring buffer with an adjustable size.

As a result of the serialization, the actual state of the SIEsGraphCustomWidget can be saved in a file in binary form - and also restored.

The SIEsGraphCustomWidget can be operated using the "Pan" gesture (where the view is shifted) and the "Pinch"/"Spread" gestures (zooming in and out of the view).

Using the mouse, you can shift the view (left mouse button + Move), and you can zoom in and out (mouse wheel).

For performance reasons, the display is not automatically refreshed. Depending on the particular application, you can initiate the refresh by calling the appropriate function.

Example




Figure 9-1 SIEsGraphCustomWidget example

```
//M(MyGraphSampleMask/"SIEsGraphCustomWidget Sample")
DEF MyGraphVar = (W///,"slesgraphcustomwidget.SIEsGraphCustomWidget"////10,10,340,340/0,0,0,0)
VS1=("Add objects",,sel)
LOAD
  WRITECWPROPERTY("MyGraphVar", "AxisNameX", "X")
  WRITECWPROPERTY("MyGraphVar", "AxisNameY", "Y")
  WRITECWPROPERTY("MyGraphVar", "ScaleTextOrientationYAxis", 2)
  WRITECWPROPERTY("MyGraphVar", "KeepAspectRatio", TRUE)

  REG[0]= CALLCWMETHOD("MyGraphVar", "addContour", "MyContour", TRUE)
  REG[0]= CALLCWMETHOD("MyGraphVar", "showContour", "MyContour")
  REG[0]= CALLCWMETHOD("MyGraphVar", "setView", -35, -35, 150, 150)
END_LOAD

PRESS (VS1)
  REG[0]= CALLCWMETHOD("MyGraphVar", "addLine", 10, 20, 40, 20)
```

```
//M(MyGraphSampleMask/"SIEsGraphCustomWidget Sample")  
  
REG[0]= CALLCWMETHOD("MyGraphVar", "addLine", 40, 20, 40, 40)  
REG[0]= CALLCWMETHOD("MyGraphVar", "addLine", 40, 40, 60, 40)  
REG[0]= CALLCWMETHOD("MyGraphVar", "addLine", 80, 0, 80, 100)  
REG[0]= CALLCWMETHOD("MyGraphVar", "addLine", 90, 0, 90, 100)  
REG[0]= CALLCWMETHOD("MyGraphVar", "addRect", 25, 100, 50, 75)  
REG[0]= CALLCWMETHOD("MyGraphVar", "setPenColor", "#ff0000");red  
REG[0]= CALLCWMETHOD("MyGraphVar", "setFillColor", "#ffff00");yellow  
REG[0]= CALLCWMETHOD("MyGraphVar", "addCircle", -12.5, 62.5, 12.5)  
REG[0]= CALLCWMETHOD("MyGraphVar", "setFillColor");off/default  
REG[0]= CALLCWMETHOD("MyGraphVar", "setPenColor");off/default  
REG[0]= CALLCWMETHOD("MyGraphVar", "addArc", 100, 37.5, 125, 62.5, 0, 180)  
REG[0]= CALLCWMETHOD("MyGraphVar", "update")  
  
END_PRESS
```

9.5.2 Notes regarding performance

Depending on the hardware used and the basic utilization of the system, when using SIEsGraphCustomWidgets you must observe the following guide values. In addition to the hardware being used and the basic utilization, the values vary depending on the SIEsGraphCustomWidgets configuration.

Observe these guide values so that the response and stability of the overall system are not diminished.

- Number of SIEsGraphCustomWidgets configured simultaneously (e.g. a maximum of 1)
- Number of configured contours (e.g. a maximum of 6)
- Number of configured graphic objects per contour (e.g. maximum of 1000)
- Frequency of the requested refresh operations (e.g. max. 500 ms)

Note

The display is not real-time capable.

9.5.3 Reading and writing properties

Description

The properties listed in the following section are read with ReadCWProperty() and written with WriteCWProperty().

Examples

Reading the "CursorX" property of the SIEsGraphCustomWidget linked using display variable "MyGraphVar". The result is written to register 0.

```
REG[0] = ReadCWProperty("MyGraphVar", "CursorX")
```

Writes value "MyFirstContour" to the "SelectedContour" property of the SIEsGraphCustomWidget linked using display variable "MyGraphVar".

```
WriteCWProperty("MyGraphVar ", "SelectedContour", "MyFirstContour")
```

9.5.4 Properties

Overview

Property	Description
AxisNameX	Axis identifiers, X axis
AxisNameY	Axis identifiers, Y axis
AxisNameY2	Axis identifiers, second Y axis (right)
AxisY2Visible	Display/hide second Y axis (right)
AxisY2Offset	Offset second Y axis (right)
AxisY2Factor	Factor second Y axis (right)
ScaleTextEmbedded	Position of the scaling texts
ScaleTextOrientationYAxis	Alignment of the scaling texts of the Y axis
KeepAspectRatio	Keep aspect ratios
SelectedContour	Name of the currently selected contour
BackColor	Background color
ChartBackColor	Background color of the drawing area
ForeColor	Foreground color for text and default pen color
ForeColorY2	Foreground color for the texts of the second Y axis (right)
GridColor	Color of the grid lines
GridColorY2	Color of the horizontal grid lines of the second Y axis (right)
CursorColor	Color of the cursor crosshairs
ShowCursor	Display/hide cursor
CursorX	Cursor X position
CursorY	Cursor Y position
CursorY2	Cursor Y position referred to the second Y axis (right)
CursorStyle	Cursor display type
ViewMoveZoomMode	Response when zooming and shifting using gestures

AxisNameX – axis identifiers, X axis

Syntax:	Return Value = ReadCWProperty(GraphVarName, " AxisNameX ") WriteCWProperty(GraphVarName, " AxisNameX ", Value)	
Description:	Reads or sets the identifier of the X axis. If an identifier is not specified, then the space available for the drawing area is fully utilized.	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Read value of the property (QString)
	Value	Value to be set (QString)

AxisNameX – axis identifiers, Y axis

Syntax:	Return Value = ReadCWProperty(GraphVarName, " AxisNameY ") WriteCWProperty(GraphVarName, " AxisNameY ", Value)	
Description:	Reads or sets the identifier of the Y axis. If an identifier is not specified, then the space available for the drawing area is fully utilized.	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Read value of the property (QString)
	Value	Value to be set (QString)

AxisY2Visible – display/hide second Y axis (right)

Syntax:	Return Value = ReadCWProperty(GraphVarName, " AxisY2Visible ") WriteCWProperty(GraphVarName, " AxisY2Visible ", Value)	
Description:	Displays/hides second Y axis (right)	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Read value of the property (bool)
	Value	Value to be set (bool): TRUE or FALSE

AxisY2Offset – offset second Y axis (right)

Syntax:	Return Value = ReadCWProperty(GraphVarName, " AxisY2Offset ") WriteCWProperty(GraphVarName, " AxisY2Offset ", Value)	
Description:	Offset of the second Y axis (right) referred to the first Y axis (left). See example for AxisY2Factor property.	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Read value of the property (double)
	Value	Value to be set (double).

AxisY2Factor – factor second Y axis (right)

Syntax:	Return Value = ReadCWProperty(GraphVarName, "AxisY2Factor") WriteCWProperty(GraphVarName, "AxisY2Factor", Value)	
Description:	Factor of the second Y axis (right) referred to the first Y axis (left).	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Read value of the property (double)
	Value	Value to be set (double).

Together with the "AxisY2Offset" property, it is possible to display a second Y axis (right) with its own scaling. The scale is coupled to the first Y axis (left) through an offset and a factor.

Formula for converting Y2 to Y:

$$Y = Y2 / \text{factor} - \text{offset}$$

Formula for converting Y to Y2:

$$Y2 = (Y + \text{offset}) * \text{factor}$$




Figure 9-2 Example with second Y axis with own scaling

Example

Y: 0 to 200 should correspond to Y2: -25 to 25.

- Offset: -100
- Factor: 0.25

Calculation example:

$$Y2 = -30$$

$$Y = -30 / 0.25 - (-100) = -20$$

Calculation example:

$$Y = 0$$

$$Y2 = (0 + (-100)) * 0.25 = -25$$

The X axis is the same for both coordinate systems.

You can set the colors using setForeColorY2() and setGridColorY2() (see colors).

The axes are labeled with setAxisNameY2() (see axis identifiers).

ScaleTextEmbedded - position of the scaling texts

Syntax:	Return Value = ReadCWProperty(GraphVarName, "ScaleTextEmbedded") WriteCWProperty(GraphVarName, "ScaleTextEmbedded", Value)	
Description:	Using this property you define whether the scaling is positioned inside or outside the drawing area.	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Read value of the property (bool)
	Value	Value to be set (bool): TRUE or FALSE

Example

Scaling text outside the drawing area:

ScaleTextEmbedded = FALSE




Figure 9-3 Scaling text outside the drawing area

Scaling text within the drawing area:

ScaleTextEmbedded = TRUE




Figure 9-4 Scaling text within the drawing area

ScaleTextOrientationYAxis - alignment of the scaling texts of the Y axis

Syntax:	ReturnValue = ReadCWProperty(GraphVarName, "ScaleTextOrientationYAxis") WriteCWProperty(GraphVarName, "ScaleTextOrientationYAxis", Value)	
Description:	Using this function, the scaling texts of the Y axis are aligned vertically.	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Read value of the property (int)
	Value	Value to be set (int): 1 (= horizontal) or 2 (= vertical)

Example

Scaling text within the drawing area:

- ScaleTextEmbedded = TRUE

Horizontal text alignment:

- ScaleTextOrientationYAxis = 1




Figure 9-5 Scaling text within the drawing area, horizontal text alignment

Vertical text alignment:

- ScaleTextOrientationYAxis = 2




Figure 9-6 Scaling text within the drawing area, vertical text alignment

Scaling text outside the drawing area:

- ScaleTextEmbedded = FALSE

Horizontal text alignment:

- ScaleTextOrientationYAxis = 1




Figure 9-7 Scaling text outside the drawing area, horizontal text alignment

Vertical text alignment:

- ScaleTextOrientationYAxis = 2




Figure 9-8 Scaling text outside the drawing area, vertical text alignment

KeepAspectRatio – keep aspect ratio

Syntax:	ReturnValue = ReadCWProperty(GraphVarName, " KeepAspectRatio ") WriteCWProperty(GraphVarName, " KeepAspectRatio ", Value)	
Description:	With this property, you define as to whether the view defined using setView() should be automatically aligned, adapted or extended, so that the aspect ratio from X to Y axis always remains the same. This property is especially relevant when displaying geometrical figures. For example, a circle or square is displayed as such, and does not become an ellipse or rectangle.	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Read value of the property (bool)
	Return Value	Value to be set (bool): TRUE or FALSE

Example

```
setView(-15, -15, 15, 15)
setFillColor("#A0A0A4")
addCircle(0, 0, 5)
KeepAspectRatio = TRUE
```




Figure 9-9 Aspect ratio from X to Y axis remain the same

```
KeepAspectRatio = FALSE
```




Figure 9-10 Aspect ratio from X to Y axis distorted

SelectedContour – name of the currently selected contour

Syntax:	Return Value = ReadCWProperty(GraphVarName, " SelectedContour ") WriteCWProperty(GraphVarName, " SelectedContour ", Value)	
Description:	Reads or sets the selection of the actual contour.	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Read value of the property (QString)
	Value	Value to be set (QString)

Note

In order to be able to execute operations on a contour, e.g. to add a graphic object, you must first select this.

BackColor – background color

Syntax:	Return Value = ReadCWProperty(GraphVarName, " BackColor ") WriteCWProperty(GraphVarName, " BackColor ", Value)	
Description:	The background color for labeling axes depends on the ScaleTextInsideChartArea property - also the scaling texts.	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Read color of the property (QString)
	Value	Value to be set (QString) as RGB value in the form "#RRGGBB", for example, "#04B7FB"

ChartBackColor – background color of the drawing area

Syntax:	Return Value = ReadCWProperty(GraphVarName, " ChartBackColor ") WriteCWProperty(GraphVarName, " ChartBackColor ", Value)	
Description:	Background color for the drawing area.	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Read color of the property (QString)
	Value	Value to be set (QString) as RGB value in the form "#RRGGBB", for example, "#04B7FB"

ForeColor - foreground color for labeling and default pen color

Syntax:	Return Value = ReadCWProperty(GraphVarName, " ForeColor ") WriteCWProperty(GraphVarName, " ForeColor ", Value)	
Description:	Foreground color for text and default pen color.	

Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Read color of the property (QString)
	Value	Value to be set (QString) as RGB value in the form "#RRGGBB", for example, "#04B7FB"

ForeColorY2 - foreground color for labeling the second Y axis (right)

Syntax:	Return Value = ReadCWProperty(GraphVarName, " ForeColorY2 ") WriteCWProperty(GraphVarName, " ForeColorY2 ", Value)	
Description:	Foreground color for the texts of the second Y axis (right).	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Read color of the property (QString)
	Value	Value to be set (QString) as RGB value in the form "#RRGGBB", for example, "#04B7FB"

GridColor - color of the grid lines

Syntax:	Return Value = ReadCWProperty(GraphVarName, " GridColor ") WriteCWProperty(GraphVarName, " GridColor ", Value)	
Description:	Color of the grid lines.	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Read color of the property (QString)
	Value	Value to be set (QString) as RGB value in the form "#RRGGBB", for example, "#04B7FB"

GridColorY2 - color of the horizontal grid lines of the second Y axis (right)

Syntax:	Return Value = ReadCWProperty(GraphVarName, " GridColorY2 ") WriteCWProperty(GraphVarName, " GridColorY2 ", Value)	
Description:	Color of the horizontal grid lines of the second Y axis (right).	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Read color of the property (QString)
	Value	Value to be set (QString) as RGB value in the form "#RRGGBB", for example, "#04B7FB"

CursorColor - color of the cursor

Syntax:	Return Value = ReadCWProperty(GraphVarName, " CursorColor ") WriteCWProperty(GraphVarName, " CursorColor ", Value)	
Description:	Color of the cursor.	

Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Read color of the property (QString)
	Value	Value to be set (QString) as RGB value in the form "#RRGGBB", for example, "#04B7FB"

ShowCursor - Display/hide cursor

Syntax:	Return Value = ReadCWProperty(GraphVarName, " ShowCursor ") WriteCWProperty(GraphVarName, " ShowCursor ", Value)	
Description:	Displays/hides cursor.	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Read value of the property (bool)
	Value	Value to be set (bool): TRUE or FALSE

Note

This function automatically refreshes the display.

CursorX – cursor X position

Syntax:	Return Value = ReadCWProperty(GraphVarName, " CursorX ") WriteCWProperty(GraphVarName, " CursorX ", Value)	
Description:	X position of the cursor.	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Read value of the property (double)
	Value	Value to be set (double).

Note

This function automatically refreshes the display.

CursorY – cursor Y position

Syntax:	Return Value = ReadCWProperty(GraphVarName, " CursorY ") WriteCWProperty(GraphVarName, " CursorY ", Value)	
Description:	Y position of the cursor.	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Read value of the property (double)
	Value	Value to be set (double).

Note

This function automatically refreshes the display.

CursorY2 - cursor Y position referred to the second Y axis (right)

Syntax:	ReturnValue = ReadCWProperty(GraphVarName, "CursorY2") WriteCWProperty(GraphVarName, "CursorY2", Value)	
Description:	Y position of the cursor referred to the second Y axis (right).	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Read value of the property (double)
	Value	Value to be set (double).

Note

This function automatically refreshes the display.

CursorStyle – cursor display type

Syntax:	ReturnValue = ReadCWProperty(GraphVarName, "CursorStyle") WriteCWProperty(GraphVarName, "CursorStyle", Value)	
Description:	Cursor display type.	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Read value of the property (int)
	Value	Value to be set (int): 0 (= cross) 1 (= crosshairs) 2 (= vertical line) 3 (= horizontal line) 4 (= horizontal and vertical line)

ViewMoveZoomMode – response when zooming and shifting using gestures

Syntax:	ReturnValue = ReadCWProperty(GraphVarName, "ViewMoveZoomMode") WriteCWProperty(GraphVarName, "ViewMoveZoomMode", Value)
Description:	The displayed view of the SIEsGraphCustomWidgets can be changed using gestures. This property allows you to define which type should be permitted. For example, in certain applications it may make sense that the view is only horizontally shifted and zoomed, e.g. when displaying measured value characteristics.

Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Read value of the property (int)
	Value	Value to be set (int): 0 (= off) 1 (= only horizontal) 2 (= only vertical) 3 (= horizontal and vertical)

9.5.5 Functions

You can call the subsequently listed functions using the CallCWMMethod() function.

Example

Setting the view of the SIEsGraphCustomWidget link using display variable "MyGraphVar".

The result is written to register 0.

```
REG[0] = CallCWMMethod("MyGraphVar", "setView", -8, -5, 11- 20)
```

Overview

Function	Description
setView	Sets coordinate system
setMaxContourObjects	Sets maximum number of objects for a contour (ring buffer)
addContour	Adds a contour
showContour	Shows a contour
hideContour	Hides a contour
hideAllContours	Hides all contours
removeContour	Removes a contour
clearContour	Deletes graphic object of a contour
fitViewToContours	Automatic adaptation of the view
fitViewToContour	Automatic adaptation of the view
findX	Searches in a contour
setPolylineMode	Displays points of a contour as polyline/curve
setIntegralFillMode	Displays points of a contour as polyline/curve
repaint, update	Refreshes view
addPoint	Adds a point to a contour
addLine	Adds a line to a contour
addRect	Adds a rectangle to a contour
addRoundedRect	Adds a rectangle with rounded corners to a contour
addEllipse	Adds an ellipse to a contour
addCircle	Adds a circle to a contour
addArc	Adds an arc to a contour

Function	Description
addText	Adds text to a contour
setPenWidth	Sets the pen width
setPenStyle	Sets the pen style
setPenColor	Sets the pen color
setFillColor	Sets fill color
setCursorPosition	Positions the cursor
setCursorPositionY2	Positions the cursor referred to the second Y axis (right)
setCursorOnContour	Positions the cursor on contour
moveCursorOnContourBegin	Positions the cursor to the first graphic object of a contour
moveCursorOnContourEnd	Positions the cursor to the last graphic object of a contour
moveCursorOnContourNext	Positions the cursor to the next graphic object of a contour
serialize	Saves/restores the actual state

setView – sets the coordinate system

Syntax:	ReturnValue = CallCWMMethod(GraphVarName, "setView", x1, y1, x2, y2)	
Description:	Using this function, you define the size of the coordinate system that should be displayed within the SIEsGraphCustomWidget. See also KeepAspectRatio property.	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Error code (bool): TRUE = successful
	x1	left-hand edge (double)
	y1	upper edge (double)
	x2	right-hand edge (double)
	y2	lower edge (double)

Note

The function automatically refreshes the display.

Example

```
setView(-8, -5, 11, 20)
AxisNameX = "X"
AxisNameY = "Y"
ScaleTextOrientationYAxis = 1
ScaleTextEmbedded = false
KeepAspectRatio = false
update
```




Figure 9-11 Example - setView

setMaxContourObjects – sets the maximum number of objects of a contour (ring buffer)

Syntax:	ReturnValue = CallCWMMethod(GraphVarName, "setMaxContourObjects", Value) ReturnValue = CallCWMMethod(GraphVarName, "setMaxContourObjects", Value, ContourName)	
Description:	Using this function, you can define the size of a contour ring buffer. If the number of objects added to the contour exceeds this limit, then the oldest object is deleted.	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Error code (bool): TRUE = successful
	Value	Maximum number of graphic objects (uint)
	ContourName	Name of the contour (QString). If a contour is not specified, then the call automatically refers to the currently selected contour.

Note

The function automatically refreshes the display.

addContour – add contour

Syntax:	ReturnValue = CallCWMMethod(GraphVarName, "addContour", ContourName) ReturnValue = CallCWMMethod(GraphVarName, "addContour", ContourName, Selected) ReturnValue = CallCWMMethod(GraphVarName, "addContour", ContourName, Selected, AssignedY2)
Description:	Using this function, you can define a new contour. Optionally, you can assign the contour to the coordinate system of the second Y axis (right).

Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Error code (bool): TRUE = successful
	ContourName	Name of the contour (QString). If a contour is not specified, then the call automatically refers to the currently selected contour.
	Selected	Contour should be selected (bool): TRUE or FALSE
	AssignedY2	Contour should be assigned to the second Y axis (right) (bool): TRUE or FALSE

showContour – shows a contour

Syntax:	Return Value = CallCWMMethod(GraphVarName, "showContour") Return Value = CallCWMMethod(GraphVarName, "showContour", ContourName)	
Description:	This function makes a contour visible.	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Error code (bool): TRUE = successful
	ContourName	Name of the contour (QString). If a contour is not specified, then the call automatically refers to the currently selected contour.

hideContour – hide contour

Syntax:	Return Value = CallCWMMethod(GraphVarName, "hideContour") Return Value = CallCWMMethod(GraphVarName, "hideContour", ContourName)	
Description:	This function hides a contour.	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Error code (bool): TRUE = successful
	ContourName	Name of the contour (QString). If a contour is not specified, then the call automatically refers to the currently selected contour.

showAllContours – shows all contours

Syntax:	Return Value = CallCWMMethod(GraphVarName, "showAllContours")	
Description:	This function makes all contours visible.	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Error code (bool): TRUE = successful

hideAllContours – hide all contours

Syntax:	ReturnValue = CallCWMMethod(GraphVarName, " hideAllContours ")	
Description:	This function hides all contours.	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Error code (bool): TRUE = successful

removeContour – hides a contour

Syntax:	ReturnValue = CallCWMMethod(GraphVarName, " removeContour ") ReturnValue = CallCWMMethod(GraphVarName, " removeContour ", ContourName)	
Description:	Removes a contour.	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Error code (bool): TRUE = successful
	ContourName	Name of the contour (QString). If a contour is not specified, then the call automatically refers to the currently selected contour.

clearContour – delete graphic object of a contour

Syntax:	ReturnValue = CallCWMMethod(GraphVarName, " clearContour ") ReturnValue = CallCWMMethod(GraphVarName, " clearContour ", ContourName)	
Description:	Deletes all graphic objects on a contour.	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Error code (bool): TRUE = successful
	ContourName	Name of the contour (QString). If a contour is not specified, then the call automatically refers to the currently selected contour.

fitViewToContours – automatic adaptation of the view

Syntax:	ReturnValue = CallCWMMethod(GraphVarName, " fitViewToContours ") ReturnValue = CallCWMMethod(GraphVarName, " fitViewToContours ", OnlyVisible)	
Description:	Using this function, the view is automatically adapted to the contours. Depending on the transfer parameter, you define whether only all visible contours can be seen or all contours can be seen.	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Error code (bool): TRUE = successful
	OnlyVisible	Value to be set (bool): TRUE or FALSE

fitViewToContour – automatic adaptation of the view

Syntax:	ReturnValue = CallCWMMethod(GraphVarName, " fitViewToContour ", Contour-Name)	
Description:	Using this function, the view is automatically adapted so that only a specific contours visible.	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Error code (bool): TRUE = successful
	ContourName	Name of the contour (QString)

findX – search in a contour

Syntax:	ReturnValue = CallCWMMethod(GraphVarName, " findX ", x) ReturnValue = CallCWMMethod(GraphVarName, " findX ", x, ContourName) ReturnValue = CallCWMMethod(GraphVarName, " findX ", x, ContourName, SetCursor)	
Description:	Using this function, you can search for a previously defined point with a specific X coordinate in a contour. You obtain the Y coordinate as result. Optionally, you can also simultaneously position the cursor to this point.	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Error code (QString): If successful, the associated Y value is supplied
	x	X value to be searched for (double)
	ContourName	Name of the contour (QString). If a contour is not specified, then the call automatically refers to the currently selected contour
	SetCursor	Set cursor (bool): TRUE or FALSE

Note

The display is automatically updated if you set the cursor using this function.

setPolylineMode – displays points on the contour as polyline/curve

Syntax:	ReturnValue = CallCWMMethod(GraphVarName, " setPolylineMode ", SetPoly)	
Description:	All of the points of the actual contour added after this function call are connected to create a polyline/curve. This function is contour-specific, and can be activated and deactivated on a segment-for-segment basis.	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Error code (bool): TRUE = successful
	SetPoly	PolylineMode (bool): TRUE = on

Example




Figure 9-12 Example - PolylineMode: Off




Figure 9-13 Example - PolylineMode: To

setIntegralFillMode – fills the areas between points, lines and arcs and the X axis

Syntax:	ReturnValue = CallCWMMethod(GraphVarName, "setIntegralFillMode", SetIntFill)	
Description:	Areas between points, lines and arcs of the X axis are filled with the current fill color (independent of whether the points are +Y or -Y). This function is contour-specific, and can be activated and deactivated on a segment-for-segment basis.	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Error code (bool): TRUE = successful
	SetIntFill	IntegralFillMode (bool): TRUE = on

Example




Figure 9-14 Example - setIntegralFillMode: on




Figure 9-15 Example - setIntegralFillMode: Off

repaint, update – update view

Syntax:	ReturnValue = CallCWMMethod(GraphVarName, " repaint ") ReturnValue = CallCWMMethod(GraphVarName, " update ")	
Description:	Using this function, you can manually refresh the display.	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Error code (bool): TRUE = successful

- **update()**
The function refreshes the view, assuming that the Widget refresh is not deactivated, and the Widget is not hidden. The function is optimized so that the application performance is maintained, and the view does not flicker as a result of excessively high refresh rates.
- **repaint()**
The function refreshes the view directly after the function call. Therefore, you should only use the repaint function if an immediate refresh is absolutely necessary, e.g. for animation purposes

It is recommended that you always work with the update() function. Internally, the SIEsGraphCustomWidget always works with the function update() e.g. for setView().

addPoint – add point to a contour

Syntax:	ReturnValue = CallCWMMethod(GraphVarName, " addPoint ", x, y) ReturnValue = CallCWMMethod(GraphVarName, " addPoint ", x, y, DummyPoint)	
Description:	Adds a point to the currently selected contour. Further, you can set a dummy point; although it does not show up in the drawing, it can be positioned with the cursor.	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Error code (bool): TRUE = successful
	x	x coordinate (double)
	y	y coordinate (double)
	DummyPoint	Point is treated as invisible (bool): TRUE = yes

addLine – add line to a contour

Syntax:	ReturnValue = CallCWMMethod(GraphVarName, " addLine ", x1, y1, x2, y2)	
Description:	Adds a line to the currently selected contour	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraph-CustomWidget
	Return Value	Error code (bool): TRUE = successful
	x1	x coordinate of the starting point (double)
	y1	y coordinate of the starting point (double)
	x2	x coordinate of the end point (double)
	y2	y coordinate of the end point (double)

addRect – add rectangle to a contour

Syntax:	ReturnValue = CallCWMMethod(GraphVarName, " addRect ", x1, y1, x2, y2)	
Description:	Adds a rectangle to the currently selected contour.	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraph-CustomWidget
	Return Value	Error code (bool): TRUE = successful
	x1	left-hand edge (double)
	y1	left-hand edge (double)
	x2	right-hand edge (double)
	y2	lower edge (double)

addRoundedRect – add rectangle with rounded corners to a contour

Syntax:	ReturnValue = CallCWMMethod(GraphVarName, " addRoundedRect ", x1, y1, x2, y2, r)	
Description:	Adds a rectangle with rounded off corners to the currently selected contour.	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraph-CustomWidget
	Return Value	Error code (bool): TRUE = successful
	x1	left-hand edge (double)
	y1	upper edge (double)
	x2	upper edge (double)
	y2	upper edge (double)
	r	Radius (double)

addEllipse – add ellipse to a contour

Syntax:	ReturnValue = CallCWMMethod(GraphVarName, " addEllipse ", x1, y1, x2, y2, radius)	
Description:	Adds an ellipse to the currently selected contour.	

Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Error code (bool): TRUE = successful
	x1	left-hand edge (double)
	y1	upper edge (double)
	x2	right-hand edge (double)
	y2	lower edge (double)
	Radius	Radius (double)

addCircle – add circle to a contour

Syntax:	ReturnValue = CallCWMMethod(GraphVarName, "addCircle", x, y, radius)	
Description:	Adds a circle to the currently selected contour	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Error code (bool): TRUE = successful
	x	left-hand edge (double)
	y	upper edge (double)
	Radius	Radius (double)

addArc – add arc to a contour

Syntax:	ReturnValue = CallCWMMethod(GraphVarName, "addArc", x1, y1, x2, y2, StartAngle, SpanAngle)	
Description:	Adds an arc to the currently selected contour	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Error code (bool): TRUE = successful
	x1	left-hand edge (double)
	y1	upper edge (double)
	x2	right-hand edge (double)
	y2	lower edge (double)
	StartAngle	Starting angle in degrees (double)
	SpanAngle	Opening angle in degrees (double)

addText – add text to a contour

Syntax:	ReturnValue = CallCWMMethod(GraphVarName, "addText", x, y, Text)	
Description:	Adds a text to the currently selected contour	

Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Error code (bool): TRUE = successful
	x	left-hand edge (double)
	y	upper edge (double)
	Text	Text (QString)

setPenWidth – sets the pen width

Syntax:	ReturnValue = CallCWMMethod(GraphVarName, " setPenWidth ") ReturnValue = CallCWMMethod(GraphVarName, " setPenWidth ", width)	
Description:	Defines the pen width from the instant that the function was called for the following objects that were added to the actual contour.	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Error code (bool): TRUE = successful
	width	Pen width (double). If a pen width is not specified, then the default pen width is set.

setPenStyle – sets the pen style

Syntax:	ReturnValue = CallCWMMethod(GraphVarName, " setPenStyle ") ReturnValue = CallCWMMethod(GraphVarName, " setPenStyle ", style)	
Description:	Defines pen style from the instant that the function is called for the following objects that are added to the actual contour.	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Error code (bool): TRUE = successful
	style	1 : Solid line (___) 2 : Interrupted line (_ _) 3 : Dotted line (...) 4 : Line-point-line (_ .) 5 : Line-point-point (_ . .)

setPenColor – sets the pen color

Syntax:	ReturnValue = CallCWMMethod(GraphVarName, " setPenColor ") ReturnValue = CallCWMMethod(GraphVarName, " setPenColor ", Color)	
Description:	Defines the pen color from the instant that the function was called for the following objects that were added to the actual contour.	

Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Error code (bool): TRUE = successful
	Color	Value to be set (QString) as RGB value in the form "#RRGGBB", for example, "#04B7FB"

setFillColor – set fill color

Syntax:	ReturnValue = CallCWMMethod(GraphVarName, "setFillColor") ReturnValue = CallCWMMethod(GraphVarName, "setFillColor", Color)	
Description:	Defines the fill color from the instant that the function was called for the following objects that were added to the actual contour.	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Error code (bool): TRUE = successful
	Color	Value to be set (QString) as RGB value in the form "#RRGGBB", for example, "#04B7FB"

setCursorPosition – position cursor

Syntax:	ReturnValue = CallCWMMethod(GraphVarName, "setCursorPosition", x, y)	
Description:	Sets the cursor to the specified position.	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Error code (bool): TRUE = successful
	x	x coordinate (double)
	y	y coordinate (double)

Note

This function automatically refreshes the display.

setCursorPositionY2Cursor – position cursor referred to the second Y axis (right)

Syntax:	ReturnValue = CallCWMMethod(GraphVarName, "setCursorPositionY2", x, y2)	
Description:	Sets the cursor to the specified position referred to the second Y axis (right).	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Error code (bool): TRUE = successful
	x	x coordinate (double)
	y2	Y coordinate referred to the second Y axis (right) (double)

Note

This function automatically refreshes the display.

setCursorOnContour – position cursor on contour

Syntax:	ReturnValue = CallCWMMethod(GraphVarName, "setCursorOnContour") ReturnValue = CallCWMMethod(GraphVarName, "setCursorOnContour", Contour-Name)	
Description:	Sets the cursor to the last cursor position within a contour.	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraph-CustomWidget
	Return Value	Error code (bool): TRUE = successful
	ContourName	Name of the contour (QString). If a contour is not specified, then the call automatically refers to the currently selected contour.

Note

This function automatically refreshes the display.

Example




Figure 9-16 Example - setCursorOnContour

moveCursorOnContourBegin – position the cursor to the first graphic object of a contour

Syntax:	ReturnValue = CallCWMMethod(GraphVarName, "moveCursorOnContourBegin") ReturnValue = CallCWMMethod(GraphVarName, "moveCursorOnContourBegin", ContourName)	
Description:	Starting from the actual cursor position within a contour, using this function you can navigate the cursor to the first point object of a contour.	

Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Error code (bool): TRUE = successful
	ContourName	Name of the contour (QString). If a contour is not specified, then the call automatically refers to the currently selected contour.

Note

This function automatically refreshes the display.

moveCursorOnContourEnd – position the cursor to the last graphic object of a contour

Syntax:	ReturnValue = CallCWMMethod(GraphVarName, "moveCursorOnContourEnd") ReturnValue = CallCWMMethod(GraphVarName, "moveCursorOnContourEnd", ContourName)	
Description:	Starting from the actual cursor position within a contour, using this function you can navigate the cursor to the last point object of a contour.	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Error code (bool): TRUE = successful
	ContourName	Name of the contour (QString). If a contour is not specified, then the call automatically refers to the currently selected contour.

Note

This function automatically refreshes the display.

moveCursorOnContourNext – position the cursor to the next graphic object of a contour

Syntax:	ReturnValue = CallCWMMethod(GraphVarName, "moveCursorOnContourNext") ReturnValue = CallCWMMethod(GraphVarName, "moveCursorOnContourNext", ContourName)	
Description:	Starting from the actual cursor position within a contour, using this function you can navigate the cursor to the next point object of a contour.	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Error code (bool): TRUE = successful
	ContourName	Name of the contour (QString). If a contour is not specified, then the call automatically refers to the currently selected contour.

Note

This function automatically refreshes the display.

moveCursorOnContourBack – position the cursor to the previous graphic object of a contour

Syntax:	ReturnValue = CallCWMMethod(GraphVarName, "moveCursorOnContourBack") ReturnValue = CallCWMMethod(GraphVarName, "moveCursorOnContourBack", ContourName)	
Description:	Starting from the actual cursor position within a contour, using this function you can navigate the cursor to the previous point object of a contour.	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Error code (bool): TRUE = successful
	ContourName	Name of the contour (QString). If a contour is not specified, then the call automatically refers to the currently selected contour.

Note

This function automatically refreshes the display.

serialize – save/restore the actual state

Syntax:	ReturnValue = CallCWMMethod(GraphVarName, "serialize", FilePath, IsStoring)	
Description:	Using this function, when required, you can write the actual state and content of the SIEsGraphWidget in binary form to a file or datastream and also restore it.	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	Return Value	Error code (bool): TRUE = successful
	FilePath	Complete path with file name (QString)
	IsStoring	Save/restore (bool): TRUE = save

Note

This function automatically refreshes the display.

9.5.6 Signals

You can capture the subsequently described ViewChanged signal in the configuration and respond appropriately.

Overview

Function	Description
ViewChanged	Changing the view

ViewChanged – changing the view

Syntax:	SUB(on_<GraphVarName>_ViewChanged) ... END_SUB	
Description:	The "ViewChanged" signal is sent if the view changes. You can respond to this in the configuration in a specific SUB method. The SIGARG parameters are appropriately set.	
Parameters:	GraphVarName	Name of the display variable which contains a SIEsGraphCustomWidget
	SIGARG[0]	left-hand edge (double)
	SIGARG[1]	upper edge (double)
	SIGARG[2]	right-hand edge (double)
	SIGARG[3]	lower edge (double)

Example

```

DEF MyGraphVar = (W///,"slesgraphcustomwidget.SIEsGraphCustomWidget"////
10,10,340,340/0,0,0,0)

SUB(on_MyGraphVar_ViewChanged
    DLGL("Current view: " << SIGARG[0] << ", " << SIGARG[1] << ", " << SIGARG[2]
    << ", " << SIGARG[3]
END_SUB

```

9.6 SIEsToggleButton

9.6.1 SIEsToggleButton

General information

You can create even functionally demanding applications simply by using Run MyScreens. For touch operation you can configure buttons that can be freely located (TouchButtons). The following attributes apply when configuring TouchButtons:

- The two possible state changes of the "clicked" and "checked" buttons can be queried in the configuration and the appropriate actions initiated.
- TouchButtons can be operated with single or multitouch, mouse and keyboard.

- The TouchButton is displayed corresponding to the actual resolution. This also applies to the font and displayed graphics.
- The TouchButton has two styles "Softkey look&feel" and "Application-specific". In the "Softkey look&feel" style, the TouchButton is displayed corresponding to the Operate softkeys. Both display styles have functions, for example, to scale graphics.
- TouchButtons are implemented and made available as custom widgets.




Figure 9-17 Examples of TouchButtons

Example

```
//M(MyTBMask/"My CustomWidget TouchButton ...")
```

```
DEF MyTB1 = (W///,"slesstdcw.SLEsTouchButton"////70,20,200,100/0,0,0,0)
```

```
LOAD
```

```
WRITECWPROPERTY("MyTB1", "text", "This is my first TouchButton !!!")
```

```
WRITECWPROPERTY("MyTB1", "textPressed", "This is my first TouchButton (pressed)!!!")
```

```
WRITECWPROPERTY("MyTB1", "picture", "dsm_remove_trashcan_red.png") WRITECWPROPERTY("MyTB1", "pictureAlignment", "left")
```

```
WRITECWPROPERTY("MyTB1", "scalePicture", FALSE)
```

```
WRITECWPROPERTY("MyTB1", "picturePressed", "slsu_topology_empty_round_slot.png") WRITECWPROPERTY("MyTB1", "picture", "slsu_topology_empty_slot_left_error.png")
```

```
END_LOAD
```




Figure 9-18 Example, "This is my first TouchButton !!!"

9.6.2 Reading and writing properties

Description

The properties listed in the following section are read with `ReadCWProperty()` and written with `WriteCWProperty()`.

Examples

Reading the "Text" property of the SIEsTouchButton linked using display variable "MyTouchButton". The result is written to register 0.

```
REG[0] = ReadCWProperty("MyTouchButton", "Text")
```

Writing value "sk_ok.png" in the "Picture" property of the SIEsTouchButton, linked using display variable "MyTouchButton".

```
WriteCWProperty("MyTouchButton", "Picture", "sk_ok.png")
```

9.6.3 Properties

Overview

Property	Description
ButtonStyle	TouchButton display style
Flat	Displayed flat or in 3D
Enabled	Activate/deactivate operability
Checkable	Activate/deactivate toggle function
Checked	TouchButton is presently checked
ShowFocusRect	Display focus square if the TouchButton has the input focus

Property	Description
Picture	Picture (image) that should be displayed if the TouchButton is in the normal, non-actuated state
PicturePressed	Picture (image) to be displayed if the TouchButton is pressed or checked
PictureAlignment PictureAlignmentString	Alignment of the picture
ScalePicture	Picture is scaled (stretched or compressed)
PictureKeepAspectRatio	Picture aspect ratio
Text	Normal display text
TextPressed	Text that is displayed if the TouchButton is pressed
textAlignment textAlignmentString	Alignment of the text
TextAlignedToPicture	Text is aligned relative to the picture - activate/deactivate
BackgroundPicture	Background screen to be displayed
BackgroundPictureAlignment BackgroundPictureAlignmentString	Alignment of the background picture
ScaleBackgroundPicture	Background picture is scaled (stretched or compressed)
BackgroundPictureKeepAspectRatio	Picture aspect ratio
BackColor	Background color if the TouchButton is in the normal and non-actuated state
BackColorChecked	Background color if the TouchButton is checked
BackColorPressed	Background color if the TouchButton is presently pressed
BackColorDisabled	Background color if the TouchButton cannot be operated
TextColor	Text color if the TouchButton is in the normal and non-actuated state
TextColorChecked	Text color if the TouchButton is checked
TextColorPressed	Text color if the TouchButton is presently pressed
TextColorDisabled	Text color if the TouchButton cannot be operated

Button style

Syntax:	Return Value = ReadCWProperty(TouchButtonVarName, "ButtonStyle") WriteCWProperty(TouchButtonVarName, "ButtonStyle", Value)	
Description:	Reads/sets the TouchButton style	
Parameters:	TouchButtonVarName	Name of the display variable that contains a SIEsTouch-Button
	Return Value	Read value of the property (int)
	Value	value to be set (int) 0 = Softkey Look&Feel (default) 1 = user-specific

With the setting "0 = Softkey Look&Feel", the TouchButton is displayed and responds just like a softkey. The currently set skin is taken into account – see display machine data 9112 = \$MM_HMI_SKIN.




Figure 9-19 ButtonStyle - Softkey Look&Feel

With setting "1 = user-specific", the text and background color can be defined according to the TouchButton state. Further, there is a 3D effect, which allows pictures to be automatically scaled and influences the distances from the edges.




Figure 9-20 ButtonStyle - user-specific

Flat – display type

Syntax:	ReturnValue = ReadCWProperty(TouchButtonVarName, " Flat ") WriteCWProperty(TouchButtonVarName, " Flat ", Value)	
Description:	Reads/sets as to whether the TouchButton is shown flat (default) or in 3D Note: This property is only available with active style (ButtonStyle) "1= user-specific".	
	TouchButtonVarName	Name of the display variable that contains a SIEs-TouchButton
Parameters:	Return Value	Read value of the property (bool)
	Value	Value to be set (bool): TRUE (default) or FALSE




Figure 9-21 Flat display style




Figure 9-22 3D display style

Enabled – operability of the TouchButton

Syntax:	ReturnVal = ReadCWProperty(TouchButtonVarName, "Enabled") WriteCWProperty(TouchButtonVarName, "Enabled", Value)	
Description:	Read/sets as to whether the TouchButton can be operated (= TRUE) - or cannot be operated (FALSE).	
Parameters:	TouchButtonVarName	Name of the display variable that contains a SIEsTouch-Button
	Return Value	Read value of the property (bool)
	Value	Value to be set (bool): TRUE (default) or FALSE




Figure 9-23 TouchButton can be operated




Figure 9-24 TouchButton cannot be operated

Note

If a TouchButton that cannot be operated is clicked, then signal "clickedDisabled" is sent. The signal can be evaluated, for example an appropriate message issued as to why the TouchButton and the associated function presently cannot be operated. In the deactivated state, the picture or background picture is automatically displayed in shades of gray.

Checkable – activate/deactivate toggle function

Syntax:	ReturnVal = ReadCWProperty(TouchButtonVarName, "Checkable") WriteCWProperty(TouchButtonVarName, "Checkable", Value)	
Description:	Reads/sets the TouchButton toggle function.	
Parameters:	TouchButtonVarName	Name of the display variable that contains a SIEsTouch-Button
	Return Value	Read value of the property (bool)
	Value	Value to be set (bool): TRUE or FALSE (default)

Note

In the default setting, after it has been released, the TouchButton returns to its normal state (the same as a pushbutton). However, if the TouchButton toggle functionality is activated (TRUE), then after it is pressed, it initially remains in the pressed position. If it is actuated again, then it changes back into its normal state (same as a switch).

See also the "Checked" property.

Checked – actual toggle state

Syntax:	Return Value = ReadCWProperty(TouchButtonVarName, "Checked") WriteCWProperty(TouchButtonVarName, "Checked", Value)	
Description:	Reads/sets the actual toggle state of the TouchButton	
Parameters:	TouchButtonVarName	Name of the display variable that contains a SIEsToggleButton
	Return Value	Read value of the property (bool)
	Value	Value to be set (bool): TRUE or FALSE (default)

If the toggle function is activated as the property "Checkable" is "TRUE", then the actual toggle state can be read or set using the "Checked" property.




Figure 9-25 Unchecked




Figure 9-26 Checked

For both states, text and picture can be specifically displayed.

Note

See also the "Checkable" property.

ShowFocusRect – focus rectangle display

Syntax:	Return Value = ReadCWProperty(TouchButtonVarName, "ShowFocusRect") WriteCWProperty(TouchButtonVarName, "ShowFocusRect", Value)	
Description:	Reads/sets as to whether the TouchButton should display a focus rectangle as soon as it is assigned the input focus.	
Parameters:	TouchButtonVarName	Name of the display variable that contains a SIEsTouch-Button
	Return Value	Read value of the property (bool)
	Value	Value to be set (bool): TRUE or FALSE (default)

The focus frame color is automatically set with the Operate color setting, in the following example "orange".




Figure 9-27 ShowFocusRect

Picture – displayed picture

Syntax:	Return Value = ReadCWProperty(TouchButtonVarName, "Picture") WriteCWProperty(TouchButtonVarName, "Picture", Value)	
Description:	Reads/sets the picture to be displayed if the TouchButton is in its quiescent state (not actuated).	
Parameters:	TouchButtonVarName	Name of the display variable that contains a SIEsTouch-Button
	Return Value	read value of the property (string)
	Value	value to be set (string)

The file name is specified as value, for example "sk_ok.png". The TouchButton automatically determines the correct picture file from the current resolution directory (see Chapter Using display images/graphics (Page 63)).

In the deactivated state, the picture is automatically displayed in shades of gray.

Note

See also properties - "Text", "TextAlignedToPicture", "PictureAlignment", "ScalePicture", "PictureKeepAspectRatio".

PicturePressed – picture in the pressed state

Syntax:	Return Value = ReadCWProperty(TouchButtonVarName, "PicturePressed") WriteCWProperty(TouchButtonVarName, "PicturePressed", Value)	
Description:	Reads/sets the picture to be displayed if the TouchButton is pressed or checked.	
Parameters:	TouchButtonVarName	Name of the display variable that contains a SIEsTouch-Button
	Return Value	read value of the property (string)
	Value	value to be set (string)

If a value is not specified (empty string ""), then in this state, the TouchButton shows the picture specified with the "Picture" property.

The file name is specified as value, for example "sk_ok.png". The TouchButton automatically determines the correct picture file from the current resolution directory (see Chapter Using display images/graphics (Page 63)).

In the deactivated state, the picture is automatically displayed in shades of gray.

Note

See also properties - "Text", "TextAlignedToPicture", "PictureAlignment", "ScalePicture", "PictureKeepAspectRatio".

PictureAlignment – picture alignment

Syntax:	Return Value = ReadCWProperty(TouchButtonVarName, "PictureAlignment") WriteCWProperty(TouchButtonVarName, "PictureAlignment", Value)	
Description:	Reads/sets the alignment of the picture on the TouchButton.	
Parameters:	TouchButtonVarName	Name of the display variable that contains a SIEsTouch-Button
	Return Value	Read value of the property (int)
	Value	Value to be set (int): 1 = left (default) 2 = right 32 = top 64 = bottom 128 = centered

Note

See Chapter Positioning and aligning picture and text (Page 266).

Also see properties - "Text", "TextAlignedToPicture", "PictureAlignmentString", "ScalePicture", "PictureKeepAspectRatio".

PictureAlignmentString – picture alignment

Syntax:	ReturnValue = ReadCWProperty(TouchButtonVarName, " PictureAlignmentString ") WriteCWProperty(TouchButtonVarName, " PictureAlignmentString ", Value)	
Description:	Reads/sets the alignment of the picture. This property is analogous to the "PictureAlignment" property. However, the value is not transfigured here as number (int), but as string.	
Parameters:	TouchButtonVarName	Name of the display variable that contains a SIEsTouch-Button
	Return Value	read value of the property (string)
	Value	value to be set (string): "Left" = left (default) "Right" = right "Top" = top "Bottom" = bottom "Center" = centered

Note

See Chapter Positioning and aligning picture and text (Page 266).

See also properties - "Text", "TextAlignedToPicture", "PictureAlignment", "ScalePicture", "PictureKeepAspectRatio".

ScalePicture – scale picture

Syntax:	ReturnValue = ReadCWProperty(TouchButtonVarName, " ScalePicture ") WriteCWProperty(TouchButtonVarName, " ScalePicture ", Value)	
Description:	Reads/sets whether the TouchButton (depending on the alignment) should scale the picture to be displayed.	
Parameters:	TouchButtonVarName	Name of the display variable that contains a SIEsTouch-Button
	Return Value	Read value of the property (bool)
	Value	Value to be set (bool): TRUE or FALSE (default)

Note

See Chapter Positioning and aligning picture and text (Page 266).

PictureKeepAspectRatio – scale picture - keeping the aspect ratio

Syntax:	ReturnValue = ReadCWProperty(TouchButtonVarName, " PictureKeepAspectRatio ") WriteCWProperty(TouchButtonVarName, " PictureKeepAspectRatio ", Value)	
Description:	Reads/sets, whether, when scaling (Property "ScalePicture" = "TRUE"), the aspect ratio of the picture should be kept or not.	
Parameters:	TouchButtonVarName	Name of the display variable that contains a SIEsTouch-Button
	Return Value	Read value of the property (bool)
	Value	Value to be set (bool): TRUE (default) or FALSE

Note

See Chapter Positioning and aligning picture and text (Page 266).

Text – display text

Syntax:	ReturnValue = ReadCWProperty(TouchButtonVarName, " Text ") WriteCWProperty(TouchButtonVarName, " Text ", Value)	
Description:	Reads/sets the displayed text if the TouchButton is in its quiescent state (not actuated).	
Parameters:	TouchButtonVarName	Name of the display variable that contains a SIEsTouch-Button
	Return Value	read value of the property (string)
	Value	value to be set (string)

The texts are automatically wrapped around at the word limits in the rectangle provided.

Line breaks are only forced as a result of the system if the text to be displayed comes from a language file.

Note

See Chapter Language-dependent texts (Page 268).

TextPressed – displayed text in the pressed state

Syntax:	ReturnValue = ReadCWProperty(TouchButtonVarName, " TextPressed ") WriteCWProperty(TouchButtonVarName, " TextPressed ", Value)	
Description:	Reads/sets the displayed text if the TouchButton is pressed or checked.	
Parameters:	TouchButtonVarName	Name of the display variable that contains a SIEsTouch-Button
	Return Value	read value of the property (string)
	Value	value to be set (string)

The texts are automatically wrapped around at the word limits in the rectangle provided.

Line breaks are only forced as a result of the system if the text to be displayed comes from a language file.

Note

See Chapter Language-dependent texts (Page 268).

TextAlignment – alignment of the text

Syntax:	Return Value = ReadCWProperty(TouchButtonVarName, "TextAlignment") WriteCWProperty(TouchButtonVarName, "TextAlignment", Value)	
Description:	Reads/sets the alignment of the text on the TouchButton	
Parameters:	TouchButtonVarName	Name of the display variable that contains a SIEsTouch-Button
	Return Value	Read value of the property (int)
	Value	Value to be set (int): 1 = left 2 = right 32 = top 64 = bottom 128 = centered (default) (see examples below)




Figure 9-28 TextAlignment - left




Figure 9-29 TextAlignment - right




Figure 9-30 TextAlignment - top



Figure 9-31 TextAlignment - bottom



Figure 9-32 TextAlignment - centered

Note

See Chapter Positioning and aligning picture and text (Page 266).

See also properties "Text", "TextAlignmentString", "TextAlignedToPicture".

TextAlignmentString – alignment of the text

Syntax:	ReturnValue = ReadCWProperty(TouchButtonVarName, "TextAlignmentString") WriteCWProperty(TouchButtonVarName, "TextAlignmentString", Value)	
Description:	Reads/sets the alignment of the text. This property is analogous to the "TextAlignment" property. The value is not transfigured here as number (int), but as string.	
Parameters:	TouchButtonVarName	Name of the display variable that contains a SIEsTouchButton
	Return Value	read value of the property (string)
	Value	value to be set (string): "Left" = left "Right" = right "Top" = top "Bottom" = bottom "Center" = centered (default)

Note

See Chapter Positioning and aligning picture and text (Page 266).

See also properties - "Text", "TextAlignment", "TextAlignedToPicture".

TextAlignedToPicture – text aligned relative to the picture

Syntax:	Return Value = ReadCWProperty(TouchButtonVarName, "TextAlignedToPicture") WriteCWProperty(TouchButtonVarName, " TextAlignedToPicture ", Value)	
Description:	Reads/sets whether the displayed text should be positioned relative to the picture. If FALSE is set here, then the text is shown centered on the TouchButton.	
Parameters:	TouchButtonVarName	Name of the display variable that contains a SIEsTouchButton
	Return Value	Read value of the property (bool)
	Value	Value to be set (bool): TRUE (default) or FALSE

Note

See Chapter Positioning and aligning picture and text (Page 266).
See also properties "Text", "TextPressed", "Picture", "PicturePressed".

BackColor – background color

Syntax:	Return Value = ReadCWProperty(TouchButtonVarName, " BackColor ") WriteCWProperty(TouchButtonVarName, " BackColor ", Value)	
Description:	Reads/sets the background color if the TouchButton is in its quiescent state (not actuated).	
Parameters:	TouchButtonVarName	Name of the display variable that contains a SIEsTouchButton
	Return Value	Read color of the property (string)
	Value	Value to be set (string) as RGB value in the form "#RRGGBB", for example, "#04B7FB"

Note

This property is only available with active style "1= user-specific".

BackColorChecked – background color in the checked state

Syntax:	Return Value = ReadCWProperty(TouchButtonVarName, " BackColorChecked ") WriteCWProperty(TouchButtonVarName, " BackColorChecked ", Value)	
Description:	Reads/sets the background color if the TouchButton is in the clicked state (toggle function). See properties "Checked", "Checkable"	
Parameters:	TouchButtonVarName	Name of the display variable that contains a SIEsTouchButton
	Return Value	Read color of the property (string)
	Value	Value to be set (string) as RGB value in the form "#RRGGBB", for example, "#04B7FB"

Note

This property is only available with active style "1= user-specific".

Note

See also properties "Checked", "Checkable".

BackColorPressed – background color in the pressed state

Syntax:	Return Value = ReadCWProperty(TouchButtonVarName, "BackColorPressed") WriteCWProperty(TouchButtonVarName, " BackColorPressed", Value)	
Description:	Reads/sets the background color if the TouchButton is in the pressed state	
Parameters:	TouchButtonVarName	Name of the display variable that contains a SIEsTouch-Button
	Return Value	Read color of the property (string)
	Value	Value to be set (string) as RGB value in the form "#RRGGBB" e.g. "#04B7FB"

Note

This property is only available with active style "1= user-specific".

BackColorDisabled – background color in the deactivated state

Syntax:	Return Value = ReadCWProperty(TouchButtonVarName, "BackColorDisabled") WriteCWProperty(TouchButtonVarName, " BackColorDisabled", Value)	
Description:	Reads/sets the background color if the TouchButton is in the deactivated state.	
Parameters:	TouchButtonVarName	Name of the display variable that contains a SIEsTouch-Button
	Return Value	Read color of the property (string)
	Value	Value to be set (string) as RGB value in the form "#RRGGBB", for example, "#04B7FB"

Note

This property is only available with active style "1= user-specific".

Note

See also the " Enabled" property.

TextColor – text color

Syntax:	Return Value = ReadCWProperty(TouchButtonVarName, "TextColor") WriteCWProperty(TouchButtonVarName, " TextColor", Value)	
Description:	Reads/sets the text color if the TouchButton is in its quiescent state (not actuated).	
Parameters:	TouchButtonVarName	Name of the display variable that contains a SIEsTouch-Button
	Return Value	Read color of the property (string)
	Value	Value to be set (string) as RGB value in the form "#RRGGBB", for example, "#04B7FB"

Note

This property is only available with active style "1= user-specific".

TextColorChecked – text color in the checked state

Syntax:	Return Value = ReadCWProperty(TouchButtonVarName, "TextColorChecked") WriteCWProperty(TouchButtonVarName, " TextColorChecked", Value)	
Description:	Reads/sets the text color if the TouchButton is in the checked state (toggle function).	
Parameters:	TouchButtonVarName	Name of the display variable that contains a SIEsTouch-Button
	Return Value	Read color of the property (string)
	Value	Value to be set (string) as RGB value in the form "#RRGGBB", for example, "#04B7FB"

Note

This property is only available with active style "1= user-specific".

Note

See also properties "Checked", "Checkable".

TextColorPressed – text color in the pressed state

Syntax:	Return Value = ReadCWProperty(TouchButtonVarName, "TextColorPressed") WriteCWProperty(TouchButtonVarName, "TextColorPressed", Value)	
Description:	Reads/sets the text color if the TouchButton is in the pressed state	

Parameters:	TouchButtonVarName	Name of the display variable that contains a SIEsTouch-Button
	Return Value	Read color of the property (string)
	Value	Value to be set (string) as RGB value in the form "#RRGGBB", for example, "#04B7FB"

Note

This property is only available with active style "1= user-specific".

TextColorDisabled – text color in the deactivated state

Syntax:	Return Value = ReadCWProperty(TouchButtonVarName, "TextColorDisabled") WriteCWProperty(TouchButtonVarName, "TextColorDisabled", Value)	
Description:	Reads/sets the text color if the TouchButton is in the deactivated state	
Parameters:	TouchButtonVarName	Name of the display variable that contains a SIEsTouch-Button
	Return Value	Read color of the property (string)
	Value	Value to be set (string) as RGB value in the form "#RRGGBB", for example, "#04B7FB"

Note

This property is only available with active style "1= user-specific".

Note

See also the " Enabled" property.

BackgroundPicture – background picture

Syntax:	Return Value = ReadCWProperty(TouchButtonVarName, "BackgroundPicture") WriteCWProperty(TouchButtonVarName, "BackgroundPicture", Value)	
Description:	Reads/sets the permanent background picture to be displayed, i.e. independent of the state.	
Parameters:	TouchButtonVarName	Name of the display variable that contains a SIEsTouch-Button
	Return Value	read value of the property (string)
	Value	value to be set (string)

The file name is specified as value, for example "sk_ok.png". The TouchButton automatically determines the correct picture file from the current resolution directory (see Chapter Using display images/graphics (Page 63)).

In the deactivated state, the background picture is automatically shown in shades of gray.

Note

See Chapter Using display images/graphics (Page 63).

See also properties - "BackgroundPictureAlignment", "ScaleBackgroundPicture", "BackgroundPictureKeepAspectRatio".

BackgroundPictureAlignment – alignment of the background picture

Syntax:	ReturnValue = ReadCWProperty(TouchButtonVarName, " BackgroundPictureAlignment ") WriteCWProperty(TouchButtonVarName, " BackgroundPictureAlignment ", Value)	
Description:	Reads/sets the alignment of the background picture.	
Parameters:	TouchButtonVarName	Name of the display variable that contains a SIEsTouchButton
	Return Value	Read value of the property (int)
	Value	Value to be set (int): 1 = left 2 = right 32 = top 64 = bottom 128 = centered (default)

Note

See Chapter Positioning and aligning picture and text (Page 266).

See also properties - "BackgroundPictureAlignment", "ScaleBackgroundPicture", "BackgroundPictureKeepAspectRatio".

BackgroundPictureAlignmentString – alignment of the background picture

Syntax:	ReturnValue = ReadCWProperty(TouchButtonVarName, " BackgroundPictureAlignmentString ") WriteCWProperty(TouchButtonVarName, " BackgroundPictureAlignmentString ", Value)	
Description:	Reads/sets the alignment of the background picture. This property is analogous to the property "BackgroundPictureAlignment". However, the value is not transfigured here as number (int), but as string.	

Parameters:	TouchButtonVarName	Name of the display variable that contains a SIEsTouch-Button
	Return Value	Read value of the property (int)
	Value	Value to be set (int): "Left" = left "Right" = right "Top" = top "Bottom" = bottom "Center" = centered (default)

Note

See Chapter Positioning and aligning picture and text (Page 266).

See also properties - "BackgroundPictureAlignment", "ScaleBackgroundPicture", "BackgroundPictureKeepAspectRatio".

ScaleBackgroundPicture – scale background picture

Syntax:	Return Value = ReadCWProperty(TouchButtonVarName, "ScalePicture") WriteCWProperty(TouchButtonVarName, "ScalePicture", Value)	
Description:	Reads/sets whether the TouchButton (depending on the alignment) should scale the picture to be displayed.	
Parameters:	TouchButtonVarName	Name of the display variable that contains a SIEsTouch-Button
	Return Value	Read value of the property (bool)
	Value	Value to be set (bool): TRUE or FALSE (default)

Note

See Chapter Positioning and aligning picture and text (Page 266).

See also properties - "BackgroundPictureAlignment", "ScaleBackgroundPicture", "BackgroundPictureKeepAspectRatio".

BackgroundPictureKeepAspectRatio – scale background picture and keep aspect ratio

Syntax:	Return Value = ReadCWProperty(TouchButtonVarName, "BackgroundPicture-KeepAspectRatio") WriteCWProperty(TouchButtonVarName, "BackgroundPictureKeepAspectRatio", Value)	
Description:	Reads/sets, whether, when scaling (property "ScaleBackgroundPicture" = "TRUE") the aspect ratio of the background picture should be kept or not.	
Parameters:	TouchButtonVarName	Name of the display variable that contains a SIEsTouch-Button
	Return Value	Read value of the property (bool)
	Value	Value to be set (bool): TRUE (default) or FALSE

Note

See Chapter Positioning and aligning picture and text (Page 266).

9.6.4 Functions

You can call the subsequently listed functions using the CallCWMethod() function.

Example

Setting the margins of the SIEsTouchButton linked using display variable "MyTouchButton".

The result is written to register 0.

```
REG[0] = CallCWMethod("MyTouchButton", "setMargins", 20, 20, 20, 20, 20)
```

Overview

Function	Description
setMargins	Setting the margins
serialize	Saves/restores the actual state

setMargins – setting the margins

Syntax:	ReturnValue = CallCWMethod(TouchButtonVarName, " setMargins ", left, top, right, bottom, center) ReturnValue = CallCWMethod(TouchButtonVarName, " setMargins ", left, top, right, bottom, center, marginAlignment)
Description:	Using this function, the margin clearances and the distance between picture and text are defined. If a value of "-1" is specified, then this value is applicable for the system default clearance. If the value is greater or equal to "0", then the value is set as edge clearance.

Parameters:	TouchButtonVarName	Name of the display variable that contains a SIEsTouchButton
	Return Value	Error code (bool): TRUE = successful
	left	lefthand edge (int)
	top	top edge (int)
	right	right-hand edge (int)
	bottom	bottom edge (int)
	center	Clearance between picture and text (int), if the alignment is not "center"
	marginAlignment	Optional: Defines whether the margin next to the displayed picture should also apply when positioning the display text (bool), TRUE (default)

serialize – save/restore the actual state

Syntax:	ReturnValue = CallCWMMethod(TouchButtonVarName, "serialize", FilePath, IsStoring)	
Description:	With this function, when required, you can write and restore the actual state and content of the SIEsTouchButton binary into a file or Data Stream. This function automatically refreshes the display.	
Parameters:	TouchButtonVarName	Name of the display variable that contains a SIEsTouchButton
	Return Value	Error code (bool): TRUE = successful
	FilePath	Complete path with file name (QString)
	IsStoring	Save/restore (bool): TRUE = save

Note

Programming engineers do not directly use this function!

9.6.5 Signals

You can capture the subsequently described signals in the configuration and respond appropriately.

Overview

Function	Description
clickedDisabled	Press a deactivated TouchButton
clicked	A click or tap is executed
checked	It was toggled

- If a TouchButton can be operated - but it cannot be toggled - then "clicked" signal is sent when the TouchButton is pressed.
- If a TouchButton can be operated and toggled - then the following sequence of signals is sent when the TouchButton is pressed.
"checked" → "clicked"
- If a TouchButton cannot be operated - then the "clickedDisabled" signal is sent when the TouchButton is pressed.

All of the signals mentioned above are only sent after an operator action, i.e. only once the mouse or the space bar has been released or after a tap for multitouch.

As a consequence, the SIEsTouchButton has a pure switch function, i.e. a pushbutton function is not possible.

Note

For multitouch operation, note that a click can only be sent if a tap gesture has been completely identified (pressing and releasing within approximately 0.7 seconds). If an action was already carried out when simply pressing, it would not be possible for example to scroll/shift the ScrollArea behind, or it could lead to operator input errors.

clicked – the TouchButton was clicked

Syntax:	SUB(on_<TouchButtonVarName>_clicked) ... END_SUB	
Description:	A complete sequence comprising pressing and releasing a TouchButton (that can be operated) results in a "clicked" signal. We recommend working predominantly with this signal.	
Parameters:	TouchButtonVarName	Name of the display variable that contains a SIEsTouch-Button
	SIGARG[0]	Supplies the toggle state of the TouchButton (bool)

Example

```

DEF MyTouchButton = (W///,"slesstdcw.SIEsTouchButton"////70,20,200,100/0,0,0,0)
SUB(on_MyTouchButton_clicked)
  DLGL("checked: " << SIGARG[0])
END_SUB

```

checked – a TouchButton was toggled

Syntax:	SUB(on_<TouchButtonVarName>_checked) ... END_SUB	
Description:	A TouchButton that can be toggled was pressed, which changed its state.	
Parameters:	TouchButtonVarName	Name of the display variable that contains a SIEsTouch-Button
	SIGARG[0]	Supplies the toggle state of the TouchButton (bool)

Example

```

DEF MyTouchButton = (W///,"slesstdcw.SIEsTouchButton"////70,20,200,100/0,0,0,0)
SUB(on_MyTouchButton_toggled)
  DLGL("toggled: " << SIGARG[0])
END_SUB

```

clickedDisabled – a TouchButton that cannot be operated was clicked

Syntax:	SUB(on_<TouchButtonVarName>_clickedDisabled) ... END_SUB	
Description:	A complete sequence comprising pressing and releasing a TouchButton (that cannot be operated) results in a "clickedDisabled" signal.	
Parameters:	TouchButtonVarName	Name of the display variable that contains a SIEsTouch-Button
	SIGARG[0]	Supplies the toggle state of the TouchButton (bool)

Example

```

DEF MyTouchButton = (W///,"slesstdcw.SIEsTouchButton"////70,20,200,100/0,0,0,0)
SUB(on_MyTouchButton_clickedDisabled)
  DLGL("checkedDisabled: " << SIGARG[0])
END_SUB

```

9.6.6 Positioning and aligning picture and text

Positioning pictures

A picture is positioned as follows with the specified alignment:

- In a first step, the picture matching the current resolution is determined from the associated resolution directory.
- The rectangle of the area (ClientArea) is then reduced by the specified clearances to the edges (MarginArea).

The MarginArea can be influenced using the "setMargins" function:

- setMargins(-1, -1, -1, -1, -1)




Figure 9-33 setMargins(-1, -1, -1, -1, -1)

- setMargins(0, 0, 0, 0, 0)




Figure 9-34 setMargins(0, 0, 0, 0, 0)

- setMargins(20, 20, 20, 20, 20)




Figure 9-35 setMargins(20, 20, 20, 20, 20)

Example for alignment "left"

The area is horizontally halved, so that the picture to be displayed can assume half (maximum) of the area.

The picture is then drawn as follows:

- Property "scalePicture": FALSE
The picture is drawn at this location without any scaling. It must be ensured that the basic picture is not too large, and can be completely displayed within the TouchButton.




Figure 9-36 scalePicture FALSE

- Property "scalePicture": TRUE
The picture is scaled (stretched or compressed), so that it fits into the left-hand half of the TouchButton. The "pictureKeepAspectRatio" property is taken into account as follows:
 - Property "pictureKeepAspectRatio": FALSE
The picture is scaled horizontally and vertically so that it precisely fits into the left-hand half of the TouchButton. In so doing, the aspect ratio of the original picture is no longer taken into consideration.




Figure 9-37 scalePicture - pictureKeepAspectRatio FALSE

- Property "pictureKeepAspectRatio": TRUE
Taking into consideration the aspect ratio of the original picture, the picture is scaled large enough so that it just fits into the left-hand half of the TouchButton.




Figure 9-38 scalePicture - pictureKeepAspectRatio TRUE

Note

The same principle applies for "right", "top" and "bottom" alignments.

For the "centered" alignment, an attempt is made to fit the picture - depending on the "scalePicture" and "pictureKeepAspectRatio" properties - in the complete MarginArea.

Positioning the text

The text is positioned as follows depending on the "textAlignedToPicture" property:

- Property "textAlignedToPicture": FALSE
The text is shown in the MarginArea centered vertically and horizontally.




Figure 9-39 textAlignedToPicture FALSE

- Property "textAlignedToPicture": TRUE
The text is output in the remaining area of the MarginArea minus the area of the drawn picture, centered horizontally and vertically.




Figure 9-40 textAlignedToPicture TRUE

9.6.7 Language-dependent texts

SLEsTouchButton does not support foreign languages by itself. However, the following example shows how you can implement language dependency:

Example

easyscreen.ini:

```
[LANGUAGEFILES]LngFile03 = user.txt
```

user_eng.txt:

```
85000 0 0 "This is my first TouchButton !!!"
```

user_deu.txt:

```
85000 0 0 "Das ist mein erster TouchButton !!!"
```

Configuration file:

```
//M(MyTBMask/"My CustomWidget TouchButton ...")
DEF MyTB1 = (W///,"slesstdcw.SLEsTouchButton"//////70,20,200,100/0,0,0,0)
LOAD
```

```
//M(MyTBMask/"My CustomWidget TouchButton ...")
DEF MyTB1 = (W///,"slesstdcw.SIEsToggleButton"////70,20,200,100/0,0,0,0)
WRITECWPROPERTY("MyTB1", "text", $85000)
END_LOAD
LANGUAGE
WRITECWPROPERTY("MyTB1", "text", $85000)
END_LANGUAGE
```

The texts are automatically wrapped around at the word limits in the rectangle provided. The forced line break is only possible if the text to be displayed is sourced from a language file A "%n" must be inserted at the appropriate location in the text (see the following example).

user_eng.txt:

```
85001 0 0 "This is%nmynfirst%nTouchButton !!!"
```

Configuration file:

```
WRITECWPROPERTY("MyTB1", "text", $85001)
```

Result




Figure 9-41 Example of a line break in a language-dependent text

"Custom" operating area

10.1 How to activate the "Custom" operating area

Activating the "Custom" operating area

The "Custom" operating area is not activated on delivery.

1. First copy the "slamconfig.ini". file from the directory [System siemens-directory]/cfg into the directory [System oem-directory]/cfg or correspondingly into [System addon-directory]/cfg or [System user-directory]/cfg.
2. To activate the "Custom" operating area, the following must be entered:
`[Custom]`
`Visible=True`

Result

After activation is complete, the softkey for the "Custom" operating area can be found in the main menu (F10) on the menu continuation bar on the HSK4 (= default).

The "Custom" operating area displays an empty window covering the entire operating area, with a configurable header. All horizontal and vertical softkeys can be configured.

10.2 How to configure the "Custom" softkey

Configuring the softkey for the "Custom" operating area

The labeling and position of the softkey for the "Custom" operating area are configured in the "slamconfig.ini" file.

The following options are available for configuring the start softkey:

1. To replace a softkey label with a **language-dependent text**, the following must be entered in the [Custom] section:
`TextId=MY_TEXT_ID`
`TextFile=mytextfile`
`TextContext=mycontext`
In this example, the softkey shows the language-dependent text which was saved with the text ID "MY_TEXT_ID" in text file mytextfile_xxx.qm under "MyContext" (xxx stands for language code).
2. To replace a softkey label with a **language-neutral text**, the following must be entered in the [Custom] section:
`TextId=HELLO`
`TextFile=<empty>`
`TextContext=<empty>`
In this example, the softkey for the "Custom" operating area displays the text "HELLO" for every language.
3. **An icon** can also be displayed on the softkey in addition to the text.
To do this, the following must be entered in the [Custom] section:
`Picture=mypicture.png`
The softkey then displays the icon from the file mypicture.png. Graphics and bitmaps are stored at the following path: [System oem directory]/ico/ico<resolution>. The directory that corresponds to the display resolution must be used.
4. **The position** of the softkey can also be set. The following entry in the [Custom] section makes this setting:
`SoftkeyPosition=12`
The default is position 12. This corresponds to the HSK4 on the menu continuation bar of the operating area's menu. Positions 1 - 8 correspond to HSK1 to HSK8 on the menu bar, positions 9 - 16 to HSK1 to HSK8 on the menu continuation bar.

10.3 How to configure the "Custom" operating area

Configuring the softkey for the "Custom" operating area

You need the "easyscreen.ini" and "custom.ini" files to configure the operating area. Templates for both these files are available in the directory [System siemens-directory]/templates/cfg.

1. First copy the files to the directory [System oem directory]/cfg and make your changes there.
2. The "easyscreen.ini" file already contains a definition line for the "Custom" operating area:
`;StartFile02 = area := Custom, dialog := SlEsCustomDialog,`
`startfile := custom.com`
The ";" at the start of the line represents the comment character. This means the line is commented out and, as such, not active. To change this, the ";" must be deleted.
The "startfile" attribute in this line defines that the entry will refer to the "custom.com" project file when the "Custom" operating area is selected.

3. You create the **project file "custom.com"** in the directory [System oem-directory]/proj. This contains the relevant configuration which is created in the same way as the "aeditor.com" file of the "Program" operating area. The configured start softkeys are then displayed in the "Custom" operating area.
4. You configure the **language-neutral text** for the title bar of the dialog in the "custom.ini" file. The following entry is available in the template for this purpose:
[Header]
Text=Custom
You can replace this text with a customized one.
5. The template contains the following entry for configuring a **start screen** for the "Custom" operating area:
[Picture]
Picture=logo.png
Logo.png is the name of the start screen which appears on the "Custom" operating area's start dialog. Here you can display a company logo, for example, or another image. The file should be saved in the directory for the corresponding resolution under: [System oem-directory]/icol/ ...
6. In order to display a specific "Run MyScreens" screen when the "Custom" operating area is shown the first time, the following entry is available in the template:
; Mask shown with startup of area "custom"
[Startup]
;Startup = Mask:=MyCustomStartupMask, File:=mycustommasks.com
Typically, SINUMERIK Operate is started directly with a specific "Run MyScreens" screen. The "startuparea" key must be set as follows in the "[miscellaneous]" section of the "systemconfiguration.ini" file:
[miscellaneous]
;name of the area to be shown at system startup
startuparea = Custom

10.4 Programming example for the "Custom" area

Example




Figure 10-1 Example with "Start example" softkey




Figure 10-2 Example with bitmap and text fields

File overview

The following files are required:

- "custom.com"
- "easyscreen.ini"

Programming

Content of file "custom.com":

Note

The graphic file "mcp.png" integrated in the example is also only a sample file. If you wish to use this programming example in your application, you must replace the graphic by one of your own graphics.

```
//S(Start)
HS7=("Start example", sel, ac7)
PRESS (HS7)
LM ("Maske4")
```

10.4 Programming example for the "Custom" area

```
END_PRESS
//END
//M(Maske4/"Example: MCP"/"mcp.png")
DEF byte=(I/O/0/"Input byte=0 (default)", "Byte number:", ""/wr1,li1//380,40,100/480,40,50)
DEF Feed=(IBB//0/""/"Feed override", ""/wr1//EB3"/20,180,100/130,180,100), Axistop=(B//0/""/"Feed
stop", ""/wr1//E2.2"/280,180,100/380,180,50/100)
DEF Spin=(IBB//0/""/"Spindle override", ""/wr1//EB0"/20,210,100/130,210,100), spinstop=(B//
0/""/"Spindle stop", ""/wr1//E2.4"/280,210,100/380,210,50/100)
DEF custom1=(IBB//0/""/" User keys 1", ""/wr1//EB7.7"/20,240,100/130,240,100)
DEF custom2=(IBB//0/""/"User keys 2", ""/wr1//EB7.5"/20,270,100/130,270,100)
DEF By1
DEF By2
DEF By3
DEF By6
DEF By7

HS1=("Input byte", SE1, AC4)
HS2=("")
HS3=("")
HS4=("")
HS5=("")
HS6=("")
HS7=("")
HS8=("")
VS1=("")
VS2=("")
VS3=("")
VS4=("")
VS5=("")
VS6=("")
VS7=("Cancel", SE1, AC7)
VS8=("OK", SE1, AC7)

PRESS (VS7)
EXIT
END_PRESS

PRESS (VS8)
EXIT
END_PRESS

LOAD
By1=1
By2=2
By3=3
```

```
By6=6
By7=7
END_LOAD

PRESS (HS1)
  Byte.wr=2
END_PRESS

CHANGE (Byte)
  By1=byte+1
  By2=byte+2
  By3=byte+3
  By6=byte+6
  By7=byte+7
  Feed.VAR="EB"<<By3
  Spin.VAR="EB"<<Byte
  Custom1.VAR="EB"<<By6
  Custom2.VAR="EB"<<By7
  Axisstop.VAR="E"<<By2<<".2"
  Spinstop.VAR="E"<<By2<<".4"
  Byte.wr=1
END_CHANGE

CHANGE (Axis stop)
  IF Axistop==0
    Axistop.BC=9
  ELSE
    Axistop.BC=11
  ENDIF
END_CHANGE

CHANGE (Spin stop)
  IF Spinstop==0
    Spinstop.BC=9
  ELSE
    Spinstop.BC=11
  ENDIF
END_CHANGE
//END
```


Dialog selection

11.1 Dialog selection using PLC softkeys

Configuration

Description of the procedure:

- The "systemconfiguration.ini" contains a section [keyconfiguration]. The entry specifies an action for a special PLC softkey.
- A number is given as an action. A "Run MyScreens" call is involved if the number is greater than or equal to 100.
- A section for defining the action to be performed must be created in the "easyscreen.ini" file. The name of the section is based on the name of the operating area and the dialog name (see entry under [keyconfiguration] → Area:=..., Dialog:=...) → [<Area>_<Dialog>]
→ e.g. [AreaParameter_SIPaDialog]
- The action numbers (which were given in the "systemconfiguration.ini" → see Action:=...) are defined in this section. There are two commands involved:
 1. LS("Softkey menu1","param.com") ... Loading a softkey menu
 2. LM("Screen form1","param.com") ... Loading a screen form

Selecting softkey menus via PLC softkeys

"Run MyScreens" makes it possible to select "Run MyScreens" softkey menus and "Run MyScreens" dialogs via PLC softkeys. This can only be done if the "action" attribute to be specified when configuring the relevant PLC softkeys has a value greater than or equal to 100.

PLC softkeys are configured in the file "systemconfiguration.ini" in the section [keyconfiguration]:

```
[keyconfiguration]
```

```
KEY75.1 = Area:=area, Dialog:=dialog, Screen:=screen, Action:= 100,
```

11.1 Dialog selection using PLC softkeys

The LM and LS commands to be executed upon activation of the relevant PLC softkeys are configured in the "easyscreen.ini" file. The names of the sections that are used for the purpose of configuration are structured as follows:

[areaname_dialogname]	The first part of the name "areaname" refers to the operating area and the second part "dialogname" designates the dialog to which the commands configured in this section apply.
[AreaParameter_SlPaDialog] 100.screen1 = LS("Softkey1", "param.com") 101.screen3 = LM("Screen form1", "param.com")	The names given in the "systemconfiguration.ini" file for the operating area and dialog should be used. The dialog does not have to be specified. This is particularly true for operating areas which are only implemented by means of a single dialog. Please refer to the example on the left. If "screen1" is displayed in the AreaParameter operating area implemented by the SlPaDialog dialog, the "LS("Softkey1", "param.com")" command will be executed when the "action" with the value 100 occurs.
action.screen=Command	Both the "action" and "screen" attributes clearly indicate when the specified command will be executed. The "screen" information is optional. The following commands are permissible: LM (LoadMask) LS (LoadSoftkeys)

11.1.1 Calling Run MyScreens-cycle screens in the program editor

Application

PLC keys provide the possibility to open Run MyScreens cycle screens directly in the program editor.

Boundary condition

A technology cycle can only be selected when the program editor is open. The technology cycle parameterized via the screen will be inserted at the current cursor position in the program editor.

Procedure

1. Create the Run MyScreens cycle call via PLC hard keys (Page 282).
2. In order for the Run MyScreens screen to be properly integrated into the program editor, you must extend the PLC Key configuration as described in the following example:

Example of a complete key configuration:

```
systemconfiguration.ini
[keyconfiguration]
KEY101.0 = action:=209, runmyscreenmode:=HandledByDialog
easyscreen.ini
[AreaProgramEdit_SlProgramEdit]
209 = LM("MASK_E_DR_O1_MAIN", "e_dr_o1.com")
```

3. You can check the feedback from the open Run MyScreens cycle screen via the PLC interface "DB19.DBW24".

Example:

In this example, the value "9876" is written to the PLC interface when the Run MyScreens screen is opened:

Configuration with PLC-ID=9876:

```
//M(MASK_E_DR_O1_MAIN/$85305/////XG1,FA2,TA7//"drilling.txt"/9876)
```

or

```
//M{ MASK_E_DR_O1_MAIN, HD=$85305, LANGFILELIST=" drilling.txt", PLC_ID=9876}
```

See also: Function Manual SINUMERIK 840D sl Basic Functions

Status of the program editor on the OA interface

You can query the status of the program editor via the CAP local variable "/Hmi/StepEditorInfo".

Name of variable:	/Hmi/StepEditorInfo
Description of variable:	Information from the editor about the program that has the focus.
The string contains the following information	
[fileName]	Program path definition
[channel]	Channel number
[technology]	Technology
[appearance]	Program identifier (ShopMill/ShopTurn/G code)
[state]	Step editor status: • EditorClosed: Editor is closed (e.g. HMI not in program operating area) • EditEnabled: Editing allowed • EditDisabled: Editing not allowed (e.g. read only or invalid cursor position)

11.2 Dialog selection using PLC hard keys

Application

The following functions can be initiated in the operating software by the PLC:

- Select an operating area
- Select certain scenarios within operating areas
- Execute functions configured at softkeys

Hardkeys

All keys - also the PLC keys - are subsequently referred to as hardkeys. A maximum of 254 hardkeys can be defined. The following allocation applies:

Key number	Use
Key 1 – key 9	Keys on the operator panel front
Key 10 – key 49	Reserved
Key 50 – key 254 Key 50 – key 81	PLC keys: Reserved for OEMs
Key 255	Pre-assigned by control information.

Hardkeys 1 - 9 are pre-assigned as follows:

Key designation		Action / effect
HK1	MACHINE	Selects "Machine" operating area, last dialog
HK2	PROGRAM	Selects "Program" operating area, last dialog or last program
HK3	OFFSET	Selects "Parameter" operating area, last dialog
HK4	PROGRAM MANAGER	Selects "Program" operating area, "Program Manager" basic screen
HK5	ALARM	Selects "Diagnostics" operating area, "Alarm list" dialog
HK6	CUSTOM	Selects "Custom" operating area
HK7 ¹⁾	MENU SELECT	Selects "Main menu"
HK8 ¹⁾	MENU FUNCTION	Selects "Function" operating area
HK9 ¹⁾	MENU USER	Selects "User" operating area

1) For 828D only

Configuration

The configuring is realized in the "systemconfiguration.ini" configuration file in the section [keyconfiguration]. Each line defines what is known as a hardkey event. A hardkey event is the n-th actuation of a specific hardkey. For example, the second and third actuation of a specific hardkey can result in different responses.

The entries in the "systemconfiguration.ini" configuration file can be overwritten with user-specific settings. The directories [System user-directory]/cfg and [System oem-directory]/cfg are available for this purpose.

The lines for configuring the hardkey events have the following structure:

```
KEYx.n = area:=area, dialog:=dialog, screen:=screen, forms:=form,
menus:=menu,
action:=menu.action, cmdline:=cmdline
KEYx.n = area:=area, dialog:=dialog, cmdline:=cmdline, action:=
action
```

x: Number of the hardkey, range of values: 1 – 254

n: Event number – corresponds to the nth actuation of the hardkey, range of values: 0 – 9

Requirement

The PLC user program must fulfill the following requirement:

Only one hardkey is processed. As a consequence, a new request can only be set if the operating software has acknowledged the previous request. If the PLC user program derives the hardkey from an MCP key, it must provide sufficient buffer storage of the key(s) to ensure that no fast keystrokes are lost.

PLC interface

An area to select a hardkey is provided in the PLC interface. The area is in DB19.DBB10. Here, the PLC can directly specify a key value of between 50 and 254.

Acknowledgment by the operating software takes place in two steps. This procedure is necessary so that the operating software can correctly identify two separate events if the same key code is entered twice consecutively. In the first step, control information 255 is written to byte DB19.DBB10. This defined virtual key stroke enables the HMI to identify every PLC key sequence uniquely. The control information is of no significance to the PLC user program and must not be changed. In the second step, the actual acknowledgment takes place with respect to the PLC by clearing DB19.DBB10. From this point in time, the PLC user program can specify a new hardkey. In parallel, the actual hardkey request is processed in the operating software.

Example

Configuration file:

```
; PLC hardkeys (KEY50-KEY254)
[keyconfiguration]
KEY50.0 = name := AreaMachine, dialog := SlMachine
KEY51.0 = name := AreaParameter, dialog := SlParameter
KEY52.0 = name := AreaProgramEdit, dialog := SlProgramEdit
KEY53.0 = name := AreaProgramManager, dialog := SlPmDialog
KEY54.0 = name := AreaDiagnosis, dialog := SlDgDialog
KEY55.0 = name := AreaStartup, dialog := SlSuDialog
KEY56.0 = name := Custom, dialog := SlEsCustomDialog
```

The area and dialog identifiers can be found in the "systemconfiguration.ini" from [system siemens-directory]/cfg.

11.3 Dialog selection via NC

MMC command in HMI Operate

You can use MMC commands as described in the following:

1. Definition of MMC commands

The following combinations are available in the standard "systemconfiguration.ini" file:

address:=MCYCLES --> command:=LM

address:=CYCLES --> command:=PICTURE_ON

This distinction is necessary, in order to make a differentiation between measuring cycles and other cycles. This means that:

- LM is always applicable for measuring cycles, PICTURE_ON always for non-measuring cycles
- It is not permissible that newly defined MMC commands are designated PICTURE_ON and LM

2. "Run MyScreens" license

All of the dialogs opened by "Run MyScreen" – with the exception of the measuring cycles – fall under the "Run MyScreens" license, and therefore without license, only a limited number of dialogs can be used.

Example call with "test.com" (Run MyScreens):

```
g0 f50
```

```
MMC ("CYCLES, PICTURE_ON, test.com, screen form1", "A")
```

```
m0
```

```
MMC ("CYCLES, PICTURE_OFF", "N")
```

```
M30
```

Examples for cycle masks

12.1 Examples for cycle masks

When installing SINUMERIK Operate, examples for cycle masks created with Run MyScreens are also saved to the system.

The Run MyScreens examples are available under the following archive paths:

[System siemens-directory]		
...\siemens\sinumerik\hmi\template\easy\screen\		
...		
	standard\	Help screens, PNG
	x3d\	Help screens / animations
...		
	Milling\	Fräsbearbeitung
	Turning\	Drehbearbeitung
...		
	deu\	German description
	eng\	English description

Examples in the commissioning operating area can be found on the HMI user interface:

Horizontal softkey system data → HMI data → Templates → Examples → Easy Screen → ... (see above).

Brief description of the examples

- Milling
 - Drilling example: This is where a position can be added
 - Measure workpiece example: This is where a cycle call can be generated and processed via NC start while the dialog is open
 - Workpiece counter example: This shows how GUDs should be handled
- Turning
 - Fixtures: this contains a tailstock, bar loader, part catcher
 - Measure workpiece example: This is where a cycle call can be generated and processed via NC start while the dialog is open
 - Drilling example: This is where a position can be added

Configuration in the side screen

The following options are available to you for displaying Run MyScreens configurations in the side screen:

1. Display of a Run MyScreens configuration in a (separate) side screen page:
The Run MyScreens configuration takes up all of the space of the side screen page.
2. Display of several Run MyScreens configurations in a (separate) side screen page:
The individual Run MyScreens configurations are displayed above each other within the side screen page, in so-called side screen elements. The side screen elements, and thus also the Run MyScreens configurations, can be scrolled vertically.
3. Adding one or more Run MyScreens configurations to an existing side screen page:
I.e. the Run MyScreens configuration is added to a side screen page contained in the SIEMENS delivery kit. This case matches point 2 with the exception of the affected side screen page.
4. Adding one or more Run MyScreens configurations to a side screen element:
The individual Run MyScreens configurations are displayed next to each other in so-called side screen widgets and can be scrolled horizontally.

13.1 Display of a Run MyScreens configuration in a side screen page

To display a Run MyScreens configuration in a (separate) side screen page, you must add a new side screen page to the existing side screen configuration ("slsidescreen.ini"). The Run MyScreens configuration is then displayed or executed in this side screen page.




Figure 13-1 Display of a Run MyScreens configuration in a side screen page

Procedure

Expand the file "slsidescreen.ini" by the following entry:

```
[Sidescreen]
PAGE100= name:=RMSPage,
implementation:=slseasyscreen.SlEsSideScreenPage
```

13.1 Display of a Run MyScreens configuration in a side screen page

- The number of the page, "100" in this case, must be counted up corresponding to existing side screen pages. The number of the page must be ≥ 100 . This avoids conflicts with the SIEMENS pages.
- You can freely select the name of the page, "RMSPage" in this case.
- You cannot change the specification for implementing the page, "sleasyscreen.SlEsSideScreenPage" in this case.

Configure the Run MyScreens configuration that is to be carried out in the next step. To do this, create a new section with a name that contains the name of the newly created page:

```
[Page_RMSPage]
Icon=rmspage.png
PROPERTY001= name:=maskPath, type:=QString,
value:="sidescreenmask.com"
PROPERTY002= name:=maskName, type:=QString, value:="Mask"
PROPERTY003= name:=focusable, type:=bool, value:="true"
```

- The name of the section is formed by appending the name of the page to the prefix "Page_", in this case "RMSPage".
- Under Icon, specify the file name, "rmspage.png" in this case. The file contains the icon for the button for selecting the page. Store the file in the directory /user/sinumerik/hmi/ico/ico640 or /oem/sinumerik/hmi/ico/ico640.
- In the property maskPath, specify the name of the file that contains the RunMyScreens configuration, "sidescreenmask.com" in this case.
- In the property maskName, specify the name of the RunMyScreens mask that is to be displayed, "sidescreenmask.com" in this case.
- Specify the input focus in the Property focusable. The page can be assigned the input focus only if this attribute has the value "true". This attribute is required for pages with input elements.

Store the "slsidescreen.ini" in the directory /oem/sinumerik/hmi/cfg or /user/sinumerik/hmi/cfg.

The Run MyScreens configuration is available after the next HMI power-up.

Example

Example for a complete configuration in "slsidescreen.ini":

```
[Sidescreen]
PAGE005= name:=RMSPage,
implementation:=sleasyscreen.SlEsSideScreenPage
[Page_RMSPage]
PROPERTY001= name:=maskPath, type:=QString,
value:="sidescreenmask.com"
PROPERTY002= name:=maskName, type:=QString, value:="Mask"
```

13.2 Display of several Run MyScreens configurations in a side screen page

For the display of several Run MyScreens configurations in a (separate) side screen page, you must also configure so-called side screen elements, in addition to the side screen page. The side screen elements are used to display the Run MyScreens configurations.




Figure 13-2 Display of several Run MyScreens configurations in a side screen page

Procedure

Expand the "slsidescreen.ini" by the following entries:

```
[Sidescreen]
```

```
PAGE100= name:=RMSPage, implementation:=SlSideScreenPage
```

13.2 Display of several Run MyScreens configurations in a side screen page

- The number of the page, "100" in this case, must be counted up corresponding to existing side screen pages. The number of the page must be ≥ 100 . This avoids conflicts with the SIEMENS pages.
- You can freely select the name of the page, "RMSPage" in this case.
- You cannot change the specification for implementing the page, "SISideScreenPage" in this case.

```
[Page_RMSPage]
ELEMENT001= name:=RMSElement001,
implementation:=sleseasyscreen.SlEsSideScreenElement
ELEMENT002= name:=RMSElement002,
implementation:=sleseasyscreen.SlEsSideScreenElement
```

- Two side screen elements are assigned to the page – RMSElement001 and RMSElement002. You can freely select the names of the elements.
- You cannot change the specification for implementing the elements, "sleseasyscreen.SlEsSideScreenElement" in this case.

Finally, you must assign Run MyScreens configurations that are still to be displayed in these elements to the side screen elements:

```
[Element_RMSElement001]
PROPERTY001= name:=maskPath, type:=QString,
value:="sidescreenmask.com"
PROPERTY002= name:=maskName, type:=QString, value:="Mask001"
...
[Element_RMSElement002]
PROPERTY001= name:=maskPath, type:=QString,
value:="sidescreenmask.com"
PROPERTY002= name:=maskName, type:=QString, value:="Mask002"
```

Store the "slsidescreen.ini" in the directory /oem/sinumerik/hmi/cfg or /user/sinumerik/hmi/cfg.

The Run MyScreens configuration is available after the next HMI power-up.

13.3 Adding Run MyScreens configurations to a side screen page

The procedure for integrating one or several Run MyScreens configurations for an existing side screen page is identical to the procedure described in Chapter Display of several Run MyScreens configurations in a side screen page (Page 290). The only difference is that the side screen elements for displaying the Run MyScreens configurations are added to an existing side screen page.




Figure 13-3 Adding Run MyScreens configurations to a side screen page

Note

Of the side screen pages contained in the SIEMENS delivery kit, you can only expand the WidgetsPage (see file "slsidescrini") with Run MyScreens configurations.

Procedure

Expand the "slsidescreen.ini" by the following entries:

In the [Page_WidgetsPage] section, add a corresponding element for receiving the Run MyScreens configuration.

```
[Page_WidgetsPage]
ELEMENT100= name:=RMSElement,
implementation:=slseasyscreen.SlEsSideScreenElement
```

- Use a number range ≥ 100 for new elements. This avoids conflicts with the SIEMENS display elements. The RMSElement is inserted in the WidgetsPage under the SIEMENS elements according to this numbering.

```
[Element_RMSElement]
PROPERTY001= name:=maskPath, type:=QString,
value:="sidescreenmask.com"
PROPERTY002= name:=maskName, type:=QString, value:="Mask001"
```

13.4 Adding Run MyScreens configurations to a side screen element

The basis of the procedure that is described in the following as example is a side screen page with a side screen element. Two Run MyScreens configurations are displayed next to each other in the side screen element.

Configure a side screen page with a side screen element as described in the following. Assign two side screen widgets with the respective Run MyScreens configurations to the side screen element.

Procedure

Expand the "slsidescreen.ini" by the following entries:

```
[Sidescreen]
PAGE100= name:=RMSPage, implementation:=SlSideScreenPage
```

- You cannot change the specification for the implementation, "SlSideScreenPage" in this case.

```
[Page_RMSPage]
ELEMENT001= name:=RMSElement, implementation:= SlSideScreenElement
```

- You cannot change the specification for the implementation, "SlSideScreenElement" in this case.

```
[Element_RMSElement]
TextId=RMS_ELEMENT_TITLE
TextFile=rmstexts
TextContext=rmstexts
TextContext=rmstexts
WIDGET001= name:=RMSWidget001,
implementation:=slseasyscreen.SlEsSideScreenWidget
WIDGET002= name:=RMSWidget002,
implementation:=slseasyscreen.SlEsSideScreenWidget
```

13.4 Adding Run MyScreens configurations to a side screen element

- When the `SIsideScreenElement` implementation is used for the side screen element (see Section [Page_RMSPage]), the side screen element has a title bar in which a text can be displayed.

This text is configured with the entries `TextId`, `TextFile` and `TextContext`:

- `TextId`: Text ID of the text to be displayed
- `TextFile`: File in which the text is saved
- `TextContext`: Text context, in which the text is located within this file

A separate file must be provided for each language.

The name of these files is formed according to the following diagram:

`<TextFile>_<Sprachsuffix>.ts`, e.g. `rmstexts_deu.ts` for the example above.

If you do not specify a file or a context (`TextFile=<empty>` and `TextContext=<empty>`), the text ID is displayed as text. You can specify any string as the text ID.

The text file (e.g. `rmstexts_deu.ts`) is structured as follows:

```
<?xml version="1.0" encoding="utf-8"?>
<!DOCTYPE TS>
<TS>
  <context>
    <name>rmstexts</name>
    <message>
      <source>My application</source>
      <translation>My Application</translation>
    </message>
  </context>
</TS>
```

Store the file in the directory `/oem/sinumerik/hmi/lng` or `/user/sinumerik/hmi/lng`. During the next HMI power-up, the file is converted to the file format that is needed during runtime.

- You can freely select the names of the widgets assigned to the element, "RMSWidget001" and "RMSWidget002" in this case.
- You must not change the widget implementation "slseasysscreen.SIEsSideScreenWidget".

[Widget_ **RMSWidget001**]

```
PROPERTY001= name:=maskPath, type:=QString, value:="mymask001.com"
PROPERTY002= name:=maskName, type:=QString, value:="MyMask001"
```

[Widget_ **RMSWidget002**]

```
PROPERTY001= name:=maskPath, type:=QString, value:="mymask002.com"
PROPERTY002= name:=maskName, type:=QString, value:="MyMask002"
```

- The names of the sections are formed for configuring the side screen widgets by appending the name of the widget that is to be configured in this section to the prefix "Widget_".
- In the Property `maskPath`, specify the name of the file that contains the RunMyScreens configuration, "mymask001.com" or "mymask002.com" in this case.
- In the Property `maskName`, specify the name of the RunMyScreens mask that is to be displayed, "MyMask001" or "MyMask002" in this case.

13.5 Notes on carrying out Run MyScreens configurations in the side screen

Note the following:

- The functions LS, LM, DLGL, EXIT, EXITLS are not available when carrying out Run MyScreens configurations in the side screen.
- It is not possible to query the mask size in the LOAD block.
- Texts are always displayed using the font that is used in SINUMERIK Operate with a screen resolution of 640x480 pixels.
- The configured positions of operator controls are implemented without changes (e.g. extension).
- The dialog size is adapted automatically.
- If Run MyScreens configurations are carried out in a side screen page, the entire area of the page is available for the configuration. When carrying out in side screen elements or widgets, the area available for display is specified by the system depending on the context.
- The header and softkeys cannot be configured.
- All of the debugging and error outputs are sequentially written to the text file "easyscreen_log.txt". There is no specific identification indicating which configuration a message comes from.
- The status of a Run MyScreens configuration displayed in the side screen is rejected when the configuration is faded out.

Note

The integration of Run MyScreens configurations into the side screen can lead to more than one Run MyScreens configuration being carried out simultaneously. To maintain the functional capability of the overall system, take note of the additional system load caused as a result of the hardware used.

Configuration in the Display Manager

14.1 Displaying Run MyScreens configurations in the Display Manager

The `SlSideScreenDialog` dialog is available to you for displaying Run MyScreens configurations in the Display Manager. Depending on the space available, this dialog can display one or more side screen pages (see IM9 Chapter 3.13). Several pages are displayed next to each other in column format. The available space (width) is evenly divided among the individual columns. The number of pages to be displayed and their content are configured. Each page has its own configuration file. The names of these configuration files are specified during the dialog configuration in the "systemconfiguration.ini" file, in the command line parameter "cmdline". Behind the parameter identifier "-sidescreen1" is the name of the configuration file for the first column; behind the parameter identifier "-sidescreen2" is the name of the configuration file for the second column, etc.

Example

```
[dialogs]
DLG500= name:=RMSApp,
implementation:=sldmsidescreenapp.SlSideScreenDialog,
process:=SlHmiHost1, preload:=false, cmdline:="-sidescreen1
rmspage1.ini -sidescreen2 rmspage2.ini -spacing 3"
```

The instance of the `SlSideScreenDialog` dialog created in this example has the name `RMSApp`. It has 2 pages/columns. The two pages/columns are configured in the files "rmspage1.ini" and "rmspage2.ini". Between the two columns, there is a distance of 3 pixels.

Note

You can freely select the names of the files with the page configurations, "rmspage1.ini" and "rmspage2.ini" in this case.

The use of Run MyScreens configurations in the Display Manager is done as described in Chapter Configuration in the side screen (Page 287). The only difference is that the integration of the configurations is not done in the file "slsidescreen.ini", but in the respective files provided for the configuration of the existing pages.

2 variants are available to you for the integration of Run MyScreens configurations into the Display Manager of SINUMERIK Operate. These are described in the following sections.

14.2 Integration in `SlSideScreenDialog`

For the integration of the Run MyScreens configuration, you must create the dialog instance of `SlSideScreenDialog` in the file "systemconfiguration.ini" and create the file for integrating the Run MyScreens configuration.

The following example shows the integration of a Run MyScreens configuration. The Run MyScreens configuration takes up the entire window of the SLSideScreenDialog dialog, i.e. only one page/column exists.

Procedure

First, create an instance of the SLSideScreenDialog in the "systemconfiguration.ini" file in the [dialogs] section. The instance is given the name "RMSApp".

```
[dialogs]
DLG500= name:=RMSApp,
implementation:=sldmsidescreenapp.SLSideScreenDialog,
process:=SlHmiHost1, preload:=false,
cmdline:="-sidescreen1 rmsapp.ini"
```

In the next step, you will configure or integrate the RunMyScreens configuration in the "rmsapp.ini" file:

```
[Sidescreen]
PAGE001= name:=RMSPage, implementation:=SlSideScreenPage
```

- Create a page with the name "RMSPage".

```
[Page_RMSPage]
ELEMENT001= name:=RMSElement,
implementation:=sleseasyscreen.SLEsSideScreenElement
```

- You create an element with the name RMSElement on the RMSPage. This element is used for displaying the Run MyScreens configuration.

```
[Element_RMSElement]
PROPERTY001= name:=maskPath, type:=QString,
value:="sidescreenmask.com"
PROPERTY002= name:=maskName, type:=QString, value:="Mask"
```

- In the property maskPath, specify the name of the file that contains the RunMyScreens configuration, "sidescreenmask.com" in this case.
- In the property maskName, specify the name of the RunMyScreens mask that is to be displayed, "sidescreenmask.com" in this case.

Store the files "rmsapp.ini" and "systemconfiguration.ini" (see above) in the directory /oem/sinumerik/hmi/cfg or /user/sinumerik/hmi/cfg.

The Run MyScreens configuration is available after the next HMI power-up.

14.3 Integration into SIWidgetsApp

The integration of a Run MyScreens configuration into the SIWidgetsApp application, which is part of the SIEMENS delivery kit, is described in the following.

Depending on which page/column of the SIWidgetsApp application the Run MyScreens configuration is to be integrated into, you must expand either the "sldmwidgets1.ini" file or the "sldmwidgets2.ini" file accordingly.

The following example shows the integration of a Run MyScreens configuration into the left page/column of the SIWidgetsApp application.

Procedure

Expand the "sldmwidgets1.ini" file as follows:

```
[Sidescreen]
PAGE001= name:=WidgetsPage, implementation:=SlSideScreenPage
[Page_WidgetsPage]
ELEMENT100= name:=RMSElement,
implementation:=slseasyscreen.SlEsSideScreenElement
```

- Create an element with the name "RMSElement" for displaying the Run MyScreens configuration.

Note

Use a number range ≥ 100 for new elements. This avoids conflicts with the SIEMENS display elements. The RMSElement is inserted in the WidgetsPage under the SIEMENS elements according to this numbering.

```
[Element_RMSElement]
PROPERTY001= name:=maskPath, type:=QString,
value:="sidescreenmask.com"
PROPERTY002= name:=maskName, type:=QString, value:="Mask"
```

- In the property maskPath, specify the name of the file that contains the RunMyScreens configuration, "sidescreenmask.com" in this case.
- In the Property maskName, specify the name of the RunMyScreens mask that is to be displayed, "Mask" in this case.

Save the file "sldmwidgets1.ini" in the directory /oem/sinumerik/hmi/cfg or /user/sinumerik/hmi/cfg .

The Run MyScreens configuration is available after the next HMI power-up.

14.4 Notes on carrying out Run MyScreens configurations in the Display Manager

Note the following:

- The functions LS, LM, DLGL, EXIT, EXITLS are not available when carrying out Run MyScreens configurations in the Display Manager.
- It is not possible to query the mask size in the LOAD block.
- Texts are always displayed using the font that is used in SINUMERIK Operate with a screen resolution of 640x480 pixels.
- The configured positions of operator controls are implemented without changes (e.g. extension).

14.4 Notes on carrying out Run MyScreens configurations in the Display Manager

- If Run MyScreens configurations are carried out in a side screen page, the entire area of the page is available for the configuration. When carrying out in side screen elements or widgets, the area available for display is specified by the system depending on the context.
- All of the debugging and error outputs are sequentially written to the text file `easyscreen_log.txt`. There is no specific identification indicating which configuration a message comes from.
- The status of a Run MyScreens configuration displayed in the Display Manager is rejected when the configuration is faded out.

Note

The integration of Run MyScreens configurations into the Display Manager can lead to more than one Run MyScreens configuration being carried out simultaneously. To maintain the functional capability of the overall system, take note of the additional system load caused as a result of the hardware used.

Reference lists

A.1 Lists of start softkeys

A.1.1 List of start softkeys for turning

Program operating area for turning

HSK1	HSK2	HSK3	HSK4	HSK5	HSK6	HSK7	HSK8
Edit	Drilling	Turning	Contour turning	Milling	Miscellaneous	Simulation	NC select
HSK9	HSK10	HSK11	HSK12	HSK13	HSK14	HSK15	HSK16
--	Straight-line circle (only for ShopTurn)	--	--	Measure workpiece	Measure tool	OEM	--

Turning

The following tables list the possible start softkeys for turning technology. Assignments of individual start softkeys can differ depending on the particular system. The specified OEM softkeys are permitted for "Run MyScreens".

programGUIDE (G-Code) start softkeys:

	Drilling	Turning	Contour turning		Milling		Miscellaneous	
	HSK2	HSK3	HSK4		HSK5		HSK6	
VSK1	Centering	Stock removal	Contour	--	Face milling	Contour	Settings	High speed settings
VSK2	Drilling reaming	Groove	Stock removal	--	Pocket	Path	Swivel plane	Parallel axes
VSK3	Deep-hole drilling	Undercut	Stock removal residual material	--	Multi-edge spigot	Predrilling	Swivel tool	--
VSK4	Boring	Thread	Grooving	--	Groove	Pocket	--	--
VSK5	Thread	Parting	Grooving residual material	--	Thread milling	Pocket res. mat.	--	--
VSK6	OEM	--	Plunge-turning	--	Engraving	Spigot	Subprogram	--

A.1 Lists of start softkeys

VSK7	Positions	OEM	Plunge turning residual material	OEM	OEM	Spigot res. mat.	--	OEM
VSK8	Repeat position.	--	>>	<<	Contour milling	<<	>>	<<

ShopTurn start softkeys:

	Drilling	Turning	Contour turning		Milling		Miscellaneous		
	HSK2	HSK3	HSK4		HSK5		HSK6		HSK10
VSK1	Drilling centered	Stock removal	New contour	--	Face milling	New contour	Settings	High speed settings	Tool
VSK2	Centering	Groove	Stock removal	--	Pocket	Path	Swivel plane	Parallel axes	Straight line
VSK3	Drilling reaming	Undercut	Stock removal residual material	--	Multi-edge spigot	Predrilling	Swivel tool	Repeat progr.	Circle center point
VSK4	Deep-hole drilling	Thread	Grooving	--	Groove	Pocket	Counter-spindle	--	Circle radius
VSK5	Thread	Parting	Grooving residual material	--	Thread milling	Pocket res. mat.	Transformations	--	Polar
VSK6	OEM	--	Plunge-turning	--	Engraving	Spigot	Subprogram	--	Approach/retract
VSK7	Positions	OEM	Plunge turning residual material	OEM	OEM	Spigot res. mat.	--	OEM	--
VSK8	Repeat position.	--	>>	<<	Contour milling	<<	>>	<<	--

A.1.2 List of start softkeys for milling

Program operating area when milling

HSK1	HSK2	HSK3	HSK4	HSK5	HSK6	HSK7	HSK8
Edit	Drilling	Milling	Contour milling	Turning (only for G code)	Miscellaneous	Simulation	NC select
HSK9	HSK10	HSK11	HSK12	HSK13	HSK14	HSK15	HSK16
--	Straight-line circle (only for ShopMill)	--	--	Measure workpiece	Measure tool	OEM	--

Milling

The following tables list the possible start softkeys for milling technology. Assignments of individual start softkeys can differ depending on the particular system. The specified OEM softkeys are permitted for "Run MyScreens".

programGUIDE (G-Code) start softkeys:

	Drilling	Milling	Contour milling		Turning		Miscellaneous	
	HSK2	HSK3	HSK4		HSK5		HSK6	
VSK1	Centering	Face milling	Contour	--	Stock removal	Contour	Settings	--
VSK2	Drilling ream-ing	Pocket	Path	--	Groove	Stock removal	Swivel plane	Parallel axes
VSK3	Deep-hole drilling	Multi-edge spigot	Predrilling	--	Undercut	Stock removal residual material	Swivel tool	--
VSK4	Boring	Groove	Pocket	--	Thread	Grooving	High speed settings	--
VSK5	Thread	Thread milling	Pocket res. mat.	--	Parting	Grooving residual material	--	--
VSK6	OEM	Engraving	Spigot	--	--	Plunge-turning	Subprogram	--
VSK7	Positions	OEM	Spigot res. mat.	OEM	OEM	Plunge turning residual material	--	OEM
VSK8	Repeat position.	--	>>	<<	Contour turning	<<	>>	<<

ShopMill start softkeys:

	Drilling	Milling	Contour milling		Miscellaneous		Straight line circle
	HSK2	HSK3	HSK4		HSK6		HSK10
VSK1	Centering	Face milling	New contour	--	Settings	--	Tool
VSK2	Drilling ream-ing	Pocket	Path	--	Swivel plane	Parallel axes	Straight line
VSK3	Deep-hole drilling	Multi-edge spigot	Predrilling	--	Swivel tool	Repeat progr.	Circle center point
VSK4	Boring	Groove	Pocket	--	High speed settings	--	Circle radius
VSK5	Thread	Thread milling	Pocket res. mat.	--	Transformations	--	Helix
VSK6	OEM	Engraving	Spigot	--	Subprogram	--	Polar
VSK7	Positions	OEM	Spigot res. mat.	OEM	--	OEM	--
VSK8	Repeat position.	--	>>	<<	>>	<<	--

A.2 List of predefined softkeys

Table A-1 Predefined softkeys

Name	Softkey
SOFTKEY_OK	
SOFTKEY_CANCEL	
SOFTKEY_APPLY	
SOFTKEY_MORE	
SOFTKEY_BACK	
SOFTKEY_ASSISTANT_NEXT	
SOFTKEY_ASSISTANT_PREVIOUS	
SOFTKEY_NAV_BACK	

A.3 List of access levels

The meanings of the different access levels are as follows:

Protection level	Locked by	Area
ac0	Reserved for Siemens	
ac1	Password	Machine manufacturer
ac2	Password	Service
ac3	Password	User
ac4	Keyswitch position 3	Programmer, machine setter
ac5	Keyswitch position 2	Qualified operator
ac6	Keyswitch position 1	Trained operator
ac7	Keyswitch position 0	Semi-skilled operator

A.4 List of colors

System colors

A uniform color table is available for configuring dialogs (subset of the respective standard colors). The color of an element (text, input field, background, etc.) can be selected from the following options (between 0 and 133).

As an alternative to the predefined colors, you can also specify colors as RGB values ("#RRGGBB").

Index	Pictogram	Color	Color description
1		Black	
2		Orange	
3		Dark green	
4		Light gray	
5		Dark gray	
6		Blue	
7		Red	
8		Brown	
9		Yellow	
10		White	
126		Black	Font color of an input/output field that is currently in focus
127		Light orange	Background color of an input/output field that is currently in focus
128		Orange	System color focus
129		Light gray	Background color
130		Blue	Header color (active)
131		Black	Header font color (active)
132		Turquoise	Background color of a toggle field
133		Light blue	Background color of a list box

A.5 List of language codes used in file names

Supported languages

Standard languages:

Language	Abbreviation in file name
Chinese simplified	chs
German	deu
English	eng
French	fra
Italian	ita
Spanish	esp

Other languages:

Language	Abbreviation in file name
Chinese traditional	cht
Danish	dan
Finnish	fin
Indonesian	ind
Japanese	jpn
Korean	kor
Malay	msl
Dutch	nld
Polish	plk
Portuguese (Brazil)	ptb
Romanian	rom
Russian	rus
Swedish	sve
Slovakian	sky
Slovenian	slv
Thai	tha
Czech	csty
Turkish	trk
Hungarian	hun
Vietnamese	vit

A.6 List of accessible system variables

References

List Manual System Variables/PGAs/

A.7 Behavior when opening the dialog (attribute CB)

The following table provides an overview of the conditions when the CHANGE method is called.

The following applies to attribute CB:

CB0

The CHANGE method is triggered when the screen is displayed if the variable has a valid value at this time (e.g. through default setting or NC/PLC variable).

CB1 (default)

The CHANGE method is not explicitly triggered when the screen is displayed. If the variable has a configured NC/PLC variable, then the CHANGE method is of course still called.

Condition				Response
Type	System or user variable	Default setting	Execute the CHANGE method	
I/O field	Yes	Yes	Yes	Due to the configured NC/PLC variable, there is always at least one automatic call of the CHANGE method with the current value of the NC/PLC variable. The pre-assignment of CB does not have an effect.
			No	
		No	Yes	
			No	
	No	Yes	Yes	The CHANGE method is called with the pre-assigned value.
			No	The CHANGE method is not called.
		No	Yes	No call because there is no valid value present to call the CHANGE method.
			No	
Toggle	Yes	Yes	Yes	Due to the configured NC/PLC variable, there is always at least one automatic call of the CHANGE method with the current value of the NC/PLC variable. The pre-assignment of CB does not have an effect.
			No	
		No	Yes	
			No	
	No	Yes	Yes	The CHANGE method is called with the pre-assigned value.
			No	The CHANGE method is not called.
		No (per default the first value from the toggle is assigned)	Yes	The CHANGE method is called with the first pre-assigned value of the toggle list.
			No	The CHANGE method is not called.

A.7 Behavior when opening the dialog (attribute CB)

Tips and tricks

B.1 General tips

- If possible, use the OPI version for system variables (\$ variables).
Reason:
Avoids complex name resolution.
Example:
Instead of "\$R[10]", it is better to use "/Channel/Parameter/R[u1,10]".
- Avoids cyclic (similar) setting, e.g. of the screen and variable HLP property. Compare the value to be set with the current value first, and only set it when it is different.
Reason:
Avoid a time-consuming search of the resolution-dependent help screens.
Example:

```
DEF MyVar=(R3///,"X1",,"mm"/WR1//"$AA_IM[0]")
CHANGE(MyVar)
  IF MyVar.VAL < 100
    HLP="mypic1.png"
  ELSE
    HLP="mypic2.png"
  ENDIF
END_CHANGE
```

Recommendation:

```
CHANGE(MyVar)
  IF MyVar.VAL < 100
    IF HLP <> "mypic1.png"
      HLP="mypic1.png"
    ENDIF
  ELSE
    IF HLP <> "mypic2.png"
      HLP="mypic2.png"
    ENDIF
  ENDIF
END_CHANGE
```

- Replace several RNP() functions in succession with one MRNP() function.
Replace several RDOP() functions in succession with one MRDOP() function.
Reason:
Reduces the communication load and increases the performance.
- Do not read drive parameters faster than in a 1 second cycle, slower is better.
Reason: The communication with the drives can otherwise be extremely disturbed or even cause failures.
- Avoid successive arithmetic operations with system or user variable-connected dialog variables. Use, for example, register (REG[x]) or (invisible) help variables for this.
Reason: Each assignment of a value results in a write operation in the connected system or user variable.
- Similar code used in different blocks should be combined in a SUB block for reasons of transparency, serviceability and performance (when displaying the screen). It can then be called at the appropriate positions with the CALL() function.
- By monitoring the CPU load in the dialog line (setting in slguiconfig.xml), it is possible to investigate the effects of changes in the screen on the performance.

B.2 Tips for debugging

- Use the DEBUG() function for diagnostic purposes. When the DEBUG() function is called, the transferred string is written to the "easyscreen_log.txt" file. The output of information in the dialog line by the DLGL() function can also be helpful.
However, after completion of the screen development, this function should be removed again for performance reasons or commented out.
- The "easyscreen_log.txt" file should have no entries after the development of a screen is completed.

B.3 Tips for the CHANGE method

- Always keep CHANGE methods very short and small, particularly for those whose variables are connected to a system or user variable and change very frequently.
Reason:
Increases the screen performance.
- If possible, do not configure any RNP() functions in CHANGE methods. Instead, it is better to configure an invisible variable parallel to the system or user variable to be read and then use this.
Reason:
An RNP() function would be issued with each call. Otherwise, the current value which is already available would be simply accessed.

Example:

A name resolution is performed via RNP() for each change of the axis motion in order to read channel-specific machine data:

```
DEF AXIS_POSITION_X = (R///,""///"$AA_IM[X] ")

CHANGE (AXIS_POSITION_X)
    DLGL ("Axis "" << RNP("$MC_AXCONF_GEOAX_NAME_TAB[0] ") << ""
has moved: "
<< AXIS_POSITION_X)
END_CHANGE
```

Keep the channel-specific machine data up-to-date with the aid of an invisible variable, copy each value change to a temporary variable, e.g. register.

This temporary variable can then be used in the CHANGE method of the value change for the axis position without making a name resolution of the machine data each time and the subsequent read access:

```
DEF AXIS_POSITION_X = (R///,""///"$AA_IM[X] ")
DEF AXIS_NAME_X = (S///,""/WR0///"$MC_AXCONF_GEOAX_NAME_TAB[0] ")

CHANGE (AXIS_NAME_X)
    REG[0] = AXIS_NAME_X
END_CHANGE

CHANGE (AXIS_POSITION_X1)
    DLGL ("Axis "" << REG[0] << "" has moved " << AXIS_POSITION_X)
END_CHANGE
```

- The update rate and therefore the execution of the associated CHANGE method of variables that are connected to system or user variables with very frequent value changes, can be reduced by using the UR variable property, e.g. variable that is coupled to the actual axis values.
Reason:
In this way, the associated CHANGE method is executed in a fixed specified grid for a value change.

B.4 Tips for DO LOOP loops

As loops can impair the performance of SINUMERIK Operate, depending on the configuration, they should be used carefully and if possible without time-intensive actions.

A register (REG[]) should also be used as run variable, because normal display variables (particularly those with OPI connection) also impair the system performance due to the frequent updates or write operations.

Note that the number of script lines executed "in one operation", is currently limited to 10,000. When this number is reached, the script execution is aborted with an appropriate entry in the "easyscreen_log.txt" file.

Reason:

- Prevention of endless loops
- "Run MyScreens" must remain operable

Animated elements

C.1 Introduction

Introduction

The manual describes working with the X3D Viewer with which you can integrate animated and non-animated graphical scenes (animated elements) – called help screens in the following – into the graphical user interface of SINUMERIK Operate as of Version V4.7 SP1 .

You can show motion sequences and parameters in context-sensitive help screens. This helps you to improve the operation of applications and make the user interface more appealing.

Implementation of your initial idea to the final help screen is described in the steps below:

- Creation of graphical elements and 3D models for the help screens that will eventually appear in the X3D Viewer (see Chapter Modeling (Page 314)).
- Creation of the scene description file in which the model data of the graphics file will be assigned to the scenes and animations to be displayed at particular points (see Chapter Structure of the scene description file (Page 320)).
- Conversion of the X3D files and XML files into HMI files (see Chapter Conversion to hmi file (Page 324)).
- C++ integration of the X3D Viewer into your own application (see Chapter Implementation example (Page 326)).
- Application in Run MyScreens (see Chapter Display in Run MyScreens (Page 327)).

Overview of the file formats




Figure C-1 File formats

File format	Description
.fxw	Graphic file from Vivaty Studio
.x3d	Model file in exchange format
.xml	Definition file for animations and scenes
.hmi	Output file for the X3D Viewer

C.2 Modeling

C.2.1 Requirements

The aim of the modeling is to create a file with the generated 3D models in .x3d file format, an official standard for 3D contents.

The modeling is done in **Vivaty Studio**. Vivaty Studio is a freely available 3D modelling tool with versatile export and import options.

Requirements

- You installed Vivaty Studio, Version 1.0
- You are familiar with modeling and working with Vivaty Studio.
- File format .x3d is not described in any detail in this document, adequate knowledge of the subject is assumed.

Note

You can download Vivaty Studio on the Internet via the link (<https://www.web3d.org/projects/vivaty-studio>).

C.2.2 Rules for modeling

Observe the following rules when modeling. You will only be able to process your help screen file if you have followed these rules correctly.

Rules for modeling

1. The time sensor must have the name "Animation".
2. All related elements must be assigned to a group.
3. All groups must be set to the following position:
x = 0, y = 0, z = 0

4. To make the groups invisible, the translation values are set as follows:
x = 1000000, y = 1000000 and z = 1000000
5. The following elements must have the same names in the Vivaty Studio graphic models and in the XML scene definitions (cf. Chapter Overview (Page 319)):
 - Tool
 - Cameras
6. Before you can create a .x3d file you must make the following settings in dialog box "Export Options":




Figure C-2 Settings in the Export Options dialog box

7. We recommend the following settings for texts (see also the following dialog box):
 - Texts must always be centered.
 - The size of the text should be 0.2. This size allows you to position the text easily. The text output by the X3D Viewer is in the font size of the user interface, irrespective of this value.




Figure C-3 Settings for text

8. To create hatching, use file schnitt.png as the texture. The lines always go from the bottom left to the top right at an angle of 45°. You should set the scaling to 3 in both dimensions. The rotation depends on the construction type and must be adapted manually.




Figure C-4 Settings for hatching

9. We recommend the following sizes/dimensions for the blanks:
 - Cylinder for turning operation:
Length = 5.5 ; Radius = 1.4 (cf. template turning_blank.fxw)
 - Cube for milling operation
x = 4.75 ; y = 3 ; z = 3 (cf. template milling_blank.fxw)

See also

XML commands (Page 319)

C.2.3 Importing graphics (models)

In Flux Studio, you can import external graphics (models). You can store frequently used models, such as tools, as .x3d or .hmi files centrally for further use as finished elements in other help screens. You will find a list of supplied modeling templates in Chapter Modeling templates (Page 318).

Complex objects can also be created with other modeling tools, such as Cinema4D, and then imported.

A description of how you can reuse these models is given below.

Import as inline

Flux Studio uses the object "Inline" for importing .x3d files. It allows you to link in external elements without multiplying the 3D data of these models.

Insert the object with menu item **Create -> Create Inline**. Then enter a file name in the object properties.




Figure C-5 Importing with object "Inline"

Importing 3D model data

Proceed as follows to import model data from a file.

1. Open dialog box "Flux Studio Accutrans3D Translation Utility" via menu item **File -> Import Other Format**.
2. Select a format from the "File Types" list box. For example, to import a Cinema4D file, select file type "3D Studio."
3. Then select a file with **Select Files** and start import.




Figure C-6 Importing 3D model data

The model data from the Cinema4D file is inserted as a complete group. All cameras and any other information that is additionally imported should be deleted. Only the graphics elements of the Cinema4D file are required.

C.2.4 Modeling templates

In this chapter, you will find a list of graphics elements on which you can base your design, colors, and sizes. To maintain a uniform "look and feel" in the user interface, we recommend using the style of the templates or the templates themselves for creating your own graphics.

General

Template	Description
intersection_texture.png	Texture for an sectioned area
rapid_traverse_line_hori.fxw	Horizontal line to illustrate the tool traversing path during rapid traverse
rapid_traverse_line_vert.fxw	Vertical line to illustrate the tool traversing path during rapid traverse

Template	Description
feed_traverse_line_hori.fwx	Horizontal line to illustrate the tool path during feed
feed_traverse_line_vert.fwx	Vertical line to illustrate the tool path during feed
dimensioning_lines_hori.fwx	Horizontal projection lines
dimensioning_lines_vert.fwx	Vertical projection lines
z1_inc.fwx	Horizontal dimension line with the identifier Z1
x1_inc.fwx	Vertical dimension line with the identifier X1
3d_coordinate_origin.fwx	3D coordinate origin
3d_zero_point.fwx	3D zero point

Turning

Template	Description
turning_blank.fwx	The blank for turning technology: A simple cylinder
turning_centerline.fwx	Center line
turning_centerpoint.fwx	Coordinate origin to display the zero point in the WCS
turning_refpoint.fwx	Reference point, for example, for a machining operation
turning_machining_area.fwx	Boundary lines for the machining area

Milling

Template	Description
milling_blank.fwx	The blank for milling technology: A simple cube
milling_centerline.fwx	Center line
milling_refpoint.fwx	Reference point, for example, for a machining operation

C.3 XML commands

C.3.1 Overview

The scene description file (*.xml) is required so that the X3D Viewer can access the graphics. In the scene description file, you assign the scene names that are called from the configuration to the times in the *.x3d file (time sensor) at which the graphics are positioned.

C.3.2 Structure of the scene description file

The structure of the scene description file is shown below together with an explanation of the relevant XML commands:

Design and description

<!-- Treatment of the plane-dependent texts for turning -->

```
<TextPlane plane="G18_ZXY" />
```

Description

```
<TextPlane plane="G18_ZXY" />
```

Treatment of the plane-dependent texts (axis names) specifically for turning. If, for example, a text with the identifier "Z" is used (for G18 first geometry axis), the corresponding geometry axis identifier of the control will be shown in the help screen (for example, "Z").

<!--Text alignment -->

```
<TextPosition center='true' />
```

Description

```
<TextPosition center='true' />
```

Marking that the texts are centered. This is relevant to the display of the texts in rotated screens. We recommend using this setting.

<!--Adapting the tool speed -->

```
<ToolSpeedFactors planeSpeedFactor="0.4" rapidSpeedFactor="0.7"
reducedSpeedFactor="1.0"/>
```

Description

```
<ToolSpeedFactors
```

This entry can be added if the tool speeds are to be modified.

```
planeSpeedFactor="0.4"
```

Factor for the feedrate (0.4 = 40%)

```
rapidSpeedFactor="0.7"
```

Factor for rapid traverse (0.7 = 70%)

```
reducedSpeedFactor="0.1" />
```

Factor for a third speed (0.1 = 10%)

<!--Definition of an animation-->

```
<SceneKey name='BoringAnimation' masterRotationSpeed="-64.0"
maxRotAngle="45.0" begin-Time='0.110' endTime='0.118' view='camiso'
speedMaster='boringtool' Type="VIEW_3D_TURN_CYL">
```

Description

<code><SceneKey name='BoringAnimation'</code>	Name of the animation
<code>masterRotationSpeed="-64.0"</code>	Direction of rotation and rotation speed of the tool. The setting is optional.
<code>maxRotAngle="45.0"</code>	To avoid aliasing effects (tool seems to be turning in the wrong direction). The value is usually a fourth of the symmetry of the tool. The setting is optional.
<code>beginTime='0.110'</code>	Start time of the animation on the time sensor
<code>endTime='0.118'</code>	End time of the animation on the time sensor
<code>view='camiso'</code>	Camera to be used for the animation
<code>speedMaster='boringtool'</code>	Name of the tool for the animation
<code>type="VIEW_3D_TURN_CYL"></code>	View type defines the view (see Section View type (Page 323))

<!-- Elements -->

```
<Element name='1' time='0.110' feed='rapid' dwell='2' />
<Element name='2' time='0.112' feed='rapid' />
<Element name='3' time='0.114' feed='rapid' />
<Element name='4' time='0.116' feed='plane' />
<Element name='5' time='0.118' feed='plane' />
```

Description

<code><Element name='1'</code>	Specifies that it is the first element of the animation.
<code>time='0.110'</code>	Time of the first element on the time sensor
<code>feed='rapid'</code>	Traversing speed of the element plane = machining feedrate rapid = rapid traverse reduced = reduced speed, slower than "plane"
<code>dwell='2'/></code>	Pause in the traversing motion of the animation. A rotating tool continues to rotate.

<!-- End of animation definition -->

`</SceneKey>`

Description

`</SceneKey>`

End of the animation definition

<!-- Existing animation as source for a new animation -->

`<SceneKey source='BoringAnimation' name='BoringAnimationRear' mirror='MirrorScreenX' />`

Description

`<SceneKey source="BoringAnimation"`

Name of an animation that is to use another animation as its source.

`name="BoringAnimationRear"`

Name of the new animation based on the source

`mirror='MirrorScreenX' />`

Mirroring in the direction of the X axis, output is in the new animation.

<!-- Definition of a static scene (screen), (four examples) -->

```
<SceneKey name='Default' time='0.026' view='camiso'
type="VIEW_3D_DRILL_CUT"/>
<SceneKey name='Cut' time='0.046' view='camside' type="VIEW_SIDE"/>
<SceneKey name='Zlink' time='0.056' view='camside' type="VIEW_SIDE"
  highLightedGroup='dad_Zlink'/>
<SceneKey name='Zlabs' time='0.066' view='camside' type="VIEW_SIDE"
  highLightedGroup='dad_Zlabs'/>
```

Description

`<SceneKeyname='Z1abs'`

Screen name

`time='0.066'`

Time of the screen on the time sensor

`view='camside'`

Camera to be used for the screen

`type="VIEW_SIDE"`

View type defines the view (see Section View type (Page 323))

`highLightedGroup='dad_Z1abs'/>`

Name of the group to be highlighted. The group has been called "Z1abs" in Flux Studio. The prefix "dad_" is automatically added by Flux.

<!-- End of xml file --!>

C.3.3 Mirroring and rotations

Mirroring or rotation of the image or model is defined with the **mirror** command.

Description

<code>mirror="RotateScreenX"</code>	The screen is rotated around the X axis
<code>mirror="RotateScreenY"</code>	The screen is rotated around the Y axis
<code>mirror="RotateScreenZ"</code>	The screen is rotated around the Z axis
<code>mirror="MirrorScreenX"</code>	The screen is mirrored along the X axis
<code>mirror="MirrorScreenY"</code>	The screen is mirrored along the Y axis
<code>mirror="MirrorScreenZ"</code>	The screen is mirrored along the Z axis
<code>mirror="RotatePieceX"</code>	The model is rotated around the X axis
<code>mirror="RotatePieceY"</code>	The model is rotated around the Y axis
<code>mirror="RotatePieceZ"</code>	The model is rotated around the Z axis
<code>mirror="MirrorPieceX"</code>	The model is mirrored along the X axis
<code>mirror="MirrorPieceY"</code>	The model is mirrored along the Y axis
<code>mirror="MirrorPieceZ"</code>	The model is mirrored along the Z axis

All rotate and mirror options can be combined. A rotation angle must be defined for rotation.

Examples

```
mirror="RotatePieceZ=180"
mirror="RotatePieceZ=-90 MirrorScreenX"
mirror="RotateScreenY=90"
mirror="MirrorPieceX MirrorPieceY"
mirror="MirrorPieceZ RotatePieceX=-90"
```

C.3.4 View type

You define the views with the view type. The views are based on empirical values and rules that produce a sensible representation of the objects.

This ensures that the representation of the objects matches the coordinate system settings made in the user interface (MD 52000 \$MCS_DISP_COORDINATE_SYSTEM or MD 52001 \$MCS_DISP_COORDINATE_SYSTEM_2).

Description

<code>"VIEW_STATIC"</code>	Direct view without conversion
<code>"VIEW_3D_TURN_CYL"</code>	3D view for turning operations (cylinder)
<code>"VIEW_3D_MILL_CUBE"</code>	3D view for milling operations (cube)
<code>"VIEW_3D_DRILL_CUT"</code>	3D view for drilling operations (sectional view)

"VIEW_SIDE"	2D view for drilling operations (sectional view)
"VIEW_TOP_GEO_AX_1"	2D view from the direction of the 1st geometry axis
"VIEW_TOP_GEO_AX_2"	2D view from the direction of the 2nd geometry axis
"VIEW_TOP_GEO_AX_3"	2D view from the direction of the 3rd geometry axis

C.4 Conversion to hmi file

Note

The X3D files and their associated XML files are converted to HMI files when the HMI is powered up.

For each X3D file, a corresponding XML file of the same name must be created. To do this, you store the X3D files and XML files in directory `search path of HMI\ico\x3d\turning or milling`. You proceed in the same way with the .ts files.

C.5 Display in Create MyHMI /3GL

C.5.1 X3D Viewer

If you want to display particular help screens in a separate OA application you must integrate the X3D Viewer widget into its own OA application.

The X3D Viewer widget provides interfaces, which enable X3D contents to be presented in the HMI.

Class `SIX3dViewerWidget` is provided for displaying graphical scenes. The definition of the class can be found in the corresponding `slx3dviewerwidget.h` header file in the global GUI include directory `\hmi_prog\gui\include`.

C.5.2 Class `SIX3dViewerWidget`

The class provides a flexible widget that autonomously displays the contents of a model file specified during runtime and, if required, runs the animation.

The interface of the class comprises the Constructor, Destructor, and two methods for controlling the graphical output.

As a direct derivative of the Qt class `QWidget`, a much more expansive interface is available, which will not be described in any further detail here, (for example, `show()`, `hide()` and `resize(...)`). For more information, please refer to the Qt documentation).

C.5.3 Public methods

SIX3dViewerWidget (QWidget* pParent = 0)

Constructor of the X3D Viewer widget.

Parameters	Meaning
pParent	The parameter is passed on to the constructor of the QWidget.

~SIX3dViewerWidget ()

Destructor of the X3D Viewer widget.

Parameters	Meaning
-	-

C.5.4 Public slots

void viewSceneSlot (const QString& rsFileName, const QString& rsScene, const QString& rsAnimationScene, int nChannel, int nPlane, SIStepTechnology nTechnology)

With the viewSceneSlot method, the X3D Viewer is instructed to load the rsScene static scene and the rsAnimationScene animated scene from the rsFileName file and display them alternately.

The static scene and then the animated scene are repeatedly alternately displayed for a fixed time.

If no static scene is specified, the animation will be shown immediately; an animated scene may also not have been specified.

Channel number, plane and technology are used to rotate the scenes to the correct position (depending on the set machine coordinate system).

Parameters	Meaning
rsFileName	Name of the file that contains the scenes to be displayed
rsScene	Name of the static scene.
rsAnimationScene	Name of the animated scene.
nChannel	Channel number

Parameters	Meaning
nPlane	Plane
nTechnology	Technology The following constants are defined for the SIStep-Technology enumeration type: • SL_STEP_NO_TECHNOLOGY • SL_STEP_MILLING • SL_STEP_TURNING • SL_STEP_SURFACE_GRINDING • SL_STEP_CIRCULAR_GRINDING

void viewSceneSlot (const QString& rsFileName, const QString& rsScene, const QString& rsAnimationScene)

A simplified form of the viewSceneSlot method with which the X3D Viewer can be instructed to load and display the rsScene static scene and/or the rsAnimationScene animated scene from the rsFileName file.

Parameters	Meaning
rsFileName	Name of the file that contains the scenes to be displayed.
rsScene	Name of the static scene.
rsAnimationScene	Name of the animated scene.

C.5.5 Libraries

In order to be able to apply the X3D Viewer in your own projects, the list of library dependencies must be extended by the 'slx3dviewer.lib' entry.

C.5.6 Implementation example

You will find an implementation example in the package Create MyHMI/3GL under **\examples\GUIFramework\SIExGuiX3D**.

C.5.7 Machine data

Display MD 9104 \$MM_ANIMATION_TIME_DELAY

Time delay in seconds until the animation is started for help screens. The setting does not apply to help screens that are only animated.

The setting applies globally to all animations of SINUMERIK Operate.

C.5.8 Notes about use

- The animation is interrupted if the X3D Viewer widget is hidden. If this happens, there is no need to choose a scene selection without animation.
- You should avoid frequent or multiple instantiation of the X3D Viewer widget as this reduces performance and memory capacity. The use (implementation) of an X3D Viewer Singleton is recommended in such application scenarios.
- The X3D Viewer can also be used in signal slot concepts.
- If an error occurs (for example, a file not found or unknown scene name), the X3D Viewer widget opens a message area. This area is automatically hidden again when another help screen is activated.

C.6 Display in Run MyScreens

This section is intended for experienced "Run MyScreens" developers. Necessary background knowledge is provided in the associated documentation.

In addition to using screens in .bmp or .png format, animated help screens can also be displayed with the X3D Viewer.

To integrate help screens, use the Run MyScreens interface in the usual way.

To output images in .bmp or .png format, XG0 is entered in the definition of a dialog box in the Attributes section or the parameter is left empty. To integrate X3D help screens in a dialog, you must enter **XG1** in the attributes.

```
//M(MASK_F_DR_O1_MAIN/$85407////52,80/XG1)
```

The following parameters are required to activate the individual help screens; their meaning is described in Section 5.3 Public slots:

1. File name
2. StaticScene (optional)
3. AnimationScene (optional)
4. Technology (optional)
5. Plane (optional)

The parameters are combined into a character string in this order, separated by a comma.

```
Hlp = "File name,StaticScene,AnimationScene,Technology,Plane"
```

Examples

- The default help screen can be set with the specified variable Hlp.
In the following example, the "MyAnimation" animation is output from the "MyDlgHelp.hmi" file. No StaticScene is specified, i.e. no static scene is output. No specifications are made for the Technology and Plane, i. e. default values are used.
`Hlp = "MyDlgHelp.hmi,MyAnimation"`
- The hlp property can be set on a specific help screen for the individual parameters of the input screen.
In the following example, the static "MyParam" scene and the "MyAnimation" animation are output from the "MyDlgHelp.hmi" file in the G17 plane. No specification is made for the Technology, i.e. a default value is used.
`VarMyParam.hlp = "MyDlgHelp.hmi,MyParam,MyAnimation,,G17"`

Index

"

"Siemens Industry Online Support" app, 13

A

Access level, 65

Alarms

Language code, 306

Array

Access mode, 196

Column index, 196

Compare mode, 196

Definition, 194

Element, 195

Line index, 196

Status, 198

Attributes, 93

B

Background color, 95

C

Colors, 95

Conditions, 118

Configuration file, 35

Configuration syntax"; "Extended syntax, 46

Configuration syntax"; "Screens, 46

Configuration syntax"; "Softkey, 46

Configuration syntax"; "Table columns, 47

Configuration syntax"; "Variables, 46

Configuring PLC softkeys, 279

Constants, 117

Custom widget

Automatic data exchange, 206

Definition, 203

Executing a method, 209

Interface, 205

Library, 204

Manual data exchange, 207

Reading and writing properties, 208

Responding to a custom widget signal, 212

D

Data matrix code, 13

Defines the softkey menu, 64

Dialog

Definition, 49

Definition block, 50

Multiple columns, 60

Properties, 51

Dialog change mode, 159

Dialog element, 58

Display mode, 93

Display option, 93

DLL file, 151

E

ELLIPSE (define circle), 190

ELLIPSE (define ellipse), 190

F

File

Copy, 137

Delete, 138

Moving, 140

File formats

fxw, 313

hmi, 313

x3d, 313

xml, 313

Focus control, 203

Foreground color, 95

Function

CALL (Subprogram call), 134

CLEAR_BACKGROUND, 192

CP (Copy Program), 137

CVAR (Check Variable), 136

Cyclic execution of scripts, 186

DEBUG, 145

DELETE_GRAPHIC, 192

DLGL (Dialog line), 144

DO LOOP, 184

DP (Delete Program), 138

EP (Exist Program), 139

EVAL (Evaluate), 149

EXIT, 145

EXITLS (EXIT Loading Softkey), 151
FCT, 151
File access, 141
FORMAT (string), 182
GC (Generate Code), 153
HIDE_GRAPHIC, 193
HMI_LOGIN, 156
HMI_LOGOFF, 156
HMI_SETPASSWD, 156
INSTR (String), 178
LA (Load Array), 157
LB (Load Block), 158
LEFT (string), 179
LEN (string), 178
LISTADDITEM, 148
LISTCLEAR, 148
LISTCOUNT, 148
LISTDELETEITEM, 148
LISTINSERTITEM, 148
LM (Load Mask), 159
LS (Load Softkey), 160
MIDS (string), 180
MP (Move Program), 140
MRDOP, 132
MRNP (Multiple Read NC PLC), 163
Overview, 131
P_LOGICAL_FILEPATH, 165
P_REAL_FILEPATH, 166
PI_START, 166
RDFILE, 141
RDLINEFILE, 141
RDOP, 132
Reading and writing drive parameters, 132
Recompile NC code, 172
Recompile without comment, 173
REPLACE (string), 180
RESIZE_VAR_IO, 168
RESIZE_VAR_TXT, 168
RETURN (Back), 171
RIGHT (string), 179
RNP (Read NC PLC Variable), 167
SB (Search Backward), 176
SF (Search Forward), 176
SHOW_GRAPHIC, 193
SL_HMI_INSTALL_DIR, 177
SL_TEMP_DIR, 177
SP (Select Program), 141
START_TIMER, 186
STOP_TIMER, 186
STRCMP (string), 181
STRINSERT (string), 181
STRREMOVE (string), 181

SWITCH, 163
TRIMLEFT (string), 182
TRIMRIGHT (string), 182
UNTIL, 184
WDOP, 132
WHILE, 184
WNP (Write NC PLC Variable), 167
WRFILE, 141
WRLINEFILE, 141

G

General Data Protection Regulation, 14
Generates NC code, 153
Graphic text, 92
Grid → Table, 199

H

H_SEPARATOR (define horizontal dividing line), 191
Help display, 95
Help file, 96
Help variable, 84

I

I/O field with integrated unit selection, 96
Image as short text, 88
Import
 Graphics (models), 317
Input mode, 94

L

Language code, 306
Language-dependent texts, (SIEsTouchButton)
Limits, 92
LINE (define line), 189
List field, 88
Long text, 92

M

Machine data, 326
Machining step support, 173
Master dialog, 159
Mathematical functions, 116
Menu tree, 36
Method
 ACCESSLEVEL, 120

CHANGE, 120
 CHANNEL, 122
 CONTROL, 122
 LANGUAGE, 123
 LOAD, 124
 LOAD GRID, 161
 OUTPUT, 125
 Overview, 119
 PRESS, 126
 PRESS(ENTER), 127
 PRESS(TOGGLE), 127
 RESOLUTION, 128
 RESUME, 129
 SUSPEND, 129
 UNLOAD, 125

Multitouch operation, 243
 mySupport documentation, 11

N

NC variable
 Read, 167
 Write, 167
 Number format, 99

O

OpenSSL, 13
 Operator
 Bit, 118
 Mathematical, 115

P

Password dialogs, 61
 Password input mode (asterisk), 91
 PI services, 132
 PLC variable
 Read, 167
 Write, 167
 Position
 Input/output field, 95, 102
 Short text, 95, 102
 Pre-assignment, 92
 Product support, 12
 Progress bar with two color changes, 89
 Progress bar without color change, 90
 Protection levels, 304
 Public slots, 325

R

RECT (defining a rectangle), 190
 Registers
 Exchanging data, 169
 Status, 170
 Value, 169
 Relational operators, 117

S

Send feedback, 11
 Short text, 92
 Siemens Industry Online Support
 App, 13
 SIEsButton
 Overview of properties, 245
 SIEsGraphCustomWidget
 Reading and writing properties, 216
 SIEsGraphCustomWidgets
 addArc, 237
 addCircle, 237
 addContour, 230
 addEllipse, 236
 addLine, 236
 addPoint, 235
 addRect, 236
 addRoundedRect, 236
 addText, 237
 AxisNameX, 218
 AxisNameY, 218
 AxisY2Factor, 219
 AxisY2Offset, 218
 AxisY2Visible, 218
 BackColor, 224
 ChartBackColor, 224
 clearContour, 232
 CursorColor, 225
 CursorStyle, 227
 CursorX, 226
 CursorY, 226
 CursorY2, 227
 findX, 233
 fitViewToContour, 233
 fitViewToContours, 232
 ForeColor, 224
 ForeColorY2, 225
 GridColor, 225
 GridColorY2, 225
 hideAllContours, 232

- hideContour, 231
 - KeepAspectRatio, 223
 - moveCursorOnContourBack, 242
 - moveCursorOnContourBegin, 240
 - moveCursorOnContourEnd, 241
 - moveCursorOnContourNext, 241
 - Overview of functions, 228
 - Overview of properties, 217
 - Overview of signals, 243
 - removeContour, 232
 - repaint, update, 235
 - ScaleTextEmbedded, 220
 - ScaleTextOrientationYAxis, 221
 - SelectedContour, 224
 - serialize, 242, 263
 - setCursorOnContour, 240
 - setCursorPosition, 239
 - setCursorPositionY2Cursor, 239
 - setFillColor, 239
 - setIntegralFillMode, 234
 - setMargins, 262
 - setMaxContourObjects, 230
 - setPenColor, 238
 - setPenStyle, 238
 - setPenWidth, 238
 - setPolylineMode, 233
 - setView, 229
 - showAllContours, 231
 - showContour, 231
 - ShowCursor, 226
 - ViewChanged, 243
 - ViewMoveZoomMode, 227
 - SIEsTouchButton, (Language-dependent texts)
 - BackColor, 256
 - BackColorChecked, 256
 - BackColorDisabled, 257
 - BackColorPressed, 257
 - BackgroundPicture, 259
 - BackgroundPictureAlignment, 260
 - BackgroundPictureAlignmentString, 260
 - BackgroundPictureKeepAspectRatio, 261
 - ButtonStyle, 246
 - Checkable, 248
 - checked, 265
 - Checked, 249
 - clicked, 264
 - clickedDisabled, 265
 - Enabled, 248
 - Flat, 247
 - Overview of functions, 262
 - Overview of signals, 263
 - Picture, 250
 - PictureAlignment, 251
 - PictureAlignmentString, 252
 - PictureKeepAspectRatio, 253
 - PicturePressed, 251
 - ScaleBackgroundPicture, 261
 - ScalePicture, 252
 - ShowFocusRect, 250
 - Text, 253
 - TextAlignedToPicture, 256
 - TextAlignment, 254
 - TextAlignmentString, 255
 - TextColor, 258
 - TextColorChecked, 258
 - TextColorDisabled, 259
 - TextColorPressed, 258
 - TextPressed, 253
 - Signal color"; "progress bar, 95
 - Signal values"; "progress bar, 92
 - SINUMERIK, 9
 - SIEsTouchButton
 - Reading and writing properties, 245
 - slhlp.xml, 78
 - SIX3dViewerWidget, 324
 - Softkey
 - Assign properties, 64
 - Properties, 66
 - Standard scope, 9
 - Start softkey, 37, 38
 - Strings, 103
 - Sub-dialog, 159
 - Subprogram, 132
 - Block identifier, 135
 - Call, 134
 - cancel, 171
 - Variable, 135
 - System colors, 305
 - System variable, 85, 95
- ## T
- Table
 - Defining columns, 201
 - Definition, 199
 - Programming, 200
 - Technical support, 12
 - Text, 92
 - Toggle field, 87, 92, 100
 - Toggle symbol, 93
 - Tooltip, 92, 94
 - Touch operation, 243
 - Training, 12
 - Trigonometric functions, 116

U

Unit text, 92
Update rate, 93
User variable, 95

V

V_SEPARATOR (define vertical dividing line), 191
Variable
 Calculating, 84
 Change property, 96
 Check, 136
 CURPOS, 105
 CURVER, 105
 End, 146
 ENTRY, 106
 ERR, 107
 FILE_ERR, 107
 FOC, 109
 Parameter, 91
 S_ALEVEL, 110
 S_CHAN, 110
 S_CONTROL, 111
 S_LANG, 111
 S_NCCODEREADONLY, 112
 S_RESX, 112
 S_RESY, 112
Variable status, 83
Variable type, 91
 INTEGER, 97
 VARIANT, 98
Variable value, 83
Vivaty Studio, 314

W

Websites of third-party companies, 9
Write mode, 95

