R45C RSD to Analog Output Converter

Instruction Manual



- Compact converter that reads sensor distance over RSD communications and outputs a voltage or current analog value
- Rugged over-molded design meets IP65, IP67, and IP68
- Connects directly to a sensor or anywhere in-line for ease of use

Models

Housing	Function		Male		Female	Connector
R45	C	-	RSDW	-	I	Q
	C = Converter		RSDW = Converter communicates over Pin 2 (White Wire) using the RSD communications protocol RSDG = Converter communicates over Pin 5 (Gray Wire) using the RSD communications protocol		I = Analog Current Out U = Analog Voltage Out	Q = Integral M12 quick disconnect

The R45C-RSDW-xx converter models are compatible with the following sensors:

Sensor	Versions
Q5XKLAF5000-Q8	V3.0 build and later
Q5XKLAF2000-Q8	V4.0 build and later

The R45C-RSDG-xx converter models are compatible with the following sensors:

Sensor	Versions	Connection
Q5XKLAF5000-Q8	V3.0 build and later	MQDC-4501SS crossover cable required
Q5XKLAF2000-Q8	V4.0 build and later	

Overview

The R45C RSD to Analog Output Converter connects to a distance sensor, and over the RSD communications link, receives the sensor's calculated distance. That distance is converted to an analog value for host side consumption.

- Voltage range is 0 V to 10 V
- Current range is 4 mA to 20 mA

Original Document
222331 Rev. B

14 December 2022

222331

ПРОМЭЛЕКТРОНИКА/ sales@prom-elec.com

Status Indicators

The R45C RSD to Analog Output Converter has two amber LED indicators on both sides for connected sensor status and provides adequate indication visibility. There is also a green LED indicator on both sides of the converter, which signals the device's power status.

Figure 1. R45C status indicators – front and back



* Indicator LEDs are visible through translucent housing

Status 1 LED – Amber	
Indication	**Status**
Solid On/Off	Follows status of LED 1 of connected sensor
Flash at 1 Hz rate	Powered on, no sensor connected
Flash at 4 Hz rate, alternating with Status 2 LED	Powered on, sensor connected, but sensor is not RSD capable

Status 2 LED – Amber	
Indication	**Status**
Solid On/Off	Follows status of LED 2 of connected sensor
Flash at 1 Hz rate	Powered on, no sensor connected
Flash at 4 Hz rate, alternating with Status 1 LED	Powered on, sensor connected, but sensor is not RSD capable

Installation

Mechanical Installation

Install the R45C to allow access for functional checks, maintenance, and service or replacement. Do not install the R45C in such a way to allow for intentional defeat.

All mounting hardware is supplied by the user. Fasteners must be of sufficient strength to guard against breakage. Use of permanent fasteners or locking hardware is recommended to prevent the loosening or displacement of the device. The mounting hole (4.5 mm) in the R45C accepts M4 (#8) hardware. See the figure below to help in determining the minimum screw length.



Screw Length (with screw head fitting in counterbore) = 12.9 mm + “X” mm + 3 mm

CAUTION: Do not overtighten the R45C's mounting screw during installation. Overtightening can affect the performance of the R45C.

Connection Options

When connecting the R45C to a sensor or control system, an adapter may be required depending on the sensor.
For the R45C-RSDG-xx, Pin 5 (gray wire) is used to communicate with an attached sensor.
For the R45C-RSDW-xx, Pin 2 (white wire) is used to communicate with an attached sensor.

Wiring

The following wiring diagrams are examples of different R45C outputs. Wiring is dependent on the sensor connected to the R45C.

Analog (Current)



Analog (Voltage)



Female	Male	Pin	Wire Color
		1	Brown
		2	White
		3	Blue
		4	Black
		5	Gray

Female (RSDG)	Signal Description
Pin 1	18 V DC to 30 V DC
Pin 2	No Connection (N/C)
Pin 3	Ground
Pin 4	Pass-through to Pin 4 (Male)
Pin 5	Banner RSD communications

Female (RSDW)	Signal Description
Pin 1	18 V DC to 30 V DC
Pin 2	Banner RSD communications
Pin 3	Ground
Pin 4	Pass-through to Pin 4 (Male)
Pin 5	No Connection (N/C)

Male (Analog Output)	Signal Description
Pin 1	18 V DC to 30 V DC
Pin 2	Analog Out
Pin 3	Ground
Pin 4	Pass-through to Pin 4 (Female)
Pin 5	Banner 1-wire

Specifications

Supply Voltage
18 V DC to 30 V DC at 50 mA maximum

Supply Protection Circuitry
Protected against reverse polarity and transient voltages

Leakage Current Immunity
400 µA

Resolution
14 bits

Accuracy
0.5%

Indicators
Green: Power LED
Amber: Status 1 LED
Amber: Status 2 LED

Connections
Integral male/female 5-pin M12 quick disconnect

Construction
Coupling Material: Nickel-plated brass
Connector Body: PVC translucent black

Vibration and Mechanical Shock
Meets IEC 60068-2-6 requirements (Vibration: 10 Hz to 55 Hz, 0.5 mm amplitude, 5 minutes sweep, 30 minutes dwell)
Meets IEC 60068-2-27 requirements (Shock: 15G 11 ms duration, half sine wave)

Certifications

Banner Engineering Europe
Park Lane, Culliganlaan 2F bus 3, 1831 Diegem, BELGIUM

Turck Banner LTD Blenheim House, Blenheim Court, Wickford, Essex SS11 8YT, Great Britain

Environmental Rating
IP65, IP67, IP68
NEMA/UL Type 1

Operating Conditions
Temperature: –40 °C to +70 °C (–40 °F to +158 °F)
90% at +70 °C maximum relative humidity (non-condensing)
Storage Temperature: –40 °C to +80 °C (–40 °F to +176 °F)

Required Overcurrent Protection

WARNING: Electrical connections must be made by qualified personnel in accordance with local and national electrical codes and regulations.

Overcurrent protection is required to be provided by end product application per the supplied table.
Overcurrent protection may be provided with external fusing or via Current Limiting, Class 2 Power Supply.
Supply wiring leads < 24 AWG shall not be spliced.
For additional product support, go to www.bannerengineering.com.

Supply Wiring (AWG)	Required Overcurrent Protection (Amps)
20	5.0
22	3.0
24	2.0
26	1.0
28	0.8
30	0.5

Dimensions

All measurements are listed in millimeters [inches], unless noted otherwise.



Accessories

Cordsets

The following cordsets can be used to connect the R45C-RSDG-xx to a 4-pin sensor where the white wire (pin 2) is used for communication (for example, Q5XLAF5000 and Q5XLAF2000 sensors).

4-Pin Female and 5-Pin Male Threaded M12 Cordset—Double Ended			
Model	**Length "L1"**	**Style**	**Pinout**
MQDC-4501SS	0.30 m (0.98 ft)	Female Straight/ Male Straight	Male  1 = Brown 2 = Not Used 3 = Blue 4 = Black 5 = White
MQDC-4506SS	1.83 m (6.00 ft)		
 			Female  1 = Brown 2 = White 3 = Blue 4 = Black

The following cordsets can be used to extend the distance between the sensor and the R45C-RSDG-xx or R45C-RSDW-xx.

5-Pin Male Threaded and 5-Pin Female Quick Disconnect M12 Cordset with Shield—Double Ended				
Model	**Length "L1"**	**Style**	**Pinout (Male)**	**Pinout (Female)**
MQDEC3-503SS	0.91 m (2.99 ft)	Female Straight/Male Straight	 	
MQDEC3-506SS	1.83 m (6 ft)			
MQDEC3-515SS	4.58 m (15 ft)			
MQDEC3-530SS	9.2 m (30.2 ft)			
 			1 = Brown 2 = White 3 = Blue	4 = Black 5 = Gray

Banner Engineering Corp. Limited Warranty

Banner Engineering Corp. warrants its products to be free from defects in material and workmanship for one year following the date of shipment. Banner Engineering Corp. will repair or replace, free of charge, any product of its manufacture which, at the time it is returned to the factory, is found to have been defective during the warranty period. This warranty does not cover damage or liability for misuse, abuse, or the improper application or installation of the Banner product.

THIS LIMITED WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES WHETHER EXPRESS OR IMPLIED (INCLUDING, WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE), AND WHETHER ARISING UNDER COURSE OF PERFORMANCE, COURSE OF DEALING OR TRADE USAGE.

This Warranty is exclusive and limited to repair or, at the discretion of Banner Engineering Corp., replacement. **IN NO EVENT SHALL BANNER ENGINEERING CORP. BE LIABLE TO BUYER OR ANY OTHER PERSON OR ENTITY FOR ANY EXTRA COSTS, EXPENSES, LOSSES, LOSS OF PROFITS, OR ANY INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES RESULTING FROM ANY PRODUCT DEFECT OR FROM THE USE OR INABILITY TO USE THE PRODUCT, WHETHER ARISING IN CONTRACT OR WARRANTY, STATUTE, TORT, STRICT LIABILITY, NEGLIGENCE, OR OTHERWISE.**

Banner Engineering Corp. reserves the right to change, modify or improve the design of the product without assuming any obligations or liabilities relating to any product previously manufactured by Banner Engineering Corp. Any misuse, abuse, or improper application or installation of this product or use of the product for personal protection applications when the product is identified as not intended for such purposes will void the product warranty. Any modifications to this product without prior express approval by Banner Engineering Corp will void the product warranties. All specifications published in this document are subject to change; Banner reserves the right to modify product specifications or update documentation at any time. Specifications and product information in English supersede that which is provided in any other language. For the most recent version of any documentation, refer to: www.bannerengineering.com.

For patent information, see www.bannerengineering.com/patents.

FCC Part 15

This device complies with Part 15 of the FCC Rules. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation is subject to the following two conditions: 1) This device may not cause harmful interference; and 2) This device must accept any interference received, including interference that may cause undesired operation.

Industry Canada

This device complies with CAN ICES-3 (B)/NMB-3(B). Operation is subject to the following two conditions: 1) This device may not cause harmful interference; and 2) This device must accept any interference received, including interference that may cause undesired operation.

Cet appareil est conforme à la norme NMB-3(B). Le fonctionnement est soumis aux deux conditions suivantes : (1) ce dispositif ne peut pas occasionner d'interférences, et (2) il doit tolérer toute interférence, y compris celles susceptibles de provoquer un fonctionnement non souhaité du dispositif.

© Banner Engineering Corp. All rights reserved