# M18T Series Infrared T-GAGE™ Temperature Sensor with Analog Output

## Features

18 mm sensor with 0 to 10 V and 4 to 20 mA analog output and TEACH configuration

To view or download the latest technical information about this product, including specifications, dimensions, accessories, and wiring, go to www.bannerengineering.com.



- Fast 75 ms response time
- Easy-to-use TEACH configuration without potentiometer adjustments
- Small, self-contained package; no auxiliary controller needed
- Rugged encapsulated design for harsh environments
- Choice of 2-meter or 9-meter unterminated cable, or 5-pin M12 quick disconnect
- Product motion is not required for sensing
- Remote configuration is available in both Static and Dynamic modes
- Alarm output for signal maximum
- Configuration for either positive or negative analog slope based on the TEACH order

**WARNING:**
- **Do not use this device for personnel protection**
- Using this device for personnel protection could result in serious injury or death.
- This device does not include the self-checking redundant circuitry necessary to allow its use in personnel safety applications. A device failure or malfunction can cause either an energized (on) or de-energized (off) output condition.

**WARNING:**
- **N'utilisez pas ce dispositif pour la protection du personnel.**
- L'utilisation de ce dispositif pour la protection du personnel pourrait entraîner des blessures graves ou mortelles.
- Ce dispositif n'est pas équipé du circuit redondant d'autodiagnostic nécessaire pour être utilisé dans des applications de protection du personnel. Une panne ou un dysfonctionnement du dispositif peut entraîner l'activation ou la désactivation de la sortie.

## Models

| Model | Cable | D:S Ratio | Sensing Face | Output |
|---|---|---|---|---|
| M18TUP8 | 5-wire, 2 m (6.5 ft) shielded cable | 8:1 | Integrated lens | 0 V DC to 10 V DC analog, plus PNP Alarm |
| M18TUP8Q | 5-pin M12 integral QD | | | |
| M18TUP6E | 5-wire, 2 m (6.5 ft) shielded cable | 6:1 | Enclosed Plastic face (for food industry use) | |
| M18TUP6EQ | 5-pin M12 integral QD | | | |
| M18TUP14 | 5-wire, 2 m (6.5 ft) shielded cable | 14:1 | Narrow-beam lens | |
| M18TUP14Q | 5-pin M12 integral QD | | | |
| M18TIP8 | 5-wire, 2 m (6.5 ft) shielded cable | 8:1 | Integrated lens | 4 to 20 mA analog, plus PNP Alarm |
| M18TIP8Q | 5-pin M12 integral QD | | | |
| M18TIP6E | 5-wire, 2 m (6.5 ft) shielded cable | 6:1 | Enclosed Plastic face (for food industry use) | |
| M18TIP6EQ | 5-pin M12 integral QD | | | |
| M18TIP14 | 5-wire, 2 m (6.5 ft) shielded cable | 14:1 | Narrow-beam lens | |
| M18TIP14Q | 5-pin M12 integral QD | | | |

Models with a quick disconnect require a mating cordset. See "Cordsets - MQDEC2 Series" on page 8 for more information.

The following models are no longer available for order but are still covered by the information in this document.

- M18TUP8 W/30
- M18TUP6E W/30

Original Instructions
14-Oct-26

© Banner Engineering Corp. All rights reserved.
www.bannerengineering.com

123698
p/n: 123698 Rev H

ПРОМЭЛЕКТРОНИКА/ sales@prom-elec.com

- M18TUP14 W/30
- M18TIP8 W/30
- M18TIP6E W/30
- M18TIP14 W/30

# Overview


The T-GAGE analog sensor is a passive, non-contacting, temperature-based device. It is used to detect object temperature within a sensing window and output a proportional voltage or current.

Although it looks and operates just like an Expert™ photoelectric sensor, the T-GAGE detects the infrared light energy emitted by objects instead of its own emitted light. The sensor uses a thermopile detector, made up of multiple infrared-sensitive elements (thermocouples) to detect this infrared energy within its field of view (see "M18T Sensing Field of View" on page 2).

Potential applications include:

- Hot part detection (baked goods, metals, bottles, rubber)
- Ejection verification of injection-molded parts
- Flame process verification
- Hot glue detection (packaging equipment, book binding)
- Cold part detection (frozen foods, ice, dairy)
- Roller monitoring

*Sensor Features*




1. Power LED
2. Alarm Output LED
3. Push Button

**NOTE:** The T-GAGE M18T sensor is not intended for absolute temperature measurement or for safety-related fire detection use.

**NOTE:** Le T-GAGE M18T n'est pas conçu pour une mesure de température absolue ni pour une utilisation dans le cadre de sécurité pour la détection de feu.

# Indicators

| Power ON/OFF LED | Indicates |
|---|---|
| OFF | Power is OFF |
| ON Green | Sensor is in Run mode |
| ON Red | TEACH is active |


| Alarm Output LED | Indicates |
|---|---|
| OFF | **Run Mode:** Alarm output is OFF |
| | **2-Point TEACH active:** Waiting for Span condition |
| ON Amber | **Run Mode:** Alarm output is energized |
| | **2-Point TEACH active:** Waiting for Null condition |
| Flashing Amber | Dynamic TEACH active |

# Sensing Field of View

Sensing range is determined by the sensor's field of view or viewing angle, combined with the size of the object(s) being detected. The sensor's distance-to-spot size ratio (D:S ratio) is inversely related to the viewing angle; a sensor with a small viewing angle will have a large D:S ratio. The T-GAGE M18T sensors have D:S ratios of 6:1, 8:1 or 14:1. For a sensor with an 8:1 D:S ratio, the sensor spot size is a 1" diameter circle at a distance of 8"; farther from the sensor face the spot size will be larger.


© Banner Engineering Corp. All rights reserved.
www.bannerengineering.com

*Detection spot size versus distance from sensor*




| Sensor D:S Ratio | Distance from Sensor Face Versus Spot Size | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|---|---|
| | 100 | 200 | 300 | 400 | 500 | 600 | 700 | 800 | 900 | 1000 | Distance (mm) |
| 6:1 | 17 | 33 | 50 | 67 | 83 | 100 | 117 | 133 | 150 | 167 | Spot Size (mm) |
| 8:1 | 13 | 25 | 38 | 50 | 63 | 75 | 88 | 100 | 113 | 125 | |
| 14:1 | 7 | 14 | 21 | 29 | 36 | 43 | 50 | 57 | 64 | 71 | |

# Apparent Temperature

Two factors that have an influence on apparent temperature are the object's emissivity and whether or not the object fills the sensor's field of view.

**Object Emissivity**

A "blackbody" is a "perfect" emitter, with an emissivity of 1.0 at all temperatures and wavelengths. Most surfaces emit only a fraction of the amount of thermal energy that a blackbody would. Typical T-GAGE applications will be sensing objects with emissivities ranging from 0.5 to 0.95. Many references are available with tables of emissivity coefficients for common materials. In general, shiny unpainted metals have low emissivity, while non-glossy surfaces have high emissivity.

**Shiny Surfaces**

A mirror or shiny surface can redirect an object's emitted energy to an undesired location, or even bring additional unintended thermal energy into the sensor's field of view. See "Application Note" on page 8.

**Object Size**

If the object being detected does not fill the sensor's field of view, then the sensor averages the temperature of that object and whatever else is in the sensing field of view. For the sensor to collect the maximum amount of energy, the object should completely fill the sensor's field of view. In some applications, when the object is too small, this may not be possible. In such cases, if the object is hot enough, the thermal contrast may still be adequate to trigger the sensor output.

# Alarm Output

The alarm output activates when the analog output is at 10 V or 20 mA, depending on the model (see "Figure: Analog/Alarm outputs as a function of taught conditions" on page 4).


© Banner Engineering Corp. All rights reserved.
www.bannerengineering.com


## Analog Output

The T-GAGE analog sensor can be programmed for either positive or negative output slope, based on the teach order (see "Figure: Analog/ Alarm outputs as a function of taught conditions" on page 4).

If the cold limit is taught first, the slope will be positive; if the hot limit is taught first, the slope will be negative.

Banner's scalable output automatically distributes the output signal over the width of the programmed sensing window.

*Analog/Alarm outputs as a function of taught conditions*





# Installation

## Installation Note

Align the sensor toward the object to be detected. Visually align if possible, or use the alignment device accessory listed in "M18T Additional Accessories" on page 9.

## Wiring




**NOTE:** Cabled wiring diagrams are functionally identical.

**NOTE:** Connect the shield wire to earth ground or DC common. Shielded cordsets are recommended for all quick disconnect models.

# M18T Sensor Configuration

Configure the sensor using one of two TEACH methods:

- Two-Point Static TEACH
- Dynamic TEACH


Use the push button or remote input to configure the sensor.

**NOTE:** The duration of each remote line pulse (corresponding to a push button "click"), and the period between multiple pulses, are defined as "T": 0.04 seconds < T < 0.8 seconds.

## Push Button Enable/Disable

The push button can be disabled using the remote input wire (gray) to prevent unauthorized adjustment. To disable the push button, connect a normally open switch between the remote input wire and dc common or connect the remote input wire to a digital output on a Programable Logic Controller (PLC). Perform the procedure below to enable or disable the push button, where 0.04 s < T < 0.8 s.


© Banner Engineering Corp. All rights reserved.
www.bannerengineering.com

| Method | Action | | Result |
|---|---|---|---|
| **Remote Input** | Pulse the remote line four times. |  | The push button is enabled or disabled, depending on the previous condition. |

## 2-Point Static TEACH

Use 2-Point Static TEACH configuration method for applications where both ON and OFF target conditions can be presented to the sensor statically by the operator. The sensor establishes the Null (0 V or 4 mA) output condition with the first configured condition and the Span (10V or 20mA) output condition with the second configured condition, and it scales between these points.

**NOTE:** The sensor returns to RUN mode if the first 2-Point Static TEACH condition is not configured within 60 seconds.

**NOTE:** After the first condition is configured, the sensor remains in 2-Point Static TEACH configuration until the second condition is configured.

1. Access 2-Point Static TEACH configuration.

| Method | Action | | Result |
|---|---|---|---|
| **Push Button** | Press and hold the button for 2 seconds. |  | ◦ Power LED turns Red<br>◦ Alarm LED turns ON |
| **Remote Input** (0.04 s < T < 0.8 s) | No action required. | | |

2. Present the condition for Null output.

| Method | Action | | Result |
|---|---|---|---|
| **Push Button** | Press the button one time. |  | ◦ Alarm LED turns OFF |
| **Remote Input** | Pulse the remote line one time. |  | |

3. Present the condition for Span output.

| Method | Action | | Result |
|---|---|---|---|
| **Push Button** | Press the button one time. |  | **TEACH Accepted**<br>◦ Power LED turns Green<br>◦ The sensor configures analog range and returns to Run mode<br>**2-Point Static TEACH Not Accepted**<br>The sensor returns to the beginning of the TEACH configuration. |
| **Remote Input** | Pulse the remote line one time. |  | |

**NOTE:** To exit 2-Point Static TEACH configuration without saving a configuration, press and hold the push button for 2 seconds or hold the remote line for 2 seconds. The sensor will return to Run mode without saving a configuration.

## Dynamic TEACH

Use Dynamic TEACH configuration method for applications where both the ON and OFF target conditions can not be presented to the sensor dynamically by the operator. After the configuration has been completed, the analog range is optimized by the sensor halfway between the average signals presented during the Dynamic TEACH configuration.

The output slope will remain in the direction of the most recently taught Two-Point Static TEACH or default to positive.


The duration of each button click or remote input pulse is defined as T, where T is: 0.04 s < T < 0.8 s.

1. Access Dynamic TEACH configuration.


© Banner Engineering Corp. All rights reserved.
www.bannerengineering.com

| Method | Action | | Result |
|---|---|---|---|
| **Push Button** | Press and hold the button for 2 seconds. |  | ◦ Power LED turns Red<br>◦ Alarm LED turns OFF |
| **Remote Input** | No action required. | | |

2. Present the sensing conditions.

| Method | Action | | Result |
|---|---|---|---|
| **Push Button** | Press the button two times. |  | ◦ Sensor begins Dynamic TEACH configuration<br>◦ Alarm LED flashes Amber at 2 Hz |
| **Remote Input** | Pulse the remote line two times. |  | |

3. End Dynamic TEACH configuration.


| Method | Action | | Result |
|---|---|---|---|
| **Push Button** | Press the button one time. |  | ◦ The sensor ends data collection; configures Null and Span limits<br>◦ Power LED turns Green<br>◦ The sensor returns to Run mode |
| **Remote Input** | Pulse the remote line one time. |  | |

## Changing Direction of Output Slope

The following procedure changes the direction of the analog output slope from negative to positive or from positive to negative. See "M18T Analog Output" on page 4 for an explanation of the analog output slope.

The duration of each button click or remote input pulse is defined as T, where T is: 0.04 s < T < 0.8 s.

Change the output slope direction.

| Method | Action | | Result |
|---|---|---|---|
| **Push Button** | Not available via the push button. | | The output slope changes from negative to positive or from positive to negative. |
| **Remote Input** | Three-pulse the remote line. |  | |

# Specifications

**Temperature Measurement Range**

−20 °C to +300 °C (−4 °F to +572 °F)[(1)]

Custom ranges available upon request

**Sensing Range**

Depends on object size and sensing field of view (see "M18T Sensing Field of View" on page 2)

**Wavelength**

8 µm to 14 µm

**Distance to Spot Size (D:S) Ratio**

6:1, 8:1, or 14:1, depending on model

**Supply Voltage**

12 V DC to 30 V DC (10% maximum ripple) at less than 35 mA (exclusive of load)

**Output Configuration**

Analog: 0 V to 10 V or 4 mA to 20 mA, depending on model

Alarm: PNP

**Output Protection**

Protected against short-circuit conditions

**Output Ratings**

Analog Voltage: 2.5 kΩ minimum load resistance

Analog Current: 1 kΩ maximum at 24 V input; max. load resistance = [(Vcc - 4)/0.02]Ω

For current output (4-20mA models): Ideal results are achieved when the total load resistance R = [(Vin - 4)/0.02]Ω. **Example**, at Vin = 24 V DC, R ~= 1kΩ (1 watt)

**Alarm**: Off-state leakage: < 10 microamps; Saturation: < 1.2 V at 10 mA and < 1.6 V at 100 mA

**Delay at Power-Up**

1.5 seconds

**Output Response Time**

75 ms (for a 95% step change)


© Banner Engineering Corp. All rights reserved.
www.bannerengineering.com

### Factory Defaults

| Setting | Default |
|---|---|
| Taught Range[1] | −20 °C to +280 °C (−4 °F to +536 °F) |
| Slope | Positive |
| Alarm High Temp | +280 °C (+536 °F) |
| Alarm Lo Temp | +265 °C (+509 °F) |
| Alarm Offset | 50% |
| Alarm Configuration | PNP |
| Alarm Delay | Off |
| Alarm Hold | Off |
| Push Button | Enabled |

### Repeatability
± 1% of measurement, or ± 1 °C, whichever is greater

### Minimum Taught Differential
10 °C

### Linearity
From 0 °C to +50 °C: ± 2 °C

From +50 °C to +300 °C: ±1 °C or ±1%, whichever is greater

[1] Specified linearity applies only within the Temperature Measurement Range of 0 °C to +300 °C (+32 °F to +572 °F).

### Required Overcurrent Protection

**WARNING:** Electrical connections must be made by qualified personnel in accordance with local and national electrical codes and regulations.

Overcurrent protection is required to be provided by end product application per the supplied table.

Overcurrent protection may be provided with external fusing or via Current Limiting, Class 2 Power Supply.

Supply wiring leads < 24 AWG shall not be spliced.

For additional product support, go to www.bannerengineering.com.

| Supply Wiring (AWG) | Required Overcurrent Protection (A) | Supply Wiring (AWG) | Required Overcurrent Protection (A) |
|---|---|---|---|
| 20 | 5.0 | 26 | 1.0 |
| 22 | 3.0 | 28 | 0.8 |
| 24 | 2.0 | 30 | 0.5 |

### Adjustments
TEACH configuration

### Indicators
One bicolor (Green/Red) status LED, one Amber LED (see "M18T Indicators" on page 2)

### Remote Teach Input
Impedance: 3 kΩ minimum load resistance

### Construction
Threaded Barrel: 304 stainless steel

Push Button Housing: ABS/PC

Push Button: Santoprene

Lightpipes: Acrylic

### Operating Conditions
–20 °C to +70 °C (–4 °F to +158 °F)

### Environmental Rating
Leakproof design, IP67

### Temperature Warm-Up Time
5 minutes

### Certifications
Banner Engineering BV
Park Lane, Culliganlaan 2F bus 3
1831 Diegem, BELGIUM

Class 2 power

### Protection contre la surintensité requise

**NOTE:** Les raccordements électriques doivent être effectués par du personnel qualifié conformément aux réglementations et codes électriques nationaux et locaux.

Une protection de surintensité doit être fournie par l'installation du produit final, conformément au tableau fourni.

Vous pouvez utiliser un fusible externe ou la limitation de courant pour offrir une protection contre la surtension dans le cas d'une source d'alimentation de classe 2.

Les fils d'alimentation < 24 AWG ne peuvent pas être raccordés.

Pour obtenir un support produit supplémentaire, rendez-vous sur le site www.bannerengineering.com.

| Câblage d'alimentation (AWG) | Protection contre la surtension requise (ampères) | Câblage d'alimentation (AWG) | Protection contre la surtension requise (ampères) |
|---|---|---|---|
| 20 | 5.0 | 26 | 1.0 |
| 22 | 3.0 | 28 | 0.8 |
| 24 | 2.0 | 30 | 0.5 |

## FCC Part 15 Class A for Unintentional Radiators

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

(Part 15.21) Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

## Industry Canada ICES-003(A)

This device complies with CAN ICES-3 (A)/NMB-3(A). Operation is subject to the following two conditions: 1) This device may not cause harmful interference; and 2) This device must accept any interference received, including interference that may cause undesired operation.

Cet appareil est conforme à la norme NMB-3(A). Le fonctionnement est soumis aux deux conditions suivantes : (1) ce dispositif ne peut pas occasionner d'interférences, et (2) il doit tolérer toute interférence, y compris celles susceptibles de provoquer un fonctionnement non souhaité du dispositif.


© Banner Engineering Corp. All rights reserved.
www.bannerengineering.com

## Application Note


The following are examples of materials with high and low emissivity. Additional examples can be found online.

| Sensor-Friendly Materials (High Emissivity) | | Materials to Sense with Caution (Low Emissivity) |
|---|---|---|
| • Aluminum - anodized<br>• Asphalt<br>• Brick<br>• Carbon - lampblack or plate material<br>• Cardboard - corrugated or chipboard<br>• Concrete<br>• Glass - smooth, lead, or borosilicate (e.g., Pyrex®)<br>• Gypsum (including finished boards) | • Ice<br>• Iron and steel (except bright galvanized)<br>• Paper - most types, regardless of color<br>• Styrofoam® insulation<br>• Plastics<br>• Water<br>• Wood<br>• Rubber (for example, tires) | • Aluminum - plain or highly polished<br>• Copper<br>• Galvanized iron<br>• Stainless steel<br>• Vapor-deposited materials |

## Dimensions

All measurements are listed in millimeters, unless noted otherwise. The measurements provided are subject to change.


*M18T cabled models*




Overall Length

| | |
|---|---|
| Model M18T..8 | 81.2 mm [3.20"] |
| Model M18T..6E | 81.7 mm [3.22"] |
| Model M18T..14 | 86.5 mm [3.41"] |

*M18T QD models*







Overall Length

| | |
|---|---|
| Model M18T..8Q | 91.3 mm [3.59"] |
| Model M18T..6EQ | 91.8 mm [3.61"] |
| Model M18T..14Q | 96.6 mm [3.80"] |

# Accessories

## Cordsets

| 5-Pin Single-Ended M12 Female Shielded Cordsets | | | | |
|---|---|---|---|---|
| **Model** | **Length** | **Style** | **Dimensions** | **Pinout (Female)** |
| MQDEC2-506 | 2 m (6.56 ft) | Straight |  |  |
| MQDEC2-515 | 5 m (16.4 ft) | | | |
| MQDEC2-530 | 9 m (29.5 ft) | | | |
| MQDEC2-550 | 15 m (49.2 ft) | | | |
| MQDEC2-575 | 23 m (75.44 ft) | | | |
| MQDEC2-5100 | 30.5 m (100 ft) | | | |
| MQDEC2-506RA | 2 m (6.56 ft) | Right-Angle |  | 1 = Brown<br>2 = White<br>3 = Blue<br>4 = Black<br>5 = Gray |
| MQDEC2-515RA | 5 m (16.4 ft) | | | |
| MQDEC2-530RA | 9 m (29.5 ft) | | | |
| MQDEC2-550RA | 15 m (49.2 ft) | | | |
| MQDEC2-575RA | 23 m (75.44 ft) | | | |
| MQDEC2-5100RA | 31 m (101.68 ft) | | | |



© Banner Engineering Corp. All rights reserved.
www.bannerengineering.com

## Brackets

**SMB18A**

- Right-angle mounting bracket with a curved slot for versatile orientation
- 12-ga. stainless steel
- 18 mm sensor mounting hole
- Clearance for M4 (#8) hardware
- CAD Files: DXF, PDF, IGS, STP


**Hole center spacing:** A to B = 24.2
**Hole size:** A = ø 4.6, B = 17.0 × 4.6, C = ø 18.5




**SMB18SF**

- 18 mm swivel bracket with M18 × 1 internal thread
- Black thermoplastic polyester
- Stainless steel swivel locking hardware included
- CAD Files: DXF, PDF, IGS, STP


**Hole center spacing:** A = 36.0
**Hole size:** A = ø 5.3, B = ø 18.0




**SMB18UR**

- 2-piece universal swivel bracket
- 300 series stainless steel
- Stainless steel swivel locking hardware included
- Mounting hole for 18 mm sensor
- CAD Files: DXF, PDF, IGS, STP

**Hole center spacing:** A = 25.4, B = 46.7
**Hole size:** B = 6.9 × 32.0, C = ø 18.3




## Additional Accessories

**Air-Purge Collar - APC-18**

- Positive air pressure prevents water, dust, and other airborne contaminants from collecting on the sensor face.
- Air flow helps cool sensors affected by ambient heat in the sensing environment.
- Works with many of Banner's 18 mm threaded-barrel photoelectric and temperature sensors.

**Note: Because air temperature affects the speed of sound, the Collar should not be used with ultrasonic sensors.**



**Laser Alignment Tool - LAT1812**

- Enables easy sensor alignment at long distances.
- Kit includes one SMB1812 bracket and an M12 laser emitter.
- Thread bracket housing onto barrel of mounted sensor; M12 laser emitter inserted into housing provides a precise laser spot for aiming temperature sensor. (Refer to Banner data sheet p/n 122529 for more information.)
- Remove the laser emitter before using the sensor.



# Product Support and Maintenance

## Clean Sensor with Compressed Air and Water

Handle the sensor with care during installation and operation. Sensor windows soiled by fingerprints, dust, water, oil, etc. create stray light that may degrade the peak performance of the sensor.

Blow the window clear using filtered, compressed air, then clean as necessary using only water and a lint-free cloth. Do not use any other chemicals for cleaning.

## Repairs

Contact Banner Engineering for troubleshooting of this device. **Do not attempt any repairs to this Banner device; it contains no field-replaceable parts or components.** If the device, device part, or device component is determined to be defective by a Banner Applications Engineer, they will advise you of Banner's RMA (Return Merchandise Authorization) procedure.

**IMPORTANT:** If instructed to return the device, pack it with care. Damage that occurs in return shipping is not covered by warranty.


© Banner Engineering Corp. All rights reserved.
www.bannerengineering.com

# Contact Us

Banner Engineering Corp. | 9714 Tenth Avenue North | Plymouth, MN 55441, USA | Phone: + 1 888 373 6767

For worldwide locations and local representatives, visit www.bannerengineering.com.

# Banner Engineering Corp Limited Warranty

Banner Engineering Corp. warrants its products to be free from defects in material and workmanship for one year following the date of shipment. Banner Engineering Corp. will repair or replace, free of charge, any product of its manufacture which, at the time it is returned to the factory, is found to have been defective during the warranty period. This warranty does not cover damage or liability for misuse, abuse, or the improper application or installation of the Banner product.

**THIS LIMITED WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES WHETHER EXPRESS OR IMPLIED (INCLUDING, WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE), AND WHETHER ARISING UNDER COURSE OF PERFORMANCE, COURSE OF DEALING OR TRADE USAGE.**

This Warranty is exclusive and limited to repair or, at the discretion of Banner Engineering Corp., replacement. **IN NO EVENT SHALL BANNER ENGINEERING CORP. BE LIABLE TO BUYER OR ANY OTHER PERSON OR ENTITY FOR ANY EXTRA COSTS, EXPENSES, LOSSES, LOSS OF PROFITS, OR ANY INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES RESULTING FROM ANY PRODUCT DEFECT OR FROM THE USE OR INABILITY TO USE THE PRODUCT, WHETHER ARISING IN CONTRACT OR WARRANTY, STATUTE, TORT, STRICT LIABILITY, NEGLIGENCE, OR OTHERWISE.**

Banner Engineering Corp. reserves the right to change, modify or improve the design of the product without assuming any obligations or liabilities relating to any product previously manufactured by Banner Engineering Corp. Any misuse, abuse, or improper application or installation of this product or use of the product for personal protection applications when the product is identified as not intended for such purposes will void the product warranty. Any modifications to this product without prior express approval by Banner Engineering Corp will void the product warranties. All specifications published in this document are subject to change; Banner reserves the right to modify product specifications or update documentation at any time. Specifications and product information in English supersede that which is provided in any other language. For the most recent version of any documentation, refer to: www.bannerengineering.com.

For patent information, see www.bannerengineering.com/patents.


© Banner Engineering Corp. All rights reserved.
www.bannerengineering.com