








T87M2036
Modulating Room Thermostat

EN Installation	NL Installatie	HU Szerelés	SK Inštalácia
ES Instalación	DE Installation	CZ Instalace	RO Instalare
FR Installation	IT Installazione	PL Montaż	TR Kurulum



T87M2036
Modulating
Room Thermostat


Installation



Installer Menu



1

EN Installer menu
ES Menú del instalador
FR Menu d'installation
NL Installatiemenu
DE Installationsmenü
IT Menu di installazione
HU Indítás menü
CZ Menu Nastavení
PL Menu Instalatora
SK Menu Nastavenia
RO Meniul Instalare
TR Menüsunü yükleyin




2

EN | Maximum temperature setting
 ES | Temperatura máxima
 FR | Température maximale
 NL | Maximaal instelbare temperatuur
 DE | Maximale Temperatureinstellung
 IT | Temperatura massima
 HU | Maximális hőmérséklet
 CZ | Maximální nastavení teploty
 PL | Maksymalny limit temperatury
 SK | Maximálne nastavenie teploty
 RO | Setarea temperaturii maxime
 TR | Maksimum sıcaklık ayarı




3

EN | Minimum temperature setting
 ES | Temperatura mínima
 FR | Température minimale
 NL | Minimum instelbare temperatuur
 DE | Minimale Temperatureinstellung
 IT | Temperatura minima
 HU | Minimális hőmérséklet
 CZ | Minimální nastavení teploty
 PL | Minimalnego limit temperatury
 SK | Minimálne nastavenie teploty
 RO | Setarea temperaturii minimă
 TR | Minimum sıcaklık ayarı



4

EN | Control type : standard (Std) or optimal comfort (OPc)
 ES | Tipo de control : estándar (Std) u óptima comodidad (OPc)
 FR | Mode de contrôle : mode standard (Std) ou mode optimal (OPc)
 NL | Type regeling : standaard (STD) of optimaal comfort (OPc)
 DE | Steuerungstyp : Standard (Std) oder optimalen Komfort (OPc)
 IT | Tipo di controllo : comfort standard (Std) o ottimale (OPc)
 HU | Vezérlő típusát : normál (STD) vagy optimális kényelmet (OPc)
 CZ | Typ ovládání : standardní (STD) nebo optimální komfort (OPc)
 PL | Rodzaj regulacji. standardowy (Std) lub optymalnego komfortu (OPc)
 SK | Typ ovládania : štandardnú (STD) alebo optimálny komfort (OPc)
 RO | Tipul de control : confort standard (STD) sau optime (OPc)
 TR | Denetim türünü : Standart (Std) veya optimum konfor (OPc)



5

EN | The Installer Menu closes automatically 10 seconds after the last action
 ES | El menú de instalación se cierra automáticamente 10 segundos después de la última acción
 FR | Le menu d'installation se ferme automatiquement 10 secondes après la dernière action
 NL | Het Installatiemenu sluit automatisch 10 seconden na de laatste actie
 DE | Das Installationsmenü wird automatisch geschlossen, 10 Sekunden nach der letzten Aktion
 IT | Il menu di installazione si chiude automaticamente 10 secondi dopo l'ultima azione
 HU | A telepítő menü automatikusan bezárul 10 másodperccel az utolsó fellépés
 CZ | Instalační Menu se automaticky 10 sekund zavře po poslední akci
 PL | Menu instalatora zamyka się automatycznie 10 sekund po ostatniej akcji
 SK | Inštalčný Menu sa automaticky 10 sekúnd zavrie po poslednej akcii
 RO | Instalare Meniul se închide automat la 10 secunde după ultima acțiune
 TR | Yükleyici Menüsü son eylem sonrasında otomatik olarak 10 saniye kapanır

resideo

Pittway Sarl, Z.A. La Pièce 4,
 1180 Rolle, Switzerland

www.resideo.com Country of origin : UK

© 2020 Resideo Technologies, Inc. All rights reserved.
 The Honeywell Home trademark is used under license from Honeywell International Inc.
 This product is manufactured by Resideo Technologies, Inc. and its affiliates.



EU 811/2013

Printed in EU.

Approvals:

Hereby, **Pittway Sarl** declares that the radio equipment type **T87M** is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: <https://hwlhome.co/DoC>
 RF (868MHz): Receiver Category 2, Max RF Power 25mW, 868-868.6MHz (868.3MHz)