




QUICK GUIDE

EE046 - Condensation Switch


This quick guide provides some information on EE046 connectivity as well as status indication and relay controlled output.

Please note: The mounting location shall be selected very carefully. Crucial is always the least favourable site, usually the one with the highest humidity.

Connection Diagram / Status Indication




Relay Function



Ademco 1 GmbH
Hardhofweg 40
74821 MOSBACH
GERMANY
Phone: +49 6261 810

Manufactured for and on behalf of the
Pittway Sàrl, La Pièce 6, 1180 Rolle, Switzerland by its Authorised
Representative Ademco 1 GmbH

Subject to change
© 2023 Pittway Sàrl. All rights reserved.
This document contains proprietary information of Pittway Sàrl and
its affiliated companies and is protected by copyright and other
international laws. Reproduction or improper use without specific
written authorisation of Pittway Sàrl is strictly forbidden. The
Honeywell Home trademark is used under license from Honeywell
International Inc.



Honeywell Home