

SIMATIC STEP 7		V5.7 SP1	
	Download	Package	
	Article	Article	
European			
STEP 7 V5.7 SP1, Floating License, 1 User	6ES7810-4CE12-0YB5	6ES7810-4CC12-0YA5	
STEP 7 V5.7 SP1, incl. Rental License 50 hrs	6ES7810-4CE12-0YB6	6ES7810-4CC12-0YA6	
STEP 7 V5.7 SP1, Trial License 21 days	--	6ES7810-4CC12-0YA7	
STEP 7 V5.7 SP1, Upgrade (from V5.3 to V5.7), FL, 1 User	6ES7810-4CE12-0YE5	6ES7810-4CC12-0YE5	
STEP 7 V5.7 SP1, Special Upgrade (V5.6 to V5.7), FL, 1 User	6ES7810-4CE12-0YC5	--	
Japanese			
STEP 7 V5.7 SP1 Japanese, Floating License, 1 User	--	6ES7810-4CC12-0JA5	
STEP 7 V5.7 SP1 Japanese, Upgrade, FL, 1 User	--	6ES7810-4CC12-0JE5	
Chinese			
STEP 7 V5.7 SP1 Chinese, Floating License, 1 User	--	6ES7810-4CC12-0KA5	
STEP 7 V5.7 SP1 Chinese, Upgrade, FL, 1 User	--	6ES7810-4CC12-0KE5	
UCL (Unlock Copy License)			
STEP 7 V5.7 SP1, UCL	6ES7810-4CE11-2YA0	6ES7810-4CC11-2YA0	
STEP 7 V5.7 SP1, UCL Upgrade	6ES7810-4CE11-2YE0	6ES7810-4CC11-2YE0	
EPL (Enterprise License)			
STEP 7 V5.7 SP1, EPL-Master	6ES7810-4CE00-2YX0	6ES7810-4CC00-2YX0	
STEP 7 V5.7 SP1, EPL-Royalty	6ES7810-4CE00-2YX1	6ES7810-4CC00-2YX1	
STEP 7 V5.7, EPL-Maintenance	6ES7810-4CE00-2YX2	6ES7810-4CC00-2YX2	

SIMATIC STEP 7 Professional		2021 SR1	
	Download	Paket	
	Artikel	Artikel	
European			
STEP 7 Professional V18 / 2021 SR1 Combo	6ES7810-5CE15-0YB5	6ES7810-5CC15-0YA5	
STEP 7 Professional 2021 SR1, Trial License	--	6ES7810-5CC13-0YA7	
UCL (Unlock Copy License)			
STEP 7 Professional V18 / 2021 SR1 Combo, UCL	6ES7810-5CE12-2YA0	6ES7810-5CC12-2YA0	
EPL (Enterprise License)			
STEP 7 Professional V18 / 2021 SR1 Combo, EPL-Master	6ES7810-5CE00-2YE0	6ES7810-5CC00-2YE0	
STEP 7 Professional V18 / 2021 SR1 Combo, EPL-Royalty	6ES7810-5CE00-2YE1	6ES7810-5CC00-2YE1	
STEP 7 Professional Combo, EPL-Maintenance	6ES7810-5CE00-2YE2	6ES7810-5CC00-2YE2	

S7-PM		V5.7 SP1	
	Download	Package	
	Article	Article	
European			
S7-PM V5.7 SP1, Floating License, 1 User	6ES7811-2CE08-0YB5	6ES7811-2CC08-0YA5	
UCL			
n/a	--	--	
EPL (Enterprise License)			
n/a	--	--	

S7-PDIAG		V5.7
	Download Article	Package Article
European		
S7-PDIAG V5.7, Floating License	--	6ES7840-0CC08-0YA5
S7-PDIAG V5.7, Upgrade	--	6ES7840-0CC08-0YE5
UCL		
n/a	--	--
EPL (Enterprise License)		
S7-PDIAG V5.7, EPL-Master	6ES7840-0CE00-2YX0	6ES7840-0CC00-2YX0
S7-PDIAG V5.7, EPL-Royalty	6ES7840-0CE00-2YX1	6ES7840-0CC00-2YX1
S7-PDIAG V5.7, EPL-Maintenance	6ES7840-0CE00-2YX2	6ES7840-0CC00-2YX2

S7-GRAPH		V5.7 SP1
	Download Article	Package Article
European		
S7-GRAPH V5.7 SP1, Floating License	--	6ES7811-0CC08-0YA5
S7-GRAPH V5.7 SP1, Upgrade	--	6ES7811-0CC08-0YE5
UCL		
n/a	--	--
EPL (Enterprise License)		
S7-GRAPH V5.7 SP1, EPL-Master	6ES7811-0CE00-2YX0	6ES7811-0CC00-2YX0
S7-GRAPH V5.7 SP1, EPL-Royalty	6ES7811-0CE00-2YX1	6ES7811-0CC00-2YX1
S7-Graph V5.7, EPL-Maintenance	6ES7811-0CE00-2YX2	6ES7811-0CC00-2YX2

S7-SCL		V5.7
	Download Article	Package Article
European		
S7-SCL V5.7, Floating License	--	6ES7811-1CC08-0YA5
S7-SCL V5.7, Upgrade	--	6ES7811-1CC08-0YE5
UCL		
n/a	--	--
EPL (Enterprise License)		
S7-SCL V5.7, EPL-Master	6ES7811-1CE00-2YX0	6ES7811-1CC00-2YX0
S7-SCL V5.7, EPL-Royalty	6ES7811-1CE00-2YX1	6ES7811-1CC00-2YX1
S7-SCL V5.7, EPL-Maintenance	6ES7811-1CE00-2YX2	6ES7811-1CC00-2YX2

S7-PLCSIM	V5.4	latest version
	Download Article	Package Article
European		
S7-PLCSIM V5.4, Floating License, 1 User	--	6ES7841-0CC05-0YA5
S7-PLCSIM V5.4, Upgrade, Floating License, 1 User	--	6ES7841-0CC05-0YE5
UCL		
S7-PLCSIM V5.4 Unlock Copy License (UCL), Basic package for 20 installations; only valid in connection with Unlock Copy License agreement	--	6ES7841-0CC05-2YA0
S7-PLCSIM V5.4 Unlock Copy License (UCL), Expansion package for 5 installations; only valid in connection with Unlock Copy License agreement; requires UCL basic package	--	6ES7841-0CC05-2YB0