IO-Link Data Map

This document refers to the following IODD file: Banner_Engineering-T30R_DualDiscrete-20201001-IODD1.1.xml. The IODD file and support files can be found on www.bannerengineering.com under the download section of the product family page.

Communication Parameters

The following communication parameters are used.

Parameter	Value		Parameter	Value
IO-Link revision	V1.1		Port class	A
Process Data In length	48-bit		SIO mode	Yes
Process Data Out length	N/A		Smart sensor profile	Yes
Bit Rate	38400 bps		Block parameterization	Yes
Minimum cycle time	3.9 ms		Data Storage	Yes
			ISDU Supported	Yes

IO-Link Process Data In (Device to Master)

Process Data In is transmitted cyclically to the IO-Link master from the IO-Link device. The T30R IO-Link Process Data is 48-bits and can be configured using parameter data to include the measurement distance, the state of the stability indicator, and/or the state of both output channels. This information is sent to the IO-Link master every 3.9 ms.

Process Data Configuration 1: Digital Measurement Sensor

Subindex	Name	Number of Bits	Data Values
1	Distance Measurement Value	32	0 to 16000 (1)
2	Measurement Scale	8	-3 = range shift of 10^{-3}
3	Stability State	1	0 = no target or marginal, 1 = valid
4	BDC2 State	1	0 = Inactive, 1 = Active
5	BDC1 State	1	0 = Inactive, 1 = Active

Octet 0								
Subindex	1	1	1	1	1	1	1	1
Bit offset	47	46	45	44	43	42	41	40
Value	0	0	0	0	0	0	0	0

Octet 1								
Subindex	1	1	1	1	1	1	1	1
Bit offset	39	38	37	36	35	34	33	32
Value	0	0	0	0	0	0	0	0

Octet 2								
Subindex	1	1	1	1	1	1	1	1
Bit offset	31	30	29	28	27	26	25	24
Value	0	0	0	0	0	1	0	1

(1) Measurement Value Exceptions:
- Out of range (-) = –2147483640
- Out of range (+) = 2147483640
- No measurement data = 2147483644

Original Instructions
29-Jul-25

© Banner Engineering Corp. All rights reserved.
www.bannerengineering.com

217270
p/n: 217270 Rev. A

ПРОМЭЛЕКТРОНИКА/ sales@prom-elec.com

Octet 3								
Subindex	1	1	1	1	1	1	1	1
Bit offset	23	22	21	20	19	18	17	16
Value	1	0	0	1	0	1	1	0

Octet 4								
Subindex	2	2	2	2	2	2	2	2
Bit offset	15	14	13	12	11	10	9	8
Value	1	1	1	1	1	1	0	1

Octet 5								
Subindex	/	/	/	/	/	3	4	5
Bit offset	7	6	5	4	3	2	1	0
Value	N/A	N/A	N/A	N/A	N/A	1	1	1

Example with Digital Measurement Sensor

Based on the values in the Digital Measurement Sensor example:

- Measurement Value: 1430
- Measurement Scale: -3

  Scaled Measurement Value: 1.430m
- Stability State : Valid
- BDC2 State : Active
- BDC1 State: Active

Process Data Configuration 2: Distance and Excess Gain

Subindex	Name	Number of Bits	Data Values
1	Distance Measurement Value	32	0 to 16000
2	Excess Gain Measurement Value	16	

Octet 0								
Subindex	1	1	1	1	1	1	1	1
Bit offset	47	46	45	44	43	42	41	40
Value	0	0	0	0	0	0	0	0

Octet 1								
Subindex	1	1	1	1	1	1	1	1
Bit offset	39	38	37	36	35	34	33	32
Value	0	0	0	0	0	0	0	0

Octet 2								
Subindex	1	1	1	1	1	1	1	1
Bit offset	31	30	29	28	27	26	25	24
Value	0	0	0	0	0	1	0	1

Octet 3								
Subindex	1	1	1	1	1	1	1	1
Bit offset	23	22	21	20	19	18	17	16
Value	1	0	0	1	0	1	1	0

Octet 4								
Subindex	2	2	2	2	2	2	2	2
Bit offset	15	14	13	12	11	10	9	8
Value	0	0	0	0	0	0	0	1

© Banner Engineering Corp. All rights reserved.
www.bannerengineering.com

Octet 5								
Subindex	2	2	2	2	2	2	2	2
Bit offset	7	6	5	4	3	2	1	0
Value	1	1	1	1	1	1	0	1

Example for Distance and Excess Gain

Based on the values in the Distance and Excess Gain example:

- Measurement Value: 1430 (1.43 m)
- Excess Gain: 509

Process Data Configuration 3: Distance and Excess Gain with Binary Data

Subindex	Name	Number of Bits	Data Values
1	Distance Measurement Value	32	0 to 16000
2	Excess Gain Measurement Value	8	(restricted 0–255×)
3	Stability State	1	0=no target or marginal, 1=valid
4	BDC2 State	1	0=inactive, 1=Active
5	BDC1 State	1	0=inactive, 1=Active

Octet 0								
Subindex	1	1	1	1	1	1	1	1
Bit offset	47	46	45	44	43	42	41	40
Value	0	0	0	0	0	0	0	0

Octet 1								
Subindex	1	1	1	1	1	1	1	1
Bit offset	39	38	37	36	35	34	33	32
Value	0	0	0	0	0	0	0	0

Octet 2								
Subindex	1	1	1	1	1	1	1	1
Bit offset	31	30	29	28	27	26	25	24
Value	0	0	0	0	0	1	0	1

Octet 3								
Subindex	1	1	1	1	1	1	1	1
Bit offset	23	22	21	20	19	18	17	16
Value	1	0	0	1	0	1	1	0

Octet 4								
Subindex	2	2	2	2	2	2	2	2
Bit offset	15	14	13	12	11	10	9	8
Value	1	1	1	1	1	1	1	1

Octet 5								
Subindex	/	/	/	/	/	3	4	5
Bit offset	7	6	5	4	3	2	1	0
Value	N/A	N/A	N/A	N/A	N/A	1	1	1

Example with Distance and Excess Gain with Binary Data

Based on the values in the Distance and Excess Gain with Binary Data example:

- Measurement Value: 1430 (1.43 m)
- Excess Gain: 253
- Stability State: Valid
- BDC2 State: Active

© Banner Engineering Corp. All rights reserved.
www.bannerengineering.com

- BDC1 State: Active

IO-Link Process Data Out (Master to Device)

Not applicable.

Parameters Set Using IO-Link

These parameters can be read from and/or written to an IO-Link model of the T30R sensor. Also included is information about whether the variable in question is saved during Data Storage and whether the variable came from the IO-Link Smart Sensor Profile. Unlike Process Data In, which is transmitted from the IO-Link device to the IO-Link master cyclically, these parameters are read or written acyclically as needed.

Index	Subindex	Name	Length	Value Range	Default	Access Rights	Data Storage?	Smart Sensor Profile
0	1-15	Direct Parameter Page 1 (incl. Vendor ID & Device ID)				ro		
0	16	Standard Command		65 = SP1 Single Value Teach 66 = SP2 Single Value Teach 130 = Restore Factory Settings 162 = Start discovery 163 = Stop discovery		wo		
1	1-16	Direct Parameters Page 2				rw		
2		Standard Command	8-bit uinteger	65 = SP1 Single Value Teach 66 = SP2 Single Value Teach 130 = Restore Factory Settings 162 = Start discovery 163 = Stop discovery		wo		y
3		Data Storage Index (device-specific list of parameters to be stored)						
12		**Device Access Locks**	16-bit Record					
12	1	Parameter Write Access Lock	Boolean	0 = off 1 = on	0	rw	y	
12	2	Data Storage Lock	Boolean	0 = off, 1 = on	0	rw	y	
12	3	Local Parameterization Lock	Boolean	0 = off, 1 = on	0	rw	y	
12	4	Local User Interface Lock	Boolean	0 = off, 1 = on	0	rw	y	
16		Vendor Name string	64-octet string	Banner Engineering Corporation		ro		
17		Vendor Text string	64-octet string	More Sensors. More Solutions		ro		
18		Product Name string	64-octet string	T30R		ro		
19		Product ID string	64-octet string			ro		
20		Product Text string	64-octet string	More Sensors. More Solutions		ro		y
21		Serial Number	16-octet string			ro		
22		Hardware Version	64-octet string			ro		
23		Firmware Version	64-octet string			ro		y
24		App Specific Tag (user defined)	32-octet string			rw	y	y
25		Function Tag	32-octet string			rw	y	y
26		Location Tag	32-octet string			rw	y	y
36		Device Status	8-bit Uinteger	0=Device is OK 4=Failure		ro		
37		Detailed Device Status	Array[6] of 3-octet			ro		
40		Process Data Input		see Process Data In		ro		
58		Teach-in Channel	8-bit Uinteger	0=Default, 1=BDC1, 2=BDC2	0	rw		
59		**Teach-In Status**						
59	1	Teach State: 4-bit Integer	4-bit Uinteger	0 = Idle 1 = SP1 Success 2 = SP2 Success 3 = SP1 SP2 Success 4 = Wait for Command 5 = Busy 7 = Error		ro		y
59	2	SP1 TP1	1-bit integer	0 = not taught or unsuccessful 1 = successfully taught		ro		y
59	3	SP1 TP2	1-bit integer	0 = not taught or unsuccessful 1 = successfully taught		ro		y

Continued on page 5

© Banner Engineering Corp. All rights reserved.
www.bannerengineering.com

Continued from page 4

Index	Subindex	Name	Length	Value Range	Default	Access Rights	Data Storage?	Smart Sensor Profile
59	4	SP2 TP1	1-bit integer	0 = not taught or unsuccessful 1 = successfully taught		ro		y
59	5	SP2 TP2	1-bit integer	0 = not taught or unsuccessful 1 = successfully taught		ro		y
60		**BDC1 Setpoints**						
60	1	BDC1 Setpoint SP1 (Switch or Window mode) (mm)	32-bit Integer	300–15000	15000	rw	y	y
60	2	BDC1 Setpoint SP2 (Window mode only) (mm)	32-bit Integer	300–15000 0 = unused for Switch Mode	0	rw	y	y
61		**BDC1 Configuration**						
61	1	BDC1 Switchpoint Logic	8-bit Uinteger	0 = LO (NO), 1 = DO (NC)	0	rw	y	y
61	2	BDC1 Mode	8-bit Uinteger	1 = Switch Mode/Single Point Mode 2 = Window Mode	1	rw	y	y
61	3	Hysteresis	16-bit Uinteger	0–15000	50	rw	y	y
62		**BDC2 Setpoints**						
62	1	BDC2 Setpoint SP1 (Switch or Window mode) (mm)	32-bit Integer	300–15000	15000	rw	y	y
62	2	BDC2 Setpoint SP2 (Window mode only) (mm)	32-bit Integer	300–15000 0 = unused for Switch Mode	0	rw	y	y
63		**BDC2 Configuration**						
63	1	BDC2 Switchpoint Logic	8-bit Uinteger	0 = LO (NO), 1 = DO (NC)	0	rw	y	y
63	2	BDC2 Mode	8-bit Uinteger	1 = Switch Mode/Single Point Mode, 2 = Window Mode	1	rw	y	y
63	3	Hysteresis	16-bit Uinteger	0–15000	50	rw	y	y
64		**Configuration**						
64	1	Response Speed	8-bit Uinteger	0 = Fast 1 = Medium 2 = Slow	1	rw	y	
64	2	Peak Select Mode	8-bit Uinteger	0 = Strongest Peak, 1 = First Peak	1	rw	y	
64	3	Sensor Lockout	8-bit Uinteger	0 = Unlocked, 1 = Locked	0	rw	y	
64	4	Output Polarity	8-bit Uinteger	0 = NPN, 1 = PNP	1	rw	y	
64	5	Process Data Filter Time (ms)	16-bit Uinteger		0	rw	y	
64	6	Process Data Layout	8-bit Uinteger	0=Digital Measurement Sensor 1=Distance and Excess Gain 2=Distance and Excess Gain with Binary Data	0	rw	y	
64	7	Remote Input Mode	8-bit Uinteger	0 = Disabled, 1 = Teach	0	rw	y	
64	8	Minimum amplitude required for target detection	32-bit Integer	100–5000	100	rw	y	
64	9	Limit Filter Enabled	8-bit Uinteger	0 = Disabled, 1 = Enabled	0	rw	y	
64	10	Limit Filter Hold Time (ms)	32-bit Integer	50–60000	1000	rw	y	
64	11	Limit Filter Maximum Distance Increase (mm)	32-bit Integer	0 = disabled 10-1000 = Distance in mm	150	rw	y	
64	12	Limit Filter Maximum Distance Decrease (mm)	32-bit Integer	0 = disabled 10-1000 = Distance in mm	150	rw	y	
64	13	Secondary Output Mode	8-bit Uinteger	0=Independent Output, 1=Complementary, 2=Pulse Frequency Output	0	rw	y	
65		**BDC1 Vendor Specific Configuration**						
65	1	BDC1 Delay On (ms)	32-bit Uinteger	0–60000, 0 = disabled	0	rw	y	
65	2	BDC1 Delay Off (ms)	32-bit Uinteger	0–60000, 0 = disabled	500	rw	y	
65	3	BDC1 Teach Offset (mm)	32-bit Integer	–15000 to 15000	100	rw	y	
66		**BDC2 Vendor Specific Configuration**						
66	1	BDC2 Delay On (ms)	32-bit Uinteger	0–60000, 0 = disabled	0	rw	y	
66	2	BDC2 Delay Off (ms)	32-bit Uinteger	0–60000, 0 = disabled	500	rw	y	
66	3	BDC2 Teach Offset (mm)	32-bit Integer	–15000 to 15000	100	rw	y	
67		**Status**						
67	1	Distance Measurement (mm)	32-bit Integer	0–16000	0	ro	y	

Continued on page 6

© Banner Engineering Corp. All rights reserved.
www.bannerengineering.com

Continued from page 5

Index	Subindex	Name	Length	Value Range	Default	Access Rights	Data Storage?	Smart Sensor Profile
67	2	Excess Gain	32-bit Integer	0–4294967295	0	ro	y	
67	3	Stability	8-bit Uinteger	0 = No Target 1 = Marginal Target 2 = Strong Target	0	ro	y	
67	4	Fault Status	8-bit Uinteger	0 = No Fault Present, 1 = Fault Present	0	ro	y	
67	5	Temperature	32-bit Integer		0	ro	y	
67	6	Last Taught Temperature	32-bit Integer		0	ro	y	
69		All-Time Run Time (0.25 hr)	32-bit Uinteger	0–4294967295	0	ro	y	
70		Resettable Run Time (0.25 hr)	32-bit Uinteger	0–4294967295	0	rw		
71		**PFM Configuration**						
71	1	Loss of Signal	8-bit Uinteger	0=Hold, 1=Low, 2=High	100	rw	y	
71	2	SP1 PFM Setpoint	32-bit Integer	150–15000	300	rw	y	
71	3	SP2 PFM Setpoint	32-bit Integer	150–15000	15000	rw	y	
76		All-Time Run Time Event Time (0.25 hr)	32-bit Uinteger	0–4294967295, 0 = disable raising event	0	rw	y	
77		Resettable Run Time Event Time (0.25 hr)	32-bit Uinteger	0–4294967295, 0 = disable raising event	0	rw	y	
78		**Active Sensing Range**						
78	1	Active Sensing Range Near (mm)	32-bit Integer	0–16000	0	rw	y	
78	2	Active Sensing Range Far (mm)	32-bit Integer	0–16000	16000	rw	y	
16512		**MDC Descriptor**		**Measuring Data Channel Descriptor - Smart Sensor Profile 2nd Edition**				
16512	1	Lower Limit	32-bit Integer		–32000	ro	y	
16512	2	Upper Limit	32-bit Integer		32000	ro	y	
16512	3	Unit	16-bit Uinteger	1010 = m	1010	ro	y	
16512	4	Scale	8-bit Integer	-3 = range shift of 10^{-3}	–3	ro	y	

IO-Link Events

Events are acyclic transmissions from the IO-Link device to the IO-Link master. Events can be error messages and/or warning or maintenance data.

Code	Type	Name	Description
25376 (0x6320)	Error	Parameter error	Check datasheet and values
36000 (0x8ca0)	Warning	All-time Run Time Event	Event indicating the corresponding configured running time has elapsed
36001 (0x8ca1)	Warning	Resettable Run Time Event	Event indicating the corresponding configured running time has elapsed
36003 (0x8ca3)	Notification	Teach Completed Event	Event indicating a teach has been completed
36004 (0x8ca4)	Notification	Factory Settings Restored Event	Event indicating that the factory settings have been restored
36005 (0x8ca5)	Notification	Teach Coerced Event	Event indicating a taught condition resulting in a setpoint being coerced; taught was updated
36007 (0x8ca7)	Notification	Teach Failed Event	Event indicating an invalid target condition was attempted to be taught; taught setpoint was not updated
36096 (0x8d00)	Error	Transceiver Fault Event	Event indicating that an error has occurred with the radar transceiver
36097 (0x8d01)	Error	System Fault Event	Contact Banner Engineering to resolve

© Banner Engineering Corp. All rights reserved.
www.bannerengineering.com